



Manuals.plus /

- › **BIUBLE** /
- › BIUBLE JS006 4250A Jump Starter with 150 PSI Air Compressor User Manual

BIUBLE JS006

BIUBLE JS006 4250A Jump Starter with 150 PSI Air Compressor User Manual

Model: JS006

1. INTRODUCTION

Thank you for choosing the BIUBLE JS006 4250A Jump Starter with 150 PSI Air Compressor. This device is a versatile tool designed to provide emergency vehicle jump-starting, tire inflation, portable power, and an LED flashlight. Please read this manual carefully before use to ensure proper operation and to prevent damage to the product or injury.

4250A Corriente Pico

Inicie el 99.9%
de las baterías DAED en segundos

TODO
Gas

10L
Diésel

60
Veces

26800mAh
Capacidad de batería



Image 1.1: The BIUBLE JS006 Jump Starter connected to a car battery, illustrating its capability to jump-start various vehicle types including cars, trucks, motorcycles, and snowmobiles, and highlighting its 4250A peak current and 26800mAh battery capacity.

2. SAFETY INFORMATION

Always observe the following safety precautions to avoid electric shock, explosion, fire, or injury.

- Do not disassemble the unit.
- Do not expose the unit to rain or moisture.
- Do not use the unit if the cables or clamps are damaged.
- Keep out of reach of children.
- Ensure proper polarity when connecting to a vehicle battery (red clamp to positive, black clamp to negative).
- Do not jump-start a frozen battery.
- Do not use the air compressor for large inflatable items like surfboards or inflatable boats, or heavy truck tires.
- The smart clip cable includes 8 safety protections: low voltage, reverse connection, reverse charge, short circuit, over-temperature, over-voltage, overload, and reverse polarity. Refer to the manual for specific error indicators on the HD display.



Protecciones De Cables De Seguridad

8 Protección, pantalla de visualización y recordatorio de sonido



Protección de bajo voltaje



Protección de conexión inversa



Protección de carga inversa



Protección contra cortocircuitos



Protección contra sobrecalentamiento



Protección contra la sobretensión



Protección contra sobrecargas



Protección de polaridad inversa



Image 2.1: The BIUBLE JS006 Jump Starter with its smart clip cable, illustrating the integrated 8 safety protections and the display for error indications.

3. PACKAGE CONTENTS

Verify that all items are present in your package:

- 1 x BIUBLE JS006 Jump Starter and Air Compressor
- 1 x Smart Clip Cable
- 1 x Inflation Hose
- 1 x DC Cigarette Lighter Adapter
- 1 x USB to Type-C Cable
- 4 x Valve Adapters
- 1 x User Manual



Image 3.1: A visual representation of all items included in the BIUBLE JS006 product package.

4. PRODUCT OVERVIEW

The BIUBLE JS006 combines multiple functions into one compact device:

- **Jump Starter:** 4250A peak current for 12V vehicles (up to 10L gas/diesel engines).
- **Air Compressor:** 150 PSI with HD display, tire pressure detection, preset shutdown, and unit settings (PSI, BAR, KPA, KG/CM²).
- **Power Bank:** 26800mAh capacity with USB and 12V DC outputs for charging electronic devices and powering 12V accessories.
- **LED Flashlight:** 4 modes (solid, strobe, SOS) for emergency lighting.

The device features an LCD display that accurately shows remaining power and inflation pressure.




Image 4.1: Detailed view of the BIUBLE JS006, labeling its ports and control buttons for easy identification and use.



Image 4.2: The integrated storage compartment for accessories, demonstrating the thoughtful design of the BIUBLE JS006.

5. SETUP

5.1 Charging the Device

Before first use, fully charge the BIUBLE JS006. Use the provided USB to Type-C cable to connect the device to a USB wall adapter (not included) or a car charger. The LCD display will show the charging status.

5.2 Checking Battery Level

Press any button to activate the LCD display and check the remaining battery percentage. Ensure the device is sufficiently charged before attempting to jump-start a vehicle or use the air compressor.

6. OPERATING INSTRUCTIONS

6.1 Jump Starting a Vehicle

1. Ensure the jump starter is at least 50% charged.
2. Connect the smart clip cable to the jump starter's auto jump port.
3. Attach the red (+) clamp to the positive terminal of the vehicle battery.
4. Attach the black (-) clamp to the negative terminal of the vehicle battery.
5. The smart clip's display will show the battery voltage. If an error is detected, refer to the troubleshooting section.
6. Start your vehicle.
7. Once the vehicle starts, immediately remove the clamps in reverse order (black first, then red), and then disconnect the smart clip cable from the jump starter.

6.2 Using the Air Compressor

1. Connect the inflation hose to the air compressor port on the device.
2. Attach the other end of the hose to the tire valve. Use appropriate valve adapters if necessary.
3. The HD display will show the current tire pressure.
4. Press the 'M' button to select the desired unit (PSI, BAR, KPA, KG/CM²).
5. Use the '+' and '-' buttons to set the target pressure.
6. Press the 'OK' button to start inflation. The compressor will automatically stop when the preset pressure is reached.

7. Disconnect the hose from the tire valve and the device.



Image 6.1: The BIUBLE JS006 in use, inflating a car tire, demonstrating its 150 PSI wireless air compressor function and digital pressure detection.

6.3 Using as a Power Bank

The JS006 can charge various electronic devices and power 12V accessories.

- **USB Output:** Connect your smartphone, tablet, or other USB-powered devices to the USB output port using a compatible cable.
- **12V DC Output:** Connect the DC cigarette lighter adapter to the 12V DC output port to power 12V accessories like car refrigerators or vacuum cleaners. The maximum continuous output is 160W.



Image 6.2: The BIUBLE JS006 functioning as a power bank, charging multiple electronic devices simultaneously.



Image 6.3: The BIUBLE JS006 providing power to a portable car refrigerator through its 12V DC output.

6.4 Using the LED Flashlight

Press the light button to cycle through the 4 LED flashlight modes:

- **Solid:** For general illumination.
- **Flash:** For signaling or attracting attention.
- **SOS:** For emergency signaling.
- **Off:** To turn off the light.



Image 6.4: The BIUBLE JS006 with its LED flashlight active, illustrating its 400 lumen brightness and multiple modes for emergency and utility lighting.

7. MAINTENANCE

- Store the device in a cool, dry place away from direct sunlight.
- Recharge the device every 3-6 months if not in regular use to maintain battery health.
- Clean the exterior with a soft, dry cloth. Do not use harsh chemicals or abrasives.
- Keep the ports free from dust and debris.

8. TROUBLESHOOTING

The smart clip cable's HD display provides error indicators. Refer to the following for common issues:

Indicator/Problem	Possible Cause	Solution
Low Voltage Indicator	Jump starter battery is low.	Recharge the jump starter.
Reverse Connection Indicator	Clamps are connected to the wrong battery terminals.	Disconnect and reconnect clamps with correct polarity (red to +, black to -).
Short Circuit Indicator	Clamps are touching each other or a short circuit is detected.	Ensure clamps are not touching. Check for any short circuits in the vehicle's battery system.
Reverse Charge Indicator	Vehicle battery is attempting to charge the jump starter.	This usually occurs after the vehicle has started. Disconnect clamps promptly.
High Temperature Indicator	Device is overheating.	Allow the device to cool down before further use. The air compressor has an intelligent temperature control system that stops inflation if temperature is too high.
No Power Output	Device is off or battery is depleted.	Ensure device is turned on and charged.

9. SPECIFICATIONS

Feature	Specification
Model	JS006
Peak Current	4250A
Battery Capacity	26800mAh
Battery Cell Composition	Lithium-ion
Voltage	12V
Max Air Compressor Pressure	150 PSI
Engine Compatibility	Up to 10L Gas/Diesel Engines
Operating Temperature	-20°C to 60°C (-4°F to 140°F)
LED Flashlight Brightness	400 Lumens
Product Dimensions	25.4 x 30.48 x 12.7 cm
Item Weight	2.29 kg



Image 9.1: The BIUBLE JS006 demonstrating its wide operating temperature range, from cold to hot environments.

10. WARRANTY AND SUPPORT

BIUBLE offers a **2-year free return and exchange service** for this product. For any issues or inquiries, please contact our customer support team. We are committed to providing five-star service 24 hours a day, 7 days a week.

Please refer to the contact information provided with your purchase or visit the official BIUBLE website for support.