

Manuals+

[Q & A](#) | [Deep Search](#) | [Upload](#)

manuals.plus /

› [INSOLKIDON](#) /

› [INSOLKIDON Tablet Case User Manual for Headwolf Wpad2 / Wpad3 10.1 inch 2023 Tablets](#)

INSOLKIDON Wpad3

INSOLKIDON Tablet Case User Manual

Model: Wpad3 (Compatible with Headwolf Wpad2 / Wpad3 10.1 inch 2023 Tablet)

INTRODUCTION

Thank you for choosing the INSOLKIDON Tablet Case. This manual provides essential information for the proper installation, use, and maintenance of your new tablet case. Designed specifically for the Headwolf Wpad2 and Wpad3 10.1 inch 2023 Tablets, this case offers comprehensive protection and enhanced functionality.

SAFETY INFORMATION

Please read the following safety guidelines before using the product:

- Keep the case away from extreme temperatures, direct sunlight, and open flames.
- Avoid contact with sharp objects to prevent damage to the material.
- Do not expose the case to excessive moisture or liquids.
- Keep out of reach of small children to prevent choking hazards from small parts.

PACKAGE CONTENTS

Your package should contain the following item:

- 1 x INSOLKIDON Tablet Case (Wpad3 model)

SETUP AND INSTALLATION

Follow these steps to properly install your tablet into the case:

1. **Open the Case:** Lay the case flat on a clean, soft surface with the interior facing upwards.
2. **Align the Tablet:** Carefully align your Headwolf Wpad2 or Wpad3 10.1 inch tablet with the case's frame. Ensure the camera, ports, and buttons align with the corresponding cutouts in the case.
3. **Insert the Tablet:** Gently press the tablet into the case, starting from one corner and working your way around. Ensure all edges of the tablet are securely seated within the case's protective frame.
4. **Verify Fit:** Once inserted, check that all ports, buttons, and the camera are accessible and unobstructed. The case

should fit snugly around the tablet.



Image: The open tablet case, illustrating the interior design for tablet placement.

OPERATING INSTRUCTIONS

Using the Folding Stand

The INSOLKIDON tablet case features a versatile folding stand capability, allowing for comfortable viewing angles for typing, watching videos, or making video calls.

1. **For Viewing Mode:** Fold the front cover backward along the designated creases to form a triangular stand. Place the tablet's edge into the groove on the inside of the cover.
2. **For Typing Mode:** Adjust the fold to create a lower angle, ideal for comfortable typing on a flat surface.



Image: Tablet securely placed in the case, demonstrating the upright viewing stand position.



Image: Tablet in the case, showcasing an alternative, lower angle stand position suitable for typing.

Auto Sleep/Wake Function

The case supports the tablet's auto sleep/wake feature. Opening the cover will automatically wake your tablet, and closing it will put your tablet to sleep, conserving battery life.

Hand Strap Usage

For added security and comfort during handheld use, utilize the integrated hand strap located on the back of the case. Slide your hand through the strap to securely hold your tablet.



Image: A hand demonstrating the use of the integrated strap on the back of the case for secure holding.

FEATURES AND BENEFITS

- **Full Coverage Protection:** Made from durable PU leather, the case provides comprehensive protection against dirt, shocks, and scratches for your tablet.
- **Precise Cutouts:** Designed with precise cutouts to ensure full access to all speakers, buttons, camera, and ports without removing the case.
- **Lightweight and Durable:** The case is constructed from soft, lightweight materials, making it easy to carry while offering robust protection.
- **Easy Installation and Removal:** The flexible design allows for simple insertion and removal of your tablet.

MAINTENANCE

To keep your INSOLKIDON tablet case in optimal condition, follow these cleaning guidelines:

- **Cleaning:** Wipe the exterior of the case with a soft, damp cloth. For stubborn stains, a mild soap solution can be used, but ensure the cloth is only slightly damp.
- **Drying:** Allow the case to air dry completely before reinserting your tablet. Do not use direct heat sources for drying.
- **Avoid Harsh Chemicals:** Do not use strong detergents, abrasive cleaners, or solvents, as these can damage the PU leather material.

TROUBLESHOOTING

Tablet Does Not Fit Properly

Issue: The tablet seems too loose or too tight in the case, or cutouts do not align.

Solution: Ensure you have the correct model of the INSOLKIDON case for your tablet. This case is specifically designed for Headwolf Wpad2 / Wpad3 10.1 inch 2023 Tablets. Double-check your tablet's model number and screen size. Re-insert the tablet carefully, ensuring it snaps into all corners.

Auto Sleep/Wake Function Not Working

Issue: Opening or closing the case does not trigger the tablet's sleep or wake function.

Solution:

- Ensure the tablet is fully seated in the case and not misaligned.
- Check your tablet's settings to confirm that the "Smart Cover" or "Magnetic Cover" feature is enabled. This setting is usually found under Display or Accessibility settings.
- If the issue persists, remove the tablet from the case and reinsert it.

SPECIFICATIONS

Feature	Detail
Product Name	INSOLKIDON Tablet Case
Compatible Devices	Headwolf Wpad2 / Wpad3 10.1 inch 2023 Tablets
Material	PU Leather
Functions	Dirt-Resistant, Shockproof, Scratch-proof, Auto Sleep/Wake, Folding Stand, Hand Strap
Form Factor	Case
Special Features	Adjustable Stand, Anti-Slip

WARRANTY AND SUPPORT

For any questions, concerns, or support needs regarding your INSOLKIDON Tablet Case, please contact the seller or refer to your purchase documentation for warranty information. We are committed to providing high-quality products and customer satisfaction.

Please retain your proof of purchase for any warranty claims.

