

Manuals+

[Q & A](#) | [Deep Search](#) | [Upload](#)

[manuals.plus](#) /

› [ATOZEE](#) /

› [ATOZEE Tablet 2-in-1 Android 14 Tablet with Keyboard \(Model: RM\) User Manual](#)

ATOZEE RM

ATOZEE Tablet 2-in-1 Android 14 Tablet with Keyboard User Manual

Model: RM

1. INTRODUCTION

This manual provides instructions for the ATOZEE 10.1-inch Android 14 Tablet, designed for versatile use with its included keyboard, mouse, stylus, and protective case. It covers setup, operation, maintenance, and troubleshooting to ensure optimal performance and user experience.

2. PACKAGE CONTENTS

Verify that all items are present in the package:

- ATOZEE 10.1-inch Android 14 Tablet
- Bluetooth Keyboard
- Wireless Mouse
- Stylus Pen
- Foldable Protective Case
- Charging Cable
- User Manual (this document)




Image: An overhead view of the ATOZEE tablet, keyboard, mouse, stylus, and protective case, all in a matching navy color, laid out on a white surface.

3. PRODUCT OVERVIEW

The ATOZEE tablet features a 10.1-inch IPS HD touch screen with a resolution of 1280x800 pixels. It is equipped with a 2MP front camera and an 8MP rear camera.

3.1 Physical Components

- **Display:** 10.1-inch IPS HD Touch Screen
- **Front Camera:** 2MP
- **Rear Camera:** 8MP with auto-focus and flash
- **Speakers:** Dual speakers for stereo sound
- **Ports:** USB-C (for charging and data transfer)
- **Buttons:** Power button, Volume up/down

- **MicroSD Card Slot:** For expandable storage up to 1TB

Large storage space

Large capacity storage,
which can save many files
from your work



Image: The ATOZEE tablet in its protective case, showcasing the screen and the tablet's slim profile.

4. SETUP

4.1 Initial Charging

Before first use, fully charge the tablet using the provided charging cable and a compatible power adapter. The battery indicator on the screen will show the charging status.

4.2 Power On/Off

- **To Power On:** Press and hold the Power button until the screen lights up.
- **To Power Off:** Press and hold the Power button, then select "Power off" from the options.
- **To Restart:** Press and hold the Power button, then select "Restart" from the options.

4.3 Connecting Accessories

The tablet comes with a Bluetooth keyboard and wireless mouse.

4.3.1 Bluetooth Keyboard

1. Ensure the keyboard is charged and powered on.
2. On the tablet, go to **Settings > Connected devices > Bluetooth**.
3. Turn on Bluetooth and scan for available devices.
4. Select the keyboard from the list and follow on-screen pairing instructions.

4.3.2 Wireless Mouse

1. Ensure the mouse is powered on.
2. On the tablet, go to **Settings > Connected devices > Bluetooth**.
3. Scan for available devices and select the mouse to pair.

4.3.3 Stylus Pen

The stylus pen is typically passive and does not require pairing. It can be used directly on the screen for navigation or drawing.

10.1inch Tablet

OS
Android 14



Camera
2.0/8.0MP



Battery
6000mAh

RAM/ROM
6GB_{RAM}/32GB_{ROM}



IPS Screen
1280*800



Wi-Fi
2.4G+5G



Image: The ATOZEE tablet in its stand, paired with the Bluetooth keyboard and wireless mouse, demonstrating a complete workstation setup.

5. OPERATING INSTRUCTIONS

5.1 Android 14 Operating System

The tablet runs on Android 14, providing access to the Google Play Store for applications.

- **Navigation:** Use touch gestures (tap, swipe, pinch-to-zoom) on the screen.

- **Home Screen:** Access apps, widgets, and notifications.
- **Settings:** Customize tablet preferences, network connections, and security.
- **Google Play Store:** Download and install applications.

5.2 Using the Camera

The tablet features a 2MP front camera and an 8MP rear camera.

1. Open the **Camera** application.
2. Select between front and rear cameras.
3. Tap the shutter button to take photos or record videos.
4. Adjust settings such as flash and modes as needed.

10.1inch High-definition Large Screen

IPS1280 * 800 resolution,
excellent for browsing web pages or watching movies



Image: The ATOZEE tablet screen displaying a vibrant image of a child swimming underwater, highlighting the display's clarity and color reproduction.

6. CONNECTIVITY

6.1 Wi-Fi Connection

The tablet supports Wi-Fi 6 (802.11ax) for fast wireless internet access.

1. Go to **Settings > Network & internet > Wi-Fi**.
2. Turn on Wi-Fi.
3. Select your desired network from the list.
4. Enter the password if prompted and tap **Connect**.

6.2 Bluetooth Connection

Bluetooth allows connection to wireless headphones, speakers, and other compatible devices.

1. Go to **Settings > Connected devices > Bluetooth**.
2. Turn on Bluetooth.
3. Select the device you wish to pair from the list and follow on-screen instructions.

7. STORAGE AND MEMORY

The tablet is equipped with 6GB RAM (including 4GB extended memory) and 32GB of internal storage (ROM). Storage can be expanded up to 1TB using a microSD card.

7.1 Expanding Storage

1. Locate the microSD card slot on the tablet.
2. Gently insert a compatible microSD card into the slot until it clicks into place.
3. The tablet will prompt you to format the card for use. Follow the on-screen instructions.

A lot of space

RAM 6GB & ROM 32GB

Large space for installing many applications,
with a maximum scalability of 1024GB



Image: A graphic illustrating the tablet's 6GB RAM and 32GB ROM, with an icon indicating 1TB expandable storage capacity.

8. BATTERY MANAGEMENT

The tablet is powered by a 6000mAh battery, providing approximately 8 hours of regular operation.

8.1 Charging

Connect the tablet to a power source using the provided charging cable. It is recommended to use the original charger for optimal performance and safety.

8.2 Battery Saving Tips

- Reduce screen brightness.
- Turn off Wi-Fi and Bluetooth when not in use.
- Close unused applications running in the background.
- Enable battery saver mode in settings.

9. MAINTENANCE

9.1 Cleaning

- Use a soft, lint-free cloth to clean the screen and body of the tablet.
- For stubborn smudges, slightly dampen the cloth with water or a screen cleaner.
- Avoid using harsh chemicals or abrasive materials.

9.2 Storage

Store the tablet in a cool, dry place away from direct sunlight and extreme temperatures. Use the protective case to prevent scratches and minor damage.

10. TROUBLESHOOTING

10.1 Tablet Does Not Power On

- Ensure the battery is charged. Connect the tablet to a charger for at least 30 minutes.
- Press and hold the Power button for 10-15 seconds to force a restart.

10.2 Screen Freezes or Becomes Unresponsive

- Press and hold the Power button for 10-15 seconds to force a restart.
- If the issue persists, consider performing a factory reset (*Note: This will erase all data. Back up important files first.*).

10.3 Cannot Connect to Wi-Fi

- Ensure Wi-Fi is enabled in settings.
- Restart your Wi-Fi router.
- Forget the network in tablet settings and try reconnecting.

10.4 Bluetooth Device Not Pairing

- Ensure Bluetooth is enabled on both the tablet and the accessory.
- Make sure the accessory is in pairing mode.
- Restart both devices and attempt pairing again.

11. SPECIFICATIONS

Feature	Specification
Model	RM
Operating System	Android 14
Screen Size	10.1 Inches
Screen Resolution	1280 x 800 IPS
RAM	6GB (including 4GB extended memory)
Internal Storage (ROM)	32GB
Expandable Storage	Up to 1TB via MicroSD card
Rear Camera	8MP
Front Camera	2MP
Battery Capacity	6000mAh
Average Battery Life	8 Hours
Wireless Connectivity	Wi-Fi 6 (802.11ax), Bluetooth
Dimensions (LxWxH)	9.7 x 6 x 0.3 inches
Item Weight	1 pound
Processor Brand	MediaTek

12. WARRANTY AND SUPPORT

For warranty information and technical support, please refer to the contact details provided with your purchase documentation or visit the official ATOZEE website. Keep your proof of purchase for warranty claims.

Related Documents - RM

	Atozee Q3K Kids Tablet: User Manual and Specifications Comprehensive user manual for the Atozee Q3K kids tablet, detailing specifications, features, port layout, and FCC compliance information. Features Android 14 (Go edition) and a 7-inch display.
---	---

	<p>AT70K Kids Tablet User Manual</p> <p>User manual for the AT70K Kids Tablet, detailing specifications, device layout, and basic operation. Includes FCC statement.</p>
	<p>Atozee Q3K Kids Tablet: User Manual and Specifications</p> <p>Comprehensive user manual for the Atozee Q3K kids tablet, detailing specifications, features, port layout, and FCC compliance information. Features Android 14 (Go edition) and a 7-inch display.</p>
	<p>AT70K Kids Tablet User Manual</p> <p>User manual for the AT70K Kids Tablet, detailing specifications, device layout, and basic operation. Includes FCC statement.</p>
	<p>Mircom FA-300 Series LCD Display Fire Alarm Control Units</p> <p>Mircom's FA-300 Series fire alarm control panels offer 6 and 12 zone models with integrated UDACT/Digital Communicator, featuring LCD displays and keypads for easy configuration. These panels are suitable for small to medium commercial, institutional, and industrial occupancies, providing reliable fire alarm control and monitoring.</p>
	<p>Mircom FA-300-6DDR-CG Marine Fire Alarm Control Unit - Features, Specifications, and Ordering</p> <p>Detailed information on the Mircom FA-300-6DDR-CG Marine Fire Alarm Control Unit, including its features, technical specifications, adder modules, remote annunciators, and ordering details. Approved by the US Coast Guard and UL listed.</p>