Saved from manuals.plus.
Open the live page for links to other documents and user manuals.

Kircuit AC Adapter Charger

Kircuit AC Adapter Charger User Manual

For KETTLER Verso 309 Crosstrainer 68003170 Power PSU

Introduction

This manual provides essential information for the safe and effective use of your Kircuit AC Adapter Charger. Designed to meet the power requirements of your KETTLER Verso 309 Crosstrainer, this adapter converts standard AC power into the DC power necessary for your device's operation and battery charging. Please read this manual thoroughly before use to ensure proper setup, operation, and maintenance.

Package Contents

Upon opening the package, please verify that all components are present and in good condition:

- 1 x Kircuit AC Adapter Charger

Setup

Follow these steps to properly set up your AC adapter:

1. **Identify the Power Outlet:** Locate a standard electrical power outlet (100V-240V AC) that is easily accessible.
2. **Connect to Device:** Insert the DC barrel connector of the AC adapter firmly into the power input port of your KETTLER Verso 309 Crosstrainer. Ensure a snug fit.
3. **Plug into Wall Outlet:** Plug the AC prongs of the adapter into the electrical power outlet. The adapter is designed for wall mount use.
4. **Verify Connection:** Confirm that the adapter is securely connected to both the device and the power outlet. Your device should now receive power or begin charging its battery.



The Kircuit AC Adapter Charger connected to a power strip, ready for use with your device.

Operating Instructions

The Kircuit AC Adapter Charger is designed for straightforward operation:

- **Powering Your Device:** Once connected as per the setup instructions, the adapter will continuously supply power to your KETTLER Verso 309 Crosstrainer, allowing it to operate.
- **Charging Batteries:** If your device has a rechargeable battery, the adapter will automatically initiate the charging process when connected and powered.
- **Overcharge Protection:** The adapter features built-in Dynamic IC, Charger IC, and power fuse for rapid charging and protection against overcharging, ensuring the safety of your device.



The Kircuit AC Adapter Charger, a reliable power source for your equipment.

Maintenance and Care

To ensure the longevity and optimal performance of your AC adapter, follow these maintenance guidelines:

- **Keep Clean:** Regularly wipe the adapter with a dry, soft cloth to remove dust and dirt. Do not use liquid cleaners.
- **Avoid Extreme Conditions:** Do not expose the adapter to extreme temperatures, high humidity, or direct sunlight.
- **Handle Cables Carefully:** Avoid bending or crimping the power cord excessively, especially near the connectors, to prevent internal wire damage.
- **Unplug When Not in Use:** For extended periods of non-use, unplug the adapter from both the wall outlet and your device.

Troubleshooting

If you encounter issues with your AC adapter, refer to the following common problems and solutions:

- **No Power to Device:**
  - Ensure the adapter is securely plugged into a working wall outlet.
  - Verify that the DC barrel connector is fully inserted into your device's power port.
  - Test the wall outlet with another device to confirm it has power.
- **Adapter Feels Hot:**
  - It is normal for adapters to feel warm during operation. However, if it is excessively hot to the touch or emitting a burning smell, immediately unplug it and discontinue use.
  - Ensure adequate ventilation around the adapter; do not cover it.
- **Device Not Charging:**
  - Confirm the adapter's specifications match your device's power requirements.
  - Check your device's battery for any issues.

Specifications

Feature	Description
Brand	Kircuit
Input Voltage	100V-240V AC, 50/60Hz 0.3A
Output	*(Output specifications not provided in input, typically listed on adapter label)*
Connectivity Technology	DC Barrel
Connector Type	Barrel Connector
Compatible Devices	KETTLER Verso 309 Crosstrainer (and other devices requiring similar power)
Special Feature	Travel-friendly design
Mounting Type	Wall Mount
Included Components	1 x AC Adapter
Cord Length	Approximately 6.5 ft



The adapter's cord length is approximately 6.5 feet, providing ample reach.

Safety Information

Please observe the following safety precautions:

- Use only with compatible devices as specified.
- Do not disassemble or modify the adapter.
- Keep out of reach of children.
- Do not use in wet environments or near water.
- If the adapter or cord is damaged, discontinue use immediately.
- Ensure proper ventilation to prevent overheating.

Warranty and Support

Kircuit products are manufactured to high-quality standards. For information regarding warranty coverage, technical support, or replacement parts, please refer to the contact information provided with your purchase or visit the official Kircuit website. Please retain your proof of purchase for warranty claims.

© 2024 Kircuit. All rights reserved.

Ask a question about this manual

Ask about setup, troubleshooting, compatibility, parts, safety, or missing instructions. Manuals+ will review the question and use this page's manual context to help answer it.

Name

Anonymous

Email

you@example.com

After a successful submission, we securely hash the supplied account or form email before sending it to Microsoft Advertising for conversion attribution. Privacy details.

Question

Example: How do I reset this device or fix this error?

Details

Model number, symptoms, what you tried, or the section of the manual you are using.

Submit question

Open the live page

https://manuals.plus/asin/B0CGDFM5VX

More documents and user manuals: **https://manuals.plus/**