

Kircuit W-8250-50BS A-PT 50 Digital Compatible

Kircuit AC/DC Adapter Instruction Manual

Model: W-8250-50BS A-PT 50 Digital Compatible Adapter

1. INTRODUCTION

This manual provides essential information for the safe and effective use of your Kircuit AC/DC Adapter. This adapter is specifically designed to provide power to Accuteck Series W-8250-50BS A-PT 50 Digital devices, converting standard AC wall power into the DC power required by your equipment. It allows you to operate your device or charge its battery from electrical power outlets.

2. IMPORTANT SAFETY INFORMATION

- Read all instructions before use to ensure safe operation.
- Do not expose the adapter to rain, moisture, or extreme humidity.
- Do not disassemble the adapter. Refer all servicing to qualified personnel.
- Ensure the adapter's input voltage (100V-240V AC) matches your power outlet's voltage.
- Avoid using the adapter in extremely hot, cold, or poorly ventilated environments.
- Keep the adapter out of reach of children.
- Unplug the adapter from the power outlet when not in use for extended periods.
- Use only with compatible devices as specified to prevent damage.

3. PACKAGE CONTENTS

- 1 x Kircuit AC/DC Adapter

4. PRODUCT SPECIFICATIONS

| Feature       | Detail       |
|---------------|--------------|
| Brand         | Kircuit      |
| Input Voltage | 100V-240V AC |

|                           |                                                                                                 |
|---------------------------|-------------------------------------------------------------------------------------------------|
| Input Frequency           | 50/60Hz, 0.3A                                                                                   |
| Power Source              | Corded Electric                                                                                 |
| Main Power Connector Type | 2 Pin (US Standard)                                                                             |
| Cord Length               | Approximately 6.5 ft (2 meters)                                                                 |
| Special Features          | Travel-friendly design, Built-in Dynamic IC, Charger IC & Power fuse for overcharge protection. |

## 5. SETUP INSTRUCTIONS

Follow these steps to set up your Kircuit AC/DC Adapter:

- 1. Identify Compatibility:** Ensure your device is an Accuteck Series W-8250-50BS A-PT 50 Digital or a compatible model requiring this specific adapter type.
- 2. Connect to Device:** Carefully insert the DC output plug of the Kircuit adapter into the power input port of your Accuteck device. Ensure a snug and secure connection.
- 3. Connect to Power Outlet:** Plug the AC input prongs of the adapter into a standard 100V-240V AC wall outlet.
- 4. Verify Power:** Once connected, your device should receive power or begin charging, indicated by its power indicator light (if applicable).



*Image 1: The Kircuit AC/DC adapter connected to a power strip, demonstrating a typical setup environment.*

## 6. OPERATING INSTRUCTIONS

---

The Kircuit AC/DC Adapter is designed for straightforward operation:

- Once properly connected as described in the "Setup Instructions," the adapter will automatically supply power to your device.
- If your device has a rechargeable battery, the adapter will initiate charging when connected to a power source.
- The adapter features built-in overcharge protection to safeguard your device's battery.
- To disconnect, first unplug the adapter from the wall outlet, then disconnect the DC plug from your device.



Image 2: The Kircuit AC/DC adapter with its 6.5 ft power cord, highlighting the length for flexible placement.

## 7. CARE AND MAINTENANCE

- Keep the adapter clean and dry. Wipe with a soft, dry cloth if necessary.
- Do not use liquid cleaners or abrasive materials, as these can damage the adapter.
- Store the adapter in a cool, dry place when not in use.
- Avoid bending, twisting, or crimping the power cord excessively to prevent internal wire damage.

## 8. TROUBLESHOOTING

| Problem | Possible Cause | Solution |
|---------|----------------|----------|
|---------|----------------|----------|

|                                             |                                                          |                                                                                                                                                                            |
|---------------------------------------------|----------------------------------------------------------|----------------------------------------------------------------------------------------------------------------------------------------------------------------------------|
| Device not powering on/charging.            | Adapter not properly connected to device or wall outlet. | Ensure both ends of the adapter are securely plugged in. Try a different wall outlet.                                                                                      |
| Device is compatible but still not working. | Faulty wall outlet or device issue.                      | Test the wall outlet with another appliance. If the outlet works, the issue might be with your device.                                                                     |
| Adapter feels unusually hot.                | Overload or poor ventilation.                            | Unplug immediately. Ensure the adapter is used in a well-ventilated area and is compatible with the device's power requirements. If overheating persists, discontinue use. |



Image 3: A detailed view of the Kircuit AC/DC adapter, showing its specifications label. Always verify compatibility with your device.

## 9. WARRANTY AND CUSTOMER SUPPORT

For warranty information or technical support, please refer to the documentation provided with your purchase or contact your retailer. Kircuit adapters are designed for reliability and come with standard protections for safe operation. Please retain your proof of purchase for any warranty claims.

## ASK A QUESTION ABOUT THIS MANUAL

Ask about setup, troubleshooting, compatibility, parts, safety, or missing instructions. Manuals+ will review the question and use this page's manual context to help answer it.

### Name

Anonymous

### Email

you@example.com

After a successful submission, we securely hash the supplied account or form email before sending it to Microsoft Advertising for conversion attribution. [Privacy details](#).

### Question

Example: How do I reset this device or fix this error?

### Details

Model number, symptoms, what you tried, or the section of the manual you are using.

Submit question

---

Open the live page

<https://manuals.plus/asin/B0CGDGSR1M>

More documents and user manuals: <https://manuals.plus/>