onerbl 32000 010-00

onerbl AC Adapter Instruction Manual

For Hyperice Hypersphere Models 32000 010-00, 32000001-00, 32000010-00

1. Introduction

This manual provides instructions for the safe and effective use of your onerbl AC Adapter. This adapter is designed as a compatible replacement power supply for Hyperice Hypersphere Vibrating Fitness Massage Ball models 32000 010-00, 32000001-00, and 32000010-00.

2. Important Safety Information

Please read and understand all safety instructions before using this product. Failure to follow these instructions may result in electric shock, fire, or other hazards.

- This adapter is intended for indoor use only. Do not expose to rain or moisture.
- Ensure the adapter's input voltage (AC 100-240V) matches your local power supply.
- Do not use the adapter if the cord or plug is damaged.
- Unplug the adapter from the power outlet when not in use or during electrical storms.
- Keep out of reach of children.
- Do not disassemble or modify the adapter. Refer all servicing to qualified personnel.




Image: The adapter features a smart chip providing multiple layers of protection, including safeguards against short-circuit, over-voltage, and over-current conditions to ensure electrical safety.

3. Product Overview

The onerbl AC Adapter is a high-quality replacement power supply designed for reliable performance.

Key Features:

- High Quality Replacement AC/DC Power Charger Adapter.
- Universal Input: AC 100-240V 50/60Hz Auto (Worldwide AC Input compatibility).
- Integrated Over Voltage Protection.
- Integrated Over Heat Protection.
- Units are tested to ensure great working condition.



Image: A clear view of the onerbl AC Adapter, showing its compact design and standard two-prong plug. The label indicates input voltage and regulatory compliance.

4. Setup

Follow these steps to properly connect your AC adapter to your Hyperice Hypersphere device:

1. Ensure your Hyperice Hypersphere device is powered off before connecting the adapter.
2. Connect the DC output plug of the onerbl AC Adapter securely into the power input port of your Hyperice Hypersphere device.
3. Plug the AC input prongs of the adapter into a standard wall electrical outlet.
4. Once connected, you may power on your Hyperice Hypersphere device according to its own operating instructions.



Image: The onerbl AC Adapter is shown connected to a power strip, illustrating a typical setup for powering a device in a home or office environment.

5. Operating

Once properly connected to a power source and your Hyperice Hypersphere device, the onerbl AC Adapter will provide the necessary power for your device to function. The adapter operates automatically, converting AC wall power to the DC power required by your device.

There are no user-adjustable settings on the adapter itself. Its operation is continuous as long as it is plugged into a live outlet and connected to the device.

6. Maintenance

Proper care and maintenance will extend the life of your AC adapter.

- **Cleaning:** Disconnect the adapter from the power source and the device before cleaning. Use a soft, dry cloth to wipe the exterior. Do not use liquid cleaners or solvents.
- **Storage:** Store the adapter in a cool, dry place away from direct sunlight and extreme temperatures when not

in use.

- **Inspection:** Periodically inspect the power cord and adapter casing for any signs of damage, such as cuts, fraying, or cracks. If damage is found, discontinue use immediately.
- **Handling:** Avoid bending the cable sharply or placing heavy objects on it, which can cause internal damage.



Image: An illustration highlighting the internal copper wire and PVC jacket, indicating a durable design for the adapter's cable, contributing to its longevity and safety.

7. Troubleshooting

If you encounter issues with your AC adapter, refer to the following table for common problems and solutions:

Problem	Possible Cause	Solution
Device not receiving power.	Adapter not plugged in, faulty outlet, loose connection, damaged adapter.	Ensure adapter is fully plugged into both the wall and the device. Try a different wall outlet. Check for visible damage to the adapter or cable.
Adapter feels excessively hot.	Overload, poor ventilation, internal fault.	Unplug immediately. Ensure adapter is in a well-ventilated area. If problem persists, discontinue use.
Intermittent power supply.	Loose connection, damaged cable.	Check all connections. Inspect the cable for damage.

8. Specifications

Detailed technical specifications for the onerbl AC Adapter:

Specification	Value
Brand	onerbl
Manufacturer	Shenzhen Waweis Technology Co., Ltd
Input Voltage	AC 100-240V, 50/60Hz
Wattage	36.5 watts
Connector Type	Proprietary
Compatible Devices	Hyperice Hypersphere Massage Ball (Models 32000 010-00, 32000001-00, 32000010-00)
Power Source	Corded Electric
Main Power Connector Type	2 Pin (US Standard)
Number of Items	1
Unit Count	1.0 Count




Image: A visual representation of the adapter's dimensions, indicating a length of 2.6 inches, width of 1.6 inches, height of 1.2 inches, and a cable length of 76 inches.

9. Warranty and Support

For warranty information, technical support, or any inquiries regarding your onerbl AC Adapter, please refer to the documentation provided with your purchase or contact the retailer from whom you purchased the product. You may also visit the manufacturer's official website for further assistance.

© 2023 onerbl. All rights reserved.

Ask a question about this manual

Ask about setup, troubleshooting, compatibility, parts, safety, or missing instructions. Manuals+ will review the question and use this page's manual context to help answer it.

Name

Anonymous

Email

you@example.com

After a successful submission, we securely hash the supplied account or form email before sending it to Microsoft Advertising for conversion attribution. Privacy details.

Question

Example: How do I reset this device or fix this error?

Details

Model number, symptoms, what you tried, or the section of the manual you are using.

Submit question