

[Manuals.plus](#) /

› [Kircuit](#) /

› Kircuit AC Adapter for KKMOON dvr1108 CCTV DVR HD Camera - Instruction Manual

Kircuit dvr1108

Kircuit AC Adapter for KKMOON dvr1108 CCTV DVR HD Camera - Instruction Manual

1. INTRODUCTION

This manual provides essential information for the safe and effective use of your Kircuit AC Adapter. This adapter is designed to convert standard AC electrical power into the DC power required by your compatible device, specifically the KKMOON dvr1108 CCTV DVR HD Camera. It allows you to operate your device or charge its battery from electrical power outlets.

The Kircuit AC Adapter features an input voltage range of 100V-240V AC, making it suitable for various power environments. It incorporates built-in dynamic IC, charger IC, and a power fuse for rapid charging and overcharge protection, ensuring reliable performance for your device.

2. SETUP

Follow these steps to properly set up your Kircuit AC Adapter:

1. **Inspect the Adapter:** Before use, visually inspect the AC adapter and its cord for any signs of damage, such as cuts, frayed wires, or bent pins. Do not use the adapter if any damage is observed.
2. **Connect to Device:** Locate the DC input port on your KKMOON dvr1108 CCTV DVR HD Camera. Carefully insert the DC output plug of the Kircuit AC Adapter into this port. Ensure a firm and secure connection.
3. **Connect to Power Outlet:** Plug the AC input prongs of the adapter into a standard electrical wall outlet (100V-240V AC). Ensure the outlet is easily accessible and not overloaded.



Figure 2.1: Kircuit AC Adapter connected to a power strip. Ensure the adapter is fully inserted into a functional power outlet.

3. OPERATING INSTRUCTIONS

The Kircuit AC Adapter is designed for simple plug-and-play operation. Once properly connected as described in the Setup section, your KKMOON dvr1108 CCTV DVR HD Camera should receive power or begin charging its battery.

- **Power Indicator:** Some devices or adapters may have an LED indicator to show that power is being supplied. Refer to your device's manual for specific indicator behavior.
- **Continuous Power:** The adapter provides continuous DC power to your device as long as it is connected to a live AC outlet and the device.
- **Disconnection:** To disconnect, first unplug the adapter from the wall outlet, then disconnect the DC plug from your device.

4. MAINTENANCE

Proper maintenance ensures the longevity and safe operation of your AC adapter:

- **Cleaning:** Keep the adapter clean and free from dust. Use a dry, soft cloth to wipe the exterior. Do not use liquid cleaners or immerse the adapter in water.
- **Storage:** When not in use, store the adapter in a cool, dry place, away from direct sunlight and extreme temperatures. Avoid tightly winding the cord, which can cause internal damage.
- **Cord Inspection:** Periodically inspect the power cord for any signs of wear, kinks, or damage. If the cord is damaged, discontinue use immediately and replace the adapter.
- **Environmental Conditions:** Avoid using the adapter in excessively humid or wet environments.

5. TROUBLESHOOTING

If you encounter issues with your Kircuit AC Adapter, refer to the following troubleshooting guide:

- **Device Not Powering On:**
 - Ensure the adapter is securely plugged into a functional wall outlet. Test the outlet with another device.
 - Verify that the DC plug is firmly connected to your KKMOON dvr1108 device's input port.
 - Check the adapter and cord for any visible damage. If damaged, do not use.
 - Confirm that the KKMOON dvr1108 device itself is functioning correctly by testing it with its original power supply if available, or by checking its power button/settings.
- **Adapter Feels Warm:**
 - It is normal for AC adapters to become warm during operation. However, if the adapter becomes excessively hot to the touch, disconnect it immediately and discontinue use. This may indicate an internal fault or an overloaded circuit.
- **Intermittent Power:**
 - Check all connections for looseness.
 - Ensure the power outlet is stable and not experiencing fluctuations.

6. SPECIFICATIONS

Detailed technical specifications for the Kircuit AC Adapter:

- **Input:** 100-240V AC, 50/60Hz, 0.3A
- **Output:** DC (Specific voltage and current are designed to match the KKMOON dvr1108 requirements. Please refer to your device's specifications for exact output needs.)
- **Cord Length:** Approximately 6.5 feet (2 meters)
- **Compatibility:** KKMOON dvr1108 CCTV DVR HD Camera
- **Manufacturer:** Shenzhen Waweis Technology Co., Ltd



Figure 6.1: Close-up view of the Kircuit AC Adapter label, indicating input specifications.



Figure 6.2: Kircuit AC Adapter displaying its cord length.

7. WARRANTY AND SUPPORT

For warranty information or technical support, please refer to the documentation provided with your purchase or contact the seller directly. Ensure you have your purchase details and product model number (KKMOON dvr1108 compatible Kircuit AC Adapter) available when seeking support.

ASK A QUESTION ABOUT THIS MANUAL

Ask about setup, troubleshooting, compatibility, parts, safety, or missing instructions. Manuals+ will review the question and use this page's manual context to help answer it.

Name

Anonymous

Email

you@example.com

After a successful submission, we securely hash the supplied account or form email before sending it to Microsoft Advertising for conversion attribution. [Privacy details](#).

Question

Example: How do I reset this device or fix this error?

Details

Model number, symptoms, what you tried, or the section of the manual you are using.

Submit question

Open the live page

<https://manuals.plus/asin/B0CGDJSM54>

More documents and user manuals: **<https://manuals.plus/>**