Saved from manuals.plus.
Open the live page for links to other documents and user manuals.

USA Toyz 6288

USA Toyz Zero-G Glow Race Track Instruction Manual

Model: 6288

Introduction

This manual provides detailed instructions for the assembly, operation, and maintenance of your USA Toyz Zero-G Glow Race Track. This set is designed to encourage creativity and STEM skills through flexible, glow-in-the-dark track pieces and a motorized LED race car capable of gravity-defying maneuvers.



Image: The complete USA Toyz Zero-G Glow Race Track set, including track pieces, a motorized car, and the product packaging.

Safety Information

- Recommended for ages 3 years and up.
- Adult supervision is recommended during assembly and play.
- Keep small parts away from children under 3 years to prevent choking hazards.
- Do not mix old and new batteries. Do not mix alkaline, standard (carbon-zinc), or rechargeable (nickel-cadmium) batteries.

What's in the Box

Your USA Toyz Zero-G Glow Race Track set includes the following components:

- 150pcs Glow in the Dark Track Set
- 108 Glowing Track Pieces
- 38 Glowing Suction Track Pieces
- 2 Graffiti Shells
- 1 Motorized LED Car

- 1 Connector



Image: A visual representation of the items included in the Zero-G Glow Race Track set, such as track pieces, car shells, and the motorized car.

Setup

1. Track Assembly

1. Connect the flexible track pieces by aligning the tabs and slots, then gently snapping them together. The tracks are designed to be bendable and flexible, allowing for various configurations including loops, twists, and turns.
2. Utilize the 38 glowing suction track pieces to attach sections of the track to smooth surfaces such as walls or windows, enabling gravity-defying layouts.



Image: Demonstrates how to easily snap track pieces together and shows various flexible track configurations.

2. Car Battery Installation

1. Locate the battery compartment on the underside of the motorized LED race car.
2. Using a small screwdriver, open the battery compartment.
3. Insert 3 AAA batteries (not included) into the compartment, ensuring correct polarity (+/-).
4. Close the battery compartment securely with the screwdriver.



Image: Illustrates the motorized LED race car, its battery placement, and the two included graffiti shells.

3. Changing Car Shells

The set includes two changeable graffiti car shells. To change a shell, gently detach the current shell from the car chassis and snap the desired shell into place.

Operating Instructions

1. Ensure batteries are correctly installed in the motorized LED car.
2. Locate the ON/OFF switch on the car and slide it to the 'ON' position. The car's LED lights will illuminate.
3. Place the car onto the assembled track. The car is designed to drive on or off the track.
4. Observe the car as it navigates the track, utilizing its magnetic properties to adhere to the track even when driving upside down or sideways on suction-cupped sections.
5. For enhanced visual effects, play in a dimly lit room to experience the glow-in-the-dark tracks and LED car lights.



Image: The race track illuminated in the dark, showcasing its glow-in-the-dark feature and the bright LED lights of the car.

Official Product Video

Your browser does not support the video tag.

Video: An official product video from USA Toyz demonstrating the Zero-G Glow Race Track in action, highlighting its flexible design, LED car, and glow-in-the-dark capabilities.

Maintenance

- **Cleaning:** Wipe track pieces and car with a dry or slightly damp cloth. Do not immerse electronic components in water.
- **Battery Replacement:** Replace batteries when the car's speed decreases or lights dim. Always use fresh AAA batteries.
- **Storage:** Store the track pieces and car in a cool, dry place away from direct sunlight to preserve the glow-in-the-dark properties and material integrity.

Troubleshooting

Problem	Possible Cause	Solution
Car does not move or moves slowly.	Low or incorrectly installed batteries.	Replace with fresh AAA batteries, ensuring correct polarity.
Car falls off the track frequently.	Track pieces not securely connected; insufficient battery power for inclines/loops; track not stable.	Ensure all track pieces are firmly snapped together. Replace car batteries. Use suction cups for stability on vertical surfaces.
Track does not glow in the dark.	Insufficient light exposure.	Expose track pieces to bright light for a period before playing in the dark.

Specifications

Feature	Detail
Product Dimensions	13.78 x 2.36 x 10.24 inches
Item Weight	2.18 pounds
Item Model Number	6288
Manufacturer Recommended Age	3 years and up
Manufacturer	USA Toyz

Warranty and Support

For warranty information or product support, please contact USA Toyz directly. You can find more information and contact details by visiting the official USA Toyz store: USA Toyz Store.

Ask a question about this manual

Ask about setup, troubleshooting, compatibility, parts, safety, or missing instructions. Manuals+ will review the question and use this page's manual context to help answer it.

Name

Anonymous

Email

you@example.com

After a successful submission, we securely hash the supplied account or form email before sending it to Microsoft Advertising for conversion attribution. Privacy details.

Question

Example: How do I reset this device or fix this error?

Details

Model number, symptoms, what you tried, or the section of the manual you are using.

Submit question

Open the live page

https://manuals.plus/asin/B0CGF3H3L2

More documents and user manuals: **https://manuals.plus/**