

[Manuals.plus](#) /

> [jjphonecase](#) /

> RW2530 Volleyball Ball PU Leather Flip Case Cover User Manual

jjphonecase RW2530

RW2530 Volleyball Ball PU Leather Flip Case Cover User Manual

Model: RW2530 | Compatible with Google Pixel 7

Brand: jjphonecase

PRODUCT OVERVIEW

The RW2530 Volleyball Ball PU Leather Flip Case Cover is designed specifically for the Google Pixel 7, offering both protection and style. This case features a unique graphic print resembling a volleyball, applied to both the front and back surfaces. Constructed from high-quality PU leather, it provides a slim-fit, scratch-resistant, and lightweight solution for safeguarding your device.

Key features include integrated card slots for essential IDs or credit cards, and robust phone protection against daily wear and tear. The design ensures full access to all ports, controls, and sensors of your Google Pixel 7.




Image 1: Front view of the RW2530 Volleyball Ball PU Leather Flip Case Cover. This image displays the closed case, highlighting the textured volleyball pattern and the overall slim profile.

SETUP AND INSTALLATION

1. **Prepare Your Device:** Ensure your Google Pixel 7 is clean and free of dust or debris before installing the case.
2. **Insert Phone:** Gently align your Google Pixel 7 with the hard plastic shell inside the flip case. Press the phone firmly into the shell until it is securely seated. Ensure all corners are properly engaged.
3. **Check Fit:** Verify that all buttons, ports, and the camera cutout are accessible and unobstructed. The case is designed for a precise fit.
4. **Utilize Card Slots:** Open the flip cover to access the integrated card slots. Carefully slide your ID, credit cards, or other small cards into the designated slots.



Image 2: Inside view of the RW2530 Flip Case. This image shows the interior of the case, including the clear plastic phone holder and the three integrated card slots on the left flap.

OPERATING INSTRUCTIONS

- **Flip Cover Usage:** The front flip cover protects your screen when closed. Open it to access your phone's display.
- **Access to Features:** The case provides precise cutouts for the camera, charging port, speakers, and microphone, allowing full functionality without removing the case.
- **Button Access:** The case is designed to allow easy access and operation of your phone's power and volume buttons.
- **Card Storage:** Use the internal card slots for convenient storage of up to three cards. Avoid overfilling the slots to prevent stretching or damage to the case.



Image 3: Back view of the RW2530 Flip Case. This image illustrates the rear of the case, specifically highlighting the precise cutout for the Google Pixel 7's camera module.

MAINTENANCE AND CARE

To ensure the longevity and appearance of your RW2530 flip case, follow these maintenance guidelines:

- **Cleaning:** Wipe the PU leather surface with a soft, damp cloth. For stubborn dirt, a mild soap solution can be used, but ensure to wipe off any residue immediately with a clean, damp cloth.
- **Drying:** Allow the case to air dry completely after cleaning. Do not use direct heat sources like hair dryers, as this can damage the PU leather.
- **Avoid Harsh Chemicals:** Do not use alcohol, abrasive cleaners, or solvents, as these can degrade the material and printed graphic.
- **Storage:** When not in use, store the case in a cool, dry place away from direct sunlight to prevent fading or material degradation.

TROUBLESHOOTING

- **Case Does Not Fit:**

Ensure you have the correct model of phone. This case is specifically designed for the *Google Pixel 7*. If you have a different model, the case may not fit correctly.

- **Difficulty Accessing Ports/Buttons:**

Verify that your phone is fully seated within the internal hard plastic shell. Sometimes, a slight misalignment can obstruct access. Gently press the phone into place to ensure a snug fit.

- **Cards Falling Out of Slots:**

The card slots are designed for standard-sized cards. Avoid placing too many cards in a single slot, as this can stretch the material. If the slots become loose over time, consider using fewer cards or placing a thin piece of paper behind the cards for a tighter fit.

SPECIFICATIONS

Product Model	RW2530
Compatible Phone Model	Google Pixel 7
Material	High Quality PU Leather, Hard Plastic (inner shell)
Features	Graphic Printed Design (Front & Back), 3 Card Slots, Slim-fit, Scratch Resistant, Lightweight, Robust Protection, Easy Access to Ports/Controls
Manufacturer	jjphonecase
UPC	768108105026



Image 4: Infographic detailing features of the flip case. This image visually summarizes key attributes such as UV cured print, magnetic closure, full color print, slim design, and cushioned impact protection.

WARRANTY AND SUPPORT

Specific warranty information for the RW2530 Volleyball Ball PU Leather Flip Case Cover is not provided in this manual. For details regarding warranty coverage, returns, or technical support, please contact the manufacturer, [jjphonecase](#), or the retailer from whom you purchased the product.

When contacting support, please have your product model (RW2530) and proof of purchase readily available.

© 2023 jjphonecase. All rights reserved.

This manual is for informational purposes only. Product specifications are subject to change without notice.