Manuals+

Q & A | Deep Search | Upload

manuals.plus /

- Hunter /
- > Hunter 52731 Builder Matte Black Ceiling Fan User Manual

Hunter 52731

Hunter 52731 Builder Matte Black Ceiling Fan User Manual

Model: 52731

1. Introduction

Thank you for choosing the Hunter 52731 Builder Matte Black Ceiling Fan. This manual provides detailed instructions for the safe installation, operation, and maintenance of your new ceiling fan. Please read all instructions carefully before beginning installation and keep this manual for future reference.



Figure 1.1: The Hunter 52731 Builder Matte Black Ceiling Fan, featuring five blades and an integrated LED light kit.

2. SAFETY INFORMATION

Always follow basic safety precautions when installing and operating electrical appliances to reduce the risk of fire, electric shock, and personal injury.

- Ensure the power is turned off at the circuit breaker before installation or servicing.
- All wiring must be in accordance with national and local electrical codes.

- The mounting structure must be capable of supporting the fan's weight (approximately 7.6 kg).
- Do not operate the fan with damaged wiring or if it is not functioning properly.
- Keep hands, clothing, and other objects clear of the fan blades when the fan is in operation.
- This fan is rated for indoor use only.

3. SETUP AND INSTALLATION

This section outlines the steps for assembling and installing your ceiling fan. Assembly is required.

3.1 Unpacking and Inspection

Carefully remove all components from the packaging. Verify that all parts are present and undamaged. Refer to the parts list in your included printed manual for a complete inventory.


3.2 Mounting the Fan

The fan supports standard profile mounting with a 3-inch downrod included. Ensure the electrical box is securely mounted to the building structure and can support the fan's weight.



LARGE ROOM

Fan Design May Vary



Standard:

3in downrod included

A: 18.10 B: 11.04

Angled: 36in downrod not included

A:51.10 B: 44.04

Fan Dimensions

Figure 3.1: Fan dimensions for standard (3in downrod) and angled mounting options. Standard dimensions: A: 18.10 inches, B: 11.04 inches.

3.3 Assembling the Blades and Light Kit

Attach the fan blades to the motor housing. The fan comes with three LED bulbs included for the light kit. Install the light kit and bulbs according to the instructions provided in the physical manual.



Figure 3.2: Detail of the fan blade attachment mechanism.



Figure 3.3: The integrated LED light kit with three light shades.

4. OPERATING INSTRUCTIONS

Your Hunter Builder ceiling fan is designed for ease of use and efficient air circulation.

4.1 Fan Speed Control

The fan is equipped with pull chains for controlling fan speed and light operation. Pull the fan chain to cycle through the available speeds (high, medium, low, off). The 6-speed WhisperWind DC motor ensures quiet operation.

4.2 Light Control

Pull the light chain to turn the integrated LED light kit on or off.

5. MAINTENANCE

Regular maintenance will ensure the longevity and optimal performance of your ceiling fan.

- Cleaning: Dust the fan blades and motor housing regularly with a soft, lint-free cloth. Do not use abrasive cleaners or solvents.
- **Tightening Screws:** Periodically check all screws on the fan blades and mounting hardware to ensure they are secure. Loose screws can cause noise and wobble.

• Light Bulbs: Replace LED bulbs as needed. Ensure the power is off before replacing bulbs.

6. TROUBLESHOOTING

If you experience issues with your fan, consult the following troubleshooting guide before contacting customer support.

Problem	Possible Cause	Solution
Fan does not start or operates intermittently	Loose wire connections; Incorrect wiring of control box; Power supply issue.	Check all electrical connections. Ensure the control box is correctly wired and seated. Verify power is supplied to the fan. If the fan requires a manual 'jump start' to begin rotation, check wiring to the motor control unit.
Fan is noisy	Loose fan blade screws; Loose mounting hardware; Unbalanced blades.	Tighten all blade screws and mounting hardware. Ensure blades are balanced; balancing kits are available if needed.
Light kit does not work	Loose wire connections; Faulty bulb; Power supply issue.	Check light kit wiring. Replace bulb. Verify power is supplied to the light kit.

7. SPECIFICATIONS

Detailed technical specifications for the Hunter 52731 Builder Matte Black Ceiling Fan.

Feature	Specification
Brand	Hunter
Model Number	52731
Item Weight	7.6 kg
Finish Type	Matte
Assembly Required	Yes
Number of Pieces	1
Batteries Required	No
Included Components	Cord
Colour	Matte Black
Electric Fan Design	Ceiling Fan
Power Source	Corded Electric

Feature	Specification	
Style	Modern	
Product Dimensions	46.8D x 130.6W x 46.8H Centimetres	
Room Type	Bedroom	
Special Feature	Remote Controlled, LED Light (Note: Remote control not explicitly mentioned in feature bullets, but listed in specs. Manual focuses on pull chain as per feature bullets.)	
Recommended Uses	Cooling, Air Circulation	
Mounting Type	Ceiling Mount	

8. WARRANTY AND SUPPORT

Hunter Fan Company stands behind the quality of its products.

8.1 Warranty Information

This product comes with a **Limited Lifetime Motor Warranty**, backed by Hunter Fan Company, a leader in the fan business for over 135 years. For specific terms and conditions of the warranty, please refer to the warranty card included with your purchase or visit the official Hunter Fan Company website.

8.2 Customer Support

If you have any questions, require technical assistance, or need to order replacement parts, please contact Hunter Fan Company customer support. Contact information can typically be found on the official Hunter Fan Company website or on the packaging of your product.

Online Resources: Visit the Hunter Fan Company official website for FAQs, additional troubleshooting tips, and product registration.

© 2024 Hunter Fan Company. All rights reserved.

Related Documents - 52731



Hunter Anisten Ceiling Fan Installation Manual

Comprehensive installation manual for the Hunter Anisten ceiling fan (Models 52835, 52836), including safety warnings, parts list, step-by-step installation instructions, wiring diagrams, troubleshooting tips, and warranty information.



Hunter Builder Deluxe Ceiling Fan Installation Manual

Comprehensive installation manual for the Hunter Builder Deluxe ceiling fan. Includes step-by-step instructions, wiring guides, troubleshooting tips, and warranty information for models 53089, 53090, 53091, and 52386.



Hunter Downtown Ceiling Fan Installation Manual

Comprehensive installation manual for the Hunter Downtown 72-inch ceiling fan, covering setup, wiring, and troubleshooting for models 51591 and 51592.



Hunter Acela Ceiling Fan Installation Manual

Comprehensive installation manual for the Hunter Acela ceiling fan, including safety warnings, tools needed, parts list, step-by-step assembly instructions, and troubleshooting tips.



<u>Hunter Radeon Ceiling Fan Installation Manual - Models 50952, 50980</u>

Comprehensive installation manual for the Hunter Radeon ceiling fan (models 50952 Matte White, 50980 Matte Black). Includes step-by-step instructions, safety warnings, troubleshooting, and warranty information.



<u>Hunter Darlington 50837 Ceiling Fan Installation Manual</u>

Comprehensive installation manual for the Hunter Darlington 50837 ceiling fan. Includes safety warnings, tools required, parts list, step-by-step installation guides, wiring instructions, troubleshooting, and warranty information.