

iJoy DS2013

iJoy Disney Lilo and Stitch Bluetooth Earbuds DS2013 User Manual

INTRODUCTION

This manual provides detailed instructions for the setup, operation, and maintenance of your iJoy Disney Lilo and Stitch Bluetooth Earbuds, model DS2013. Please read this manual thoroughly before using the product to ensure proper functionality and longevity.



Image: The iJoy Disney Lilo and Stitch Bluetooth Earbuds with their matching charging case.

WHAT'S IN THE BOX

Verify that all items are present in the package:

- iJoy Disney Lilo and Stitch Bluetooth Earbuds (Left and Right)
- Charging Case
- USB Charging Cable
- User Manual

SETUP

Charging the Earbuds and Case

Before first use, fully charge the earbuds and charging case. The charging case provides additional power for the earbuds, extending playtime up to 30 hours.

- Connect the charging case to a power source using the provided USB cable.

- Place the earbuds into the charging case. Ensure they are correctly seated.
- Indicator lights on the case will show charging status. Refer to the case for specific light patterns.



Image: The charging case indicating wireless charging compatibility.

Pairing with a Bluetooth Device

Follow these steps to pair your earbuds with your smartphone, tablet, or other Bluetooth-enabled device:

1. Open the charging case and remove both earbuds. The LED lights on both earbuds will flash red and blue, indicating they are in pairing mode.
2. On your device, navigate to the Bluetooth settings and ensure Bluetooth is enabled.
3. Allow your device to search for available Bluetooth devices. The left and right earbuds will automatically sync with each other.
4. From the list of available devices, select "Disney Earbuds" to connect. Once connected, the earbud indicator lights will stop flashing.

PAIR & SYNC

1. Open the charging case and take the earbuds out. Both LED Lights will flash red & blue.

2. Turn on Bluetooth on your device. Allow the Left & Right earbud to Sync.

3. Select Disney Earbuds from the list of available devices.

4. The earbuds will turn on.




Image: Visual guide for pairing the earbuds with a mobile device.

OPERATING

Touch Controls

The earbuds feature touch-sensitive controls for media playback and call management:

- **Single Press (Left or Right Earbud):** Play/Pause audio.
- **Double Press (Right Earbud):** Skip to the next track.
- **Double Press (Left Earbud):** Go to the previous track.
- **Hold (Right Earbud):** Increase volume.
- **Hold (Left Earbud):** Decrease volume.

WIRELESS CHARGING

C O M P A T I B L E



©Disney

Image: A visual representation of the touch control functions on each earbud.

Call Management

Utilize the built-in microphone for hands-free calls:

- **Single Press (Left or Right Earbud):** Answer an incoming call.
- **Single Press (Left or Right Earbud) during a call:** End the current call.
- **Hold (Left or Right Earbud) for 2 seconds:** Reject an incoming call.

MAINTENANCE

Water Resistance

The earbuds are rated IPX4 water resistant, meaning they are protected against splashing water from any direction. This makes them suitable for workouts and light rain exposure. They are not designed for submersion in water.




Image: An earbud being splashed with water, demonstrating its water-resistant capability.

Cleaning

To maintain optimal performance and hygiene:

- Gently wipe the earbuds and charging case with a soft, dry, lint-free cloth.
- Avoid using abrasive materials, solvents, or chemical cleaners.
- Ensure charging contacts are clean and dry before placing earbuds in the case.

TROUBLESHOOTING

If you encounter issues with your earbuds, try the following steps:

- **No Sound/Connectivity Issues:**
 - Ensure earbuds are charged.
 - Verify Bluetooth is enabled on your device.
 - Move earbuds closer to your device (within 33 feet).







- Forget "Disney Earbuds" from your device's Bluetooth list and re-pair.
- Restart your device.
- **Earbuds Not Syncing:**
 - Place both earbuds back into the charging case, close the lid, wait a few seconds, then remove them again to force re-sync.
- **Low Volume:**
 - Adjust volume using earbud touch controls and your connected device.
 - Ensure ear tips are properly sealed in your ear canal.

SPECIFICATIONS

Feature	Specification
Model Name	DS2013
Brand	iJoy
Connectivity Technology	Wireless (Bluetooth)
Bluetooth Version	5.0
Bluetooth Range	Up to 33 Feet (10 meters)
Battery Life (with case)	Up to 30 Hours
Water Resistance Level	IPX4 (Water Resistant)
Control Type	Touch Control
Built-in Microphone	Yes
Compatible Devices	Bluetooth Universally Compatible
Material	Plastic
Item Weight	1.13 ounces
Product Dimensions	2.5 x 1.5 x 1.5 inches
UPC	810116713912

WARRANTY AND SUPPORT

For warranty information or technical support, please refer to the contact details provided on the product packaging or visit the official iJoy website. Keep your proof of purchase for warranty claims.

	<p><u>Disney Wireless Foldable Headphones User Manual - Model 2AJQ7DS20265-BU</u></p> <p>Official user manual for Disney wireless foldable on-ear headphones. Features include operating instructions, product specifications, battery safety, disposal guidelines, and FCC compliance for model 2AJQ7DS20265-BU.</p>
	<p><u>IJOY SPORT Z True Wireless Earbuds User Manual</u></p> <p>Comprehensive user manual for the IJOY SPORT Z True Wireless Earbuds, detailing setup, device functions, specifications, safety guidelines, FCC compliance, and warranty information.</p>
	<p><u>iJOY BUDZ Premium True Wireless Earbuds User Manual</u></p> <p>User manual for iJOY BUDZ Premium True Wireless Earbuds, detailing product overview, specifications, pairing, device functions, charging, safety precautions, battery disposal, warranty, and FCC compliance.</p>
	<p><u>Human Touch iJOY Active 2.0 Massage Chair: Use & Care Manual</u></p> <p>Comprehensive use and care manual for the Human Touch iJOY Active 2.0 Massage Chair. Learn about wellness benefits, safety instructions, assembly, operation, maintenance, and specifications.</p>
	<p><u>iJoy Mini+ Massage Chair: Use, Care, and Maintenance Manual</u></p> <p>Comprehensive user manual for the iJoy Mini+ robotic massage chair, covering setup, operation, safety guidelines, maintenance, and warranty information for optimal relaxation and well-being.</p>
	<p><u>iJoy 170 Massage Chair: Use and Care Manual Interactive Health</u></p> <p>This manual provides detailed instructions for the Interactive Health iJoy 170 massage chair, covering setup, operation, safety guidelines, maintenance, and warranty information. Learn to maximize your relaxation and well-being with Human Touch Technology.</p>