



Manuals.plus /

› Bumpboxx /

› Bumpboxx Remixx Retro Bluetooth Boombox (Neon Blue) Instruction Manual

## Bumpboxx Remixx

# Bumpboxx Remixx Retro Bluetooth Boombox (Neon Blue) Instruction Manual

Model: Remixx | Brand: Bumpboxx

---

## INTRODUCTION

---

This manual provides detailed instructions for the safe and efficient operation of your Bumpboxx Remixx Retro Bluetooth Boombox. Please read this manual thoroughly before using the product and retain it for future reference.



Figure 1: Front view of the Bumpboxx Remiix Retro Bluetooth Boombox in Neon Blue, accompanied by its wireless microphone.

## SETUP

---

### 1. Powering On and Charging

The Bumpboxx Remiix is equipped with a rechargeable lithium battery providing up to 12 hours of playtime. To charge the device, connect the provided AC adapter to the DC 15V input port on the side panel and plug it into a power outlet. The 'CHARGE' indicator light will illuminate during charging and turn 'FULL' when complete.

## **2. Bluetooth Pairing**

1. Ensure the boombox is powered on.
2. Press the 'MODE' button on the side panel until 'Bluetooth' mode is selected.
3. On your mobile device (smartphone, tablet, etc.), enable Bluetooth and search for available devices.
4. Select 'Bumpboxx Remixx' from the list to pair. A confirmation sound will indicate successful pairing.

## **3. TWS (True Wireless Stereo) Pairing**

For enhanced stereo sound, two Bumpboxx Remixx units can be paired wirelessly:

1. Power on both Bumpboxx Remixx units.
2. Ensure both units are in Bluetooth mode.
3. On one unit (this will be the primary unit), press and hold the TWS pairing button (refer to the side panel controls for exact location, typically combined with a mode button or indicated by a TWS icon).
4. The units will automatically connect. A confirmation sound will indicate successful TWS pairing.

## **4. Auxiliary Input/Output**

The device features 3.5mm Aux In and Aux Out ports for wired connections to external audio sources or to daisy-chain multiple units.

## **5. USB and TF Card Playback**

Insert a USB drive or TF (Micro SD) card into the respective slots on the side panel to play MP3 audio files directly from the storage device.



Figure 2: Detailed view of the side panel, highlighting the USB port, TF card slot, power switches, and auxiliary input/output ports.

## OPERATING INSTRUCTIONS

### 1. Controls

- **Volume Knob:** Rotate to adjust the overall sound volume.
- **Bass Knob:** Adjusts the low-frequency audio output.
- **Treble Knob:** Adjusts the high-frequency audio output.
- **Playback Buttons:** 'PREV' (previous track), 'P/P' (play/pause), 'NEXT' (next track) for media control.
- **EQ Button:** Cycles through 5 preset equalizer settings to optimize sound for different music genres.
- **LED Switch:** Toggles the LED lights on/off.

### 2. Wireless Microphone

The included wireless microphone can be used for karaoke or announcements. Ensure the microphone is powered on and within range of the boombox. The microphone will automatically connect.

### 3. Remote Control

The Bumpboxx Remiix comes with a remote control for convenient operation of playback, volume, and other

settings from a distance.

Video 1: A short loop video showcasing the Bumpboxx Remix in various colors and environments, highlighting its design and portability.

## FEATURES

---

- **Portable Cassette Style:** Retro design with center LED light cassette tape motion.
- **High-Fidelity Sound:** Deep bass and piercing highs with dual rear bass radiators.
- **Wireless Microphone:** Included for interactive audio experiences.
- **Bluetooth Connectivity:** Seamless wireless audio streaming.
- **TWS Wireless Pairing:** Connect two units for true stereo sound.
- **Long-lasting Battery:** 12-hour rechargeable lithium battery.
- **Multiple Inputs:** 3.5mm Line In/Line Out, TFT & USB MP3 player.
- **Customizable Audio:** 5 EQ Settings, adjustable Bass and Treble.
- **Portability:** Lightweight at 12.5 lbs, includes a carrying shoulder strap.



- Portable Bluetooth Speaker
- Bluetooth Connectivity
- TWS Wireless Pairing of 2 Units
- Dual Rear Bass Radiators
- 3.5mm Line In/ Out / Aux In
- USB Charging Port
- Rechargeable Lithium Battery w/ 12hr Play Time
- TFT & USB MP3 Player
- 5 EQ Settings
- Wireless Microphone Included
- Weight 12.5lbs
- 175 Watts Max Power

Figure 3: Key features of the Bumpboxx Remix, including connectivity, power, and audio customization options.

## SPECIFICATIONS

---

Attribute	Detail
Model Name	Remixx
Brand	Bumpboxx
Color	Neon Blue
Product Dimensions	4.25"D x 16.5"W x 11.75"H
Item Weight	12.5 lbs (17.71 pounds as per specifications)
Material	Plastic, Aluminum, Polypropylene
Connectivity Technology	Bluetooth
Wireless Communication Technology	Bluetooth
Bluetooth Range	10 Meters
Speaker Type	Built-In
Speaker Maximum Output Power	175 Watts
Frequency Response	20 KHz
Signal-to-Noise Ratio	112 dB
Power Source	Battery Powered (1 Lithium Ion battery included)
Included Components	Battery, Wireless Microphone, Carrying Shoulder Strap, AC Adapter, Remote Control
Water Resistance Level	Not Water Resistant

## PHYSICAL SPECIFICATIONS

Length	17.5"
Width	6.25"
Height	11.5"
Weight	12.5 lbs



Figure 4: Physical dimensions and weight of the Bumpboxx Remixx.

## MAINTENANCE

### 1. Cleaning

Wipe the exterior of the boombox with a soft, dry cloth. Avoid using harsh chemicals or abrasive cleaners, as these may damage the finish. Do not expose the device to water or excessive moisture.

## 2. Battery Care

To prolong battery life, fully charge the device before first use. If storing the unit for an extended period, charge it to approximately 50% every few months. Avoid completely draining the battery frequently.

## TROUBLESHOOTING

---

- **No Power:** Ensure the device is charged or connected to a power source. Check the power switch on the side panel.
- **No Sound:** Verify the volume is turned up on both the boombox and the connected audio source. Check that the correct input mode (Bluetooth, Aux, USB/TF) is selected.
- **Bluetooth Disconnection:** Ensure the boombox and your device are within the 10-meter Bluetooth range. Disconnect and re-pair the devices.
- **Distorted Sound:** Reduce the volume on both the boombox and the audio source. Adjust the Bass and Treble settings. Ensure the audio file quality is sufficient.
- **Microphone Not Working:** Check if the wireless microphone is powered on and has fresh batteries. Ensure it is within range of the boombox.

Video 2: A product video demonstrating the Bumpboxx Remixx speaker, showcasing its features and sound capabilities.

## WARRANTY AND SUPPORT

---

The Bumpboxx Remixx Retro Bluetooth Boombox comes with a 1-year manufacturer's warranty. For warranty claims or technical support, please contact Bumpboxx customer service through their official website or the retailer where the product was purchased. Keep your proof of purchase for warranty validation.