

Manuals+

[Q & A](#) | [Deep Search](#) | [Upload](#)

[manuals.plus](#) /

› [SEIKO](#) /

› [SEIKO QHK061KLH Rectangular Non-Ticking Bedroom Alarm Clock User Manual](#)

SEIKO QHK061KLH

SEIKO QHK061KLH Rectangular Non-Ticking Bedroom Alarm Clock User Manual

Your guide to setting up, operating, and maintaining your SEIKO QHK061KLH alarm clock.

[Setup](#) [Operating](#) [Maintenance](#) [Troubleshooting](#) [Specifications](#) [Warranty](#) [Support](#)

1. SETUP

1.1 Unpacking

Carefully remove the SEIKO QHK061KLH alarm clock from its packaging. Inspect the clock for any signs of damage. Retain all packaging materials for future reference or if the product needs to be returned.

1.2 Battery Installation

The clock requires one (1) C battery (included). To install the battery:

1. Locate the battery compartment cover on the back of the clock.
2. Slide the cover open.
3. Insert one C battery, ensuring the positive (+) and negative (-) terminals align correctly with the indicators inside the compartment.
4. Close the battery compartment cover securely.



Image: Back view of the clock, highlighting the battery compartment and control knobs.

1.3 Initial Time Setting

To set the current time:

1. Locate the time setting knob on the back of the clock (typically labeled 'TIME SET' or similar, often the rightmost knob).
2. Rotate the knob clockwise or counter-clockwise until the hour and minute hands display the correct time.
3. The clock features a quiet sweep second hand that moves continuously, eliminating ticking sounds.



Image: Front view of the alarm clock, showing the analog display with large numerals and LumiBrite tipped hands.

2. OPERATING INSTRUCTIONS

2.1 Setting the Alarm

To set the alarm time:

1. Locate the alarm setting knob on the back of the clock (typically labeled 'ALARM SET' or similar, often the leftmost knob).
2. Rotate the alarm setting knob until the alarm hand points to your desired wake-up time.
3. To activate the alarm, slide the ON/OFF switch (located on the back, usually near the top) to the 'ON' position. To deactivate, slide it to 'OFF'.

2.2 Using the Snooze/Light Function

The clock is equipped with a combined snooze and light button located on the top of the unit.

- **Light:** Press the button once to illuminate the clock face for easy reading in the dark. The LumiBrite tipped hands also glow in the dark after exposure to light.
- **Snooze:** When the alarm sounds, press the top button to temporarily silence the alarm. The alarm will sound again after a short interval.



Image: Side view of the alarm clock, illustrating the prominent snooze/light button on the top.

2.3 Silent Sweep Second Hand

The SEIKO QHK061KLH features a quiet sweep second hand that moves continuously around the dial. This design eliminates the traditional ticking sound, making it ideal for bedrooms and other quiet environments where noise can be a disturbance.

3. MAINTENANCE

3.1 Cleaning

To clean your alarm clock, use a soft, dry cloth. Avoid using abrasive cleaners, solvents, or chemical sprays, as these can damage the clock's finish or internal components.

3.2 Battery Replacement

When the clock's timekeeping becomes inaccurate or the alarm weakens, it is time to replace the C battery. Follow the battery installation steps outlined in Section 1.2. Always dispose of used batteries responsibly according to local regulations.

4. TROUBLESHOOTING

- Clock not keeping accurate time:** Ensure the C battery is fresh and correctly installed. If the issue persists, replace the battery.
- Alarm not sounding:** Verify that the alarm time is set correctly and the ON/OFF switch on the back of the clock is in the 'ON' position. Check the battery level.
- LumiBrite hands not glowing in the dark:** The LumiBrite material requires exposure to light (natural or artificial) to charge. Ensure the clock is placed in an area where it receives sufficient light during the day. The glow duration varies depending on the intensity and duration of light exposure.
- No light when pressing the top button:** Check the battery. If the battery is low, the light function may be affected before the timekeeping or alarm.

5. SPECIFICATIONS

Brand	SEIKO
Model Number	QHK061KLH
Color	Black
Display Type	Analog
Dimensions (W x H x D)	4.29" x 3.39" x 2.52"
Power Source	1 C Battery (included)
Material	Plastic, Acrylic (Frame)
Special Features	Alarm, Illuminated (LumiBrite hands), Silent Clock (Quiet Sweep Second Hand)
Movement	Quartz Crystal Movement
Item Weight	8.5 ounces

6. WARRANTY INFORMATION

This SEIKO QHK061KLH alarm clock is backed by a **1-year manufacturer's limited warranty**. For specific details regarding warranty coverage, terms, and conditions, please refer to the documentation included with

your product or contact SEIKO customer support.

7. CUSTOMER SUPPORT

For further assistance, product inquiries, or to explore other SEIKO products, please visit the official SEIKO store:

Visit the SEIKO Store on
Amazon

© 2023 SEIKO. All rights reserved.

Related Documents - QHK061KLH

	<p>Seiko QHL095-W Clock Instruction Manual - Setup and Operation Guide Comprehensive guide for the Seiko QHL095-W clock, covering setup, time and alarm setting, operation, maintenance, and troubleshooting. Ensure optimal performance of your Seiko timepiece.</p>
	<p>Seiko Clock Limited One-Year Warranty Certificate This document outlines the terms and conditions for the Seiko Clock Limited One-Year Warranty, including coverage, limitations, and procedures for obtaining warranty service.</p>
	<p>Seiko Melody Clock Instruction Manual Instruction manual for the Seiko Melody Clock, detailing setup, time and volume adjustment, melody selection, demonstration mode, light sensor functionality, and battery life information.</p>
	<p>Seiko Digital Clock Instruction Manual Comprehensive instruction manual for the Seiko digital clock, covering time setting, alarm functions, temperature display, and daylight saving time (DST).</p>

	<p>Seiko HT012-1 Clock: Instructions and Features</p> <p>Official instructions for the Seiko HT012-1 clock, covering features, setting the time and alarm, snooze function, and battery replacement.</p>
	<p>Seiko Clock Instruction Manual - Model QHL079-K</p> <p>Detailed instructions for operating the Seiko clock model QHL079-K, including setting time, calendar, alarm, timer, stopwatch, and using the light function.</p>