

## Mabe RME360FZMRM0

# Mabe 360L (14 cu ft) Matte Inox Refrigerator RME360FZMRM0 User Manual

Model: RME360FZMRM0 | Brand: Mabe

## INTRODUCTION

The Mabe RME360FZMRM0 refrigerator is a modern and functional appliance with a storage capacity of 360 liters (equivalent to 14 cubic feet). Its matte inox finish gives it an elegant and contemporary appearance that can complement different kitchen styles.

## SAFETY INFORMATION

Before operating your Mabe refrigerator, please read all safety instructions carefully to prevent injury or damage. Keep this manual for future reference.

- Ensure the refrigerator is placed on a stable, level surface.
- Do not block ventilation openings in the appliance enclosure or in the built-in structure.
- Do not use mechanical devices or other means to accelerate the defrosting process, other than those recommended by the manufacturer.
- Do not damage the refrigerant circuit.
- Do not use electrical appliances inside the food storage compartments of the appliance, unless they are of the type recommended by the manufacturer.
- Unplug the appliance before cleaning or performing any maintenance.
- Keep flammable materials and vapors away from the refrigerator.

## SETUP

### Unpacking

Carefully remove all packaging materials, including tape and protective films. Dispose of packaging responsibly. Inspect the refrigerator for any shipping damage.

### Placement

Place the refrigerator on a firm, level floor. Allow at least 5 cm (2 inches) of space at the back and sides for proper air circulation. Avoid direct sunlight or heat sources. Ensure the electrical outlet is easily accessible.



**Image:** Rear view of the Mabe refrigerator showing its dimensions (77cm width, 67.69cm depth, 176.91cm height). This image illustrates the physical size of the unit, which is crucial for proper placement and ensuring adequate clearance for ventilation.

## Leveling

Use the adjustable leveling feet at the bottom of the refrigerator to ensure it is stable and level. This prevents vibrations and ensures proper door sealing.

## Power Connection

Plug the refrigerator into a dedicated 127 Volt grounded electrical outlet. Do not use extension cords or adapters.

## OPERATING INSTRUCTIONS

---

### Initial Startup

After plugging in, allow the refrigerator to run for at least 4 hours before placing food inside. This allows the internal temperature to stabilize.

### Temperature Control

The Mabe RME360FZMRM0 refrigerator features adjustable temperature controls for both the fresh food and freezer compartments. Refer to the control panel (typically located inside the fresh food compartment or on the door) to set desired temperatures. Recommended fresh food temperature is between 2°C and 4°C (35°F and 40°F), and freezer temperature is -18°C (0°F).



**Image:** Close-up view of the Mabe refrigerator's external control panel and water dispenser. This image highlights the user interface for temperature adjustments and the mechanism for dispensing water, indicating key operational features.

## Food Storage

Organize food efficiently to allow for proper air circulation. Use drawers for fruits and vegetables, and shelves for other items. Avoid overloading the refrigerator.



**Image:** Interior view of the Mabe refrigerator with various food items organized on shelves and in drawers. This image demonstrates the internal capacity and layout, showing how different types of food can be stored effectively within the appliance.

### Water Dispenser (if applicable)

If your model includes a water dispenser, ensure the water tank is filled with potable water. Press the lever to dispense water. Clean the dispenser regularly.

## MAINTENANCE

---

### Cleaning the Interior

Unplug the refrigerator before cleaning. Remove all food items and removable shelves/drawers. Wash with a mild detergent and warm water. Rinse and dry thoroughly. Do not use abrasive cleaners or harsh chemicals.

### Cleaning the Exterior

Wipe the exterior with a soft cloth dampened with mild soap and water. For the matte inox finish, use a specialized stainless steel cleaner if necessary, wiping in the direction of the grain. Avoid spraying water directly onto the control panel.

### Defrosting

This model features a manual defrost system. When frost buildup in the freezer compartment reaches approximately 0.5 cm (1/4 inch) thick, it's time to defrost. Unplug the refrigerator, remove all food, and allow the frost to melt naturally. Place towels to absorb water. Do not use sharp objects to remove ice.

### Condenser Coils

Periodically clean the condenser coils located at the back or bottom of the refrigerator. Dust and debris can accumulate, reducing efficiency. Use a vacuum cleaner with a brush attachment.

## TROUBLESHOOTING

Problem	Possible Cause	Solution
Refrigerator not cooling	Not plugged in; power outage; temperature control set too high; door left open; condenser coils dirty.	Check power cord; check circuit breaker; adjust temperature setting; ensure door is closed; clean condenser coils.
Unusual noises	Refrigerator not level; items vibrating inside; normal operating sounds (e.g., refrigerant flow).	Level the refrigerator; rearrange items; these sounds are normal.
Water on floor	Defrost water overflow (manual defrost); clogged drain tube.	Ensure proper defrosting procedure is followed; clear drain tube if accessible (consult service manual).
Door not closing properly	Gasket dirty or damaged; refrigerator not level; food blocking closure.	Clean or replace gasket; level the refrigerator; rearrange food items.

If the problem persists after attempting these solutions, please contact Mabe customer service.

## SPECIFICATIONS

**Brand:** Mabe

**Model Number:** RME360FZMRM0

**Color:** Matte Inox

**Capacity:** 360 Liters (14 cubic feet)

**Dimensions (W x D x H):** 77 cm x 67.7 cm x 176.9 cm (approx. 30.3 x 26.7 x 69.6 inches)

**Weight:** 63 kg (approx. 138.9 lbs)

**Voltage:** 127 Volts

**Material:** Stainless Steel

**Annual Energy Consumption:** 175 Kilowatt Hours Per Year

**Defrost System:** Manual

**Number of Doors:** 2

**Installation Type:** Freestanding

## WARRANTY AND SUPPORT

Mabe products are manufactured to high-quality standards. For warranty information, please refer to the warranty card included with your purchase or visit the official Mabe website. Keep your proof of purchase for warranty claims.

For technical assistance, spare parts, or service, please contact Mabe customer support. You can find contact details on the Mabe website or in your purchase documentation.

**Mabe Official Website:** [www.mabe.com.mx](http://www.mabe.com.mx)

