

[Manuals.plus](#) /

› [Signature Hardware](#) /

› Signature Hardware Drea Wall Mounted Widespread Bathroom Faucet (Model 953916) Instruction Manual

Signature Hardware 953916 Drea

Signature Hardware Drea Wall Mounted Widespread Bathroom Faucet

Model: 953916 | Brand: Signature Hardware

INTRODUCTION

This manual provides detailed instructions for the installation, operation, and maintenance of your Signature Hardware Drea Wall Mounted Widespread Bathroom Faucet. Please read all instructions carefully before beginning installation and retain this manual for future reference.

The Drea Wall-Mount Bathroom Faucet is designed for above-counter lavatories and wall-mount installations, featuring a widespread mounting type with 3 holes and 8-inch centers. It includes dual lever handles for controlling water flow and temperature, and a drain assembly.

SAFETY INFORMATION

- Always turn off the main water supply before installing or servicing the faucet.
- Wear appropriate personal protective equipment, such as safety glasses, during installation.
- If you are unsure about any part of the installation process, consult a qualified plumber.
- Ensure all local plumbing and building codes are met.
- Do not overtighten connections, as this may cause damage to the faucet or plumbing.

PACKAGE CONTENTS

Verify that all components are present before beginning installation:

- Faucet Spout Assembly
- Hot and Cold Handle Assemblies
- Valve Bodies (2)
- Mounting Hardware
- Pop-Up Drain Assembly

- Installation Instructions



Image: The Drea Wall Mounted Widespread Bathroom Faucet, showing the spout and two lever handles.

SETUP AND INSTALLATION

This faucet is designed for wall-mounted installation with 3 holes and 8-inch centers. Professional installation is recommended.

Required Tools (Not Included):

- Adjustable Wrench
- Phillips Head Screwdriver
- Plumber's Putty or Silicone Sealant
- Tape Measure
- Drill (if new holes are required)

Installation Steps:

- 1. Prepare the Wall:** Ensure the wall surface is clean, dry, and structurally sound. Mark the locations for the faucet spout and handle valve bodies according to the 8-inch center-to-center spacing.
- 2. Install Valve Bodies:** Insert the hot and cold valve bodies into the pre-drilled holes in the wall. Secure them from behind the wall using the provided mounting hardware. Ensure they are level and properly aligned.
- 3. Connect Water Supply Lines:** Connect the hot and cold water supply lines to the corresponding valve bodies. Use an adjustable wrench to tighten connections, ensuring no leaks.
- 4. Install Faucet Spout:** Insert the faucet spout into its designated hole. Secure it from behind the wall using the provided mounting hardware. Connect the spout's water inlet to the appropriate valve body outlet.
- 5. Install Handles:** Attach the lever handles to the valve stems. Secure them in place according to the manufacturer's instructions.
- 6. Install Drain Assembly:** Follow the separate instructions provided with the pop-up drain assembly for installation into your sink. Ensure a watertight seal using plumber's putty or silicone sealant.
- 7. Test for Leaks:** Slowly turn on the main water supply. Check all connections for leaks. Operate the faucet handles to ensure proper water flow and temperature control.

OPERATING INSTRUCTIONS

The Drea Wall Mounted Widespread Bathroom Faucet features dual lever handles for precise control:

- **Water Flow:** Rotate the handles to adjust the water flow from off to full on.
- **Temperature Control:** The left handle typically controls hot water, and the right handle controls cold water. Adjust both handles to achieve the desired water temperature.

MAINTENANCE

Proper care and maintenance will ensure the longevity and appearance of your faucet.

Cleaning:

- Clean the faucet regularly with a soft, damp cloth and mild soap.
- Avoid using abrasive cleaners, harsh chemicals, or scouring pads, as these can damage the finish.
- Wipe the faucet dry after each use to prevent water spots and mineral buildup.

Aerator Maintenance:

- If water flow decreases, the aerator may be clogged with debris or mineral deposits.
- Unscrew the aerator from the end of the spout.
- Rinse the aerator under running water and gently remove any debris. For stubborn deposits, soak in a vinegar solution.
- Reattach the aerator, ensuring it is securely tightened.

TROUBLESHOOTING

Refer to the following table for common issues and their solutions:

Problem	Possible Cause	Solution
---------	----------------	----------

Problem	Possible Cause	Solution
Low Water Flow	Clogged aerator; partially closed shut-off valve; kinked supply line.	Clean aerator; ensure shut-off valves are fully open; check supply lines for kinks.
Leaking from Spout	Worn cartridge; debris in cartridge.	Replace cartridge; clean cartridge.
Leaking at Base of Handle	Loose packing nut; worn O-rings.	Tighten packing nut; replace O-rings.
Water Temperature Issues	Improper adjustment of hot/cold supply; issues with water heater.	Verify hot and cold supply lines are connected correctly; consult water heater manual.

SPECIFICATIONS

Key specifications for the Signature Hardware Drea Wall Mounted Widespread Bathroom Faucet:

Feature	Detail
Model Name	Drea
Model Number	953916
Mounting Type	Wall Mount, Widespread (3-hole, 8" centers)
Number of Handles	2 (Lever)
Material Type	Metal
Finish Type	Matte Black (as per current product)
Spout Height	1-3/8"
Spout Reach	8-1/4" (wall to spout outlet)
Flow Rate	1.2 gallons-per-minute (GPM)
Item Weight	3.7 Pounds
Item Dimensions (D x W x H)	1"D x 1"W x 2.38"H (approximate, faucet body)
Included Components	Bathroom Faucets, Drain, Drea 1.2 GPM Wall Mounted Widespread Bathroom



Image: Detail of the faucet spout, showing the 1.2 GPM flow rate marking.

WARRANTY AND SUPPORT

Your Signature Hardware Drea Wall Mounted Widespread Bathroom Faucet is covered by a **25-year limited warranty** for residential use and a **5-year limited commercial warranty**. This warranty covers defects in material and workmanship under normal use.

For warranty claims, technical assistance, or replacement parts, please contact Signature Hardware customer support directly. Keep your proof of purchase for warranty validation.

ASK A QUESTION ABOUT THIS MANUAL

Ask about setup, troubleshooting, compatibility, parts, safety, or missing instructions. Manuals+ will review the question and use this page's manual context to help answer it.

Name

Anonymous

Email

you@example.com

After a successful submission, we securely hash the supplied account or form email before sending it to Microsoft Advertising for conversion attribution. [Privacy details](#).

Question

Example: How do I reset this device or fix this error?

Details

Model number, symptoms, what you tried, or the section of the manual you are using.

Submit question