



Manuals.plus /

› decalsweet /

› decalsweet Unicorn Extra Large Toy Box Chest User Manual (Model WX-A-0102)

decalsweet WX-A-0102

Unicorn Extra Large Toy Box Chest

Brand: decalsweet | Model: WX-A-0102

INTRODUCTION

This instruction manual provides important information for the proper assembly, usage, and maintenance of your decalsweet Unicorn Extra Large Toy Box Chest. Designed for children's rooms, this collapsible storage solution helps keep spaces tidy and organized. Please read this manual thoroughly before use and retain it for future reference.



Image: The Unicorn Extra Large Toy Box Chest, featuring a pink design with unicorns and a rainbow, filled with toys in a child's room.

PRODUCT FEATURES

- **Extra Large Capacity:** Measures 37.8"L x 12.6"W x 15.75"H, providing ample space for toys, books, clothes, and more.
- **Durable Construction:** Made from high-quality, easy-to-clean, and waterproof Oxford cloth with a 3mm PP plate for stability.
- **Flip Lid Design:** Features a Velcro flip lid to protect contents from dust and maintain a neat appearance.
- **Removable Dividers:** Includes two removable dividers, allowing for customization into one, two, or three storage compartments.
- **Convenient Portability:** Equipped with reinforced handles on both sides for easy movement between rooms.
- **Collapsible Design:** Folds flat for compact storage when not in use, saving space.
- **Mesh Pockets:** Two mesh pockets on the side offer additional storage for smaller items.

Product Details

Kids Toy Storage Box



Unique Pattern



Mesh Bag



Strong Velcro



Reinforced Handle



Removable Divider

Image: Detailed view of the toy box showcasing its unique unicorn pattern, mesh side pocket, strong Velcro closure, reinforced handle, and removable internal divider.

SETUP AND ASSEMBLY

The Unicorn Extra Large Toy Box Chest is designed for quick and easy assembly. Follow these steps to set up your storage box:

1. **Unpack the Product:** Carefully remove the folded toy storage box from its packaging.
2. **Expand the Box:** Gently unfold the main body of the toy box. Insert the large base board into the bottom to provide stability.
3. **Insert Dividers (Optional):** If desired, insert the two smaller divider boards into the designated slots to create up to three separate compartments. These dividers attach with Velcro.
4. **Secure the Lid:** Place the flip lid on top of the box. The lid sections attach to the box edges using Velcro for a secure closure.

Installation Steps

1. Take out the toy storage box



2. Expand the toy storage box and put the big board in the bottom



3. Insert the small board



4. Then cover the lid



Image: Visual guide demonstrating the four simple steps to assemble the toy storage box, from unpacking to securing the lid.

USAGE

This versatile toy box is suitable for organizing a wide range of items in various rooms:

- **Toy Storage:** Ideal for plush toys, building blocks, action figures, and other children's playthings.
- **Book Storage:** Keep children's books neatly organized and easily accessible.
- **Clothing & Blanket Storage:** Store seasonal clothing, extra blankets, or linens.
- **Multi-Room Use:** Perfect for bedrooms, playrooms, nurseries, or even living areas to help maintain a tidy environment.

Utilize the removable dividers to sort items by type, size, or frequency of use. The side mesh pockets are convenient for small accessories or frequently used items.

What can be stored?



Image: An illustration depicting the diverse range of items that can be stored in the toy box, such as balls, plush toys, toy bricks, clothes, books, and towels.

MAINTENANCE

To ensure the longevity and cleanliness of your toy box, follow these maintenance guidelines:

- **Cleaning:** The Oxford cloth material is waterproof and easy to clean. Wipe down the exterior and interior surfaces with a damp cloth and mild soap. Avoid harsh chemicals or abrasive cleaners.
- **Drying:** Allow the toy box to air dry completely before closing the lid or storing items to prevent mold or mildew.
- **Storage:** When not in use, the toy box can be collapsed and stored flat in a dry place away from direct sunlight.

SPECIFICATIONS

Feature	Detail
Brand	decalsweet
Model Number	WX-A-0102
Color	Unicorn (Pink with Unicorn Rainbow design)
Material	Polypropylene, Waterproof Oxford Cloth
Item Dimensions (L x W x H)	37.8" x 12.6" x 15.75"
Item Weight	1.94 Kilograms
Number of Compartments	2 (with removable dividers)
Closure Type	Flip Top (Velcro)
Special Features	Lightweight, Collapsible, Handles, Mesh Pockets

Extra Large Toy Storage Box

Suitable for various toys or household items



Image: A visual representation of the toy box with its length, width, and height dimensions clearly marked.

TROUBLESHOOTING

- **Box Not Standing Firmly:** Ensure the large base board is fully inserted and flat at the bottom of the box. Check that all sides are properly unfolded and aligned.
- **Lid Not Closing Properly:** Verify that the Velcro strips on the lid align with those on the box edges. Ensure no items are overfilling the box, preventing the lid from sitting flush.
- **Dividers Not Staying in Place:** Make sure the Velcro on the dividers is securely attached to the corresponding strips inside the box.

SAFETY INFORMATION

- This product is intended for storage purposes only. Do not allow children to climb into or stand on the toy box.
- Keep the toy box away from open flames or heat sources.
- Regularly inspect the product for any signs of wear or damage. Discontinue use if any structural integrity is compromised.
- Ensure small children are supervised when accessing the toy box to prevent accidental entrapment or injury.