Saved from manuals.plus.
Open the live page for links to other documents and user manuals.

Comfamoli RGB LED lamp

Comfamoli RGB LED Sunset Lamp Projector with App & Remote Control User Manual

Model: RGB LED lamp

Introduction Package Contents Setup Operation Specifications Troubleshooting Warranty & Support

1. Introduction

The Comfamoli RGB LED Sunset Lamp Projector is designed to enhance your living space with dynamic and customizable mood lighting. This device projects a vibrant, circular light pattern, simulating a sunset or other atmospheric effects. It features 21 color options, 4 dynamic modes, and can be controlled via a remote or a dedicated mobile application, offering versatile lighting solutions for various environments.

2. Package Contents

Please verify that all items listed below are included in your package:

- 1 x Comfamoli Sunset Lamp Projector
- 1 x Remote Control (requires 2 AAA batteries, not included)
- 1 x USB Cable
- 1 x Installation Instruction Manual

Note: *A USB charging head is required and not included in the package. The remote control requires 2 AAA batteries, which are not included.*

3. Setup Guide

1. **Unpack the Device:** Carefully remove the sunset lamp projector, remote control, and USB cable from the packaging.
2. **Insert Remote Batteries:** Open the battery compartment on the back of the remote control and insert 2 AAA batteries (not included), ensuring correct polarity.
3. **Connect Power:** Connect the provided USB cable to the lamp's power input. Plug the other end of the USB cable into a compatible USB charging head (not included) or a USB port on a laptop or desktop PC.

4. **Position the Lamp:** Place the lamp on a stable surface. The lamp head can be rotated 360 degrees to adjust the projection angle.
5. **Adjust Projection Size:** The size and shape of the projected light halo can be adjusted by changing the distance between the lamp and the projection surface (wall or ceiling). A greater distance results in a larger projection.
6. **Download the App (Optional):** Scan the QR code provided in the printed installation instruction manual to download the dedicated mobile application. The app is compatible with both iOS and Android devices.



Image: The Comfamoli Sunset Lamp Projector, illustrating its remote control and mobile application interface for color and mode selection.



Image: Diagram illustrating various USB power options for the lamp, such as a power adapter, power bank, laptop, and desktop PC.

4. Operation

4.1 Power On/Off

- **Using the USB Cable Button:** The USB cable has an inline button to turn the lamp on or off.
- **Using the Remote Control:** Press the power button () on the remote control to turn the lamp on or off.
- **Using the App:** Use the ON/OFF toggle within the mobile application.

Note: *When first powered on, the lamp may default to a flashing mode. This is normal. Press a color button on the remote to select your desired color.*

4.2 Color and Mode Selection

- **Remote Control:**
  - Select from 21 preset colors using the color buttons on the remote.
  - Choose from 4 dynamic modes (Flash, Strobe, Fade, Smooth) using the dedicated buttons.
  - Adjust brightness using the ▲ (up) and ▼ (down) buttons.

- **Mobile Application:**
  - Access unlimited RGB color options via the color wheel.
  - Select dynamic modes, music sync, microphone mode, and set timers.
  - Adjust brightness and saturation for precise control.




Image: The sunset lamp projecting an orange glow, with a visual representation of brightness adjustment.




Image: Screenshot of the mobile application, highlighting features like microphone control, color selection, timing, and scenario settings.



Image: Two examples of lamp usage: a timing function for sleep and a party mode for social gatherings.

Your browser does not support the video tag.

Video: Demonstration of the LED Sunset Lamp's bright colors and cozy ambiance, showcasing various lighting effects.

Your browser does not support the video tag.

Video: A demonstration of how to transform a space with soothing colors using the sunset lamp, controlled via remote.

5. Maintenance

- **Cleaning:** Use a soft, dry cloth to gently wipe the lamp body and lens. Avoid using abrasive cleaners or solvents, as these may damage the finish or optical components.
- **Storage:** When not in use for extended periods, store the lamp in a cool, dry place away from direct sunlight and extreme temperatures.
- **Battery Replacement:** Replace remote control batteries when the remote's responsiveness decreases. Ensure to use 2 new AAA batteries and dispose of old batteries responsibly.

6. Troubleshooting

Problem	Possible Cause	Solution
Lamp does not turn on.	No power supply or loose connection.	Ensure the USB cable is securely connected to both the lamp and a working USB power source. Verify the power source is active.
Remote control not working.	Dead batteries, remote not aimed correctly, or interference.	Replace remote batteries (2 AAA). Aim the remote directly at the front of the lamp body. Ensure no obstacles are blocking the signal.
App control not working.	App not connected or device compatibility issues.	Ensure Bluetooth is enabled on your mobile device and the app is properly paired with the lamp. Reinstall the app if necessary.
Projected light is dim or unclear.	Lamp lens is dirty or incorrect distance from surface.	Clean the lamp lens with a soft, dry cloth. Adjust the distance between the lamp and the projection surface for optimal clarity and brightness.
Colors appear different from expected.	Monitor/lighting effects or lamp setting.	Actual color may vary slightly due to monitor settings. Adjust colors via remote or app to desired shade.

7. Specifications

Feature	Detail
Brand	Comfamoli
Model Number	RGB LED lamp
Light Type	Color-changing LED
Control Method	Remote, Mobile App
Number of Colors	21+ (unlimited RGB via app)
Dynamic Modes	4 (Flash, Strobe, Fade, Smooth)
Wattage	10 Watts
Voltage	12 Volts (Accepted: 100-240V, 50-60Hz)
Material	Aluminum, Crystal
Product Dimensions	4.7 x 4.7 x 9.9 inches
Item Weight	10.5 ounces (0.3 Kilograms)
Power Source	Corded Electric (USB)
Indoor/Outdoor Usage	Indoor

8. Warranty & Support

Comfamoli stands behind its products. If you encounter any issues with your Sunset Lamp Projector before or after

purchase, please contact us via the Amazon message center. We are committed to responding within 24 hours to assist you.

Warranty Information: The product includes a standard warranty. For specific details regarding warranty coverage and duration, please refer to your purchase documentation or contact customer support.

© 2026 Comfamoli. All rights reserved.

Ask a question about this manual

Ask about setup, troubleshooting, compatibility, parts, safety, or missing instructions. Manuals+ will review the question and use this page's manual context to help answer it.

Name

Anonymous

Email

you@example.com

After a successful submission, we securely hash the supplied account or form email before sending it to Microsoft Advertising for conversion attribution. Privacy details.

Question

Example: How do I reset this device or fix this error?

Details

Model number, symptoms, what you tried, or the section of the manual you are using.

Submit question

Open the live page

https://manuals.plus/asin/B0CGHS8V65

More documents and user manuals: **https://manuals.plus/**