Saved from manuals.plus.
Open the live page for links to other documents and user manuals.

EUARY 600W/18Kpa

EUARY 600W/18Kpa Carpet Cleaner User Manual

Model: 600W/18Kpa

1. Introduction

This manual provides essential instructions for the safe and efficient operation, maintenance, and troubleshooting of your EUARY 600W/18Kpa Carpet Cleaner. Please read this manual thoroughly before first use and keep it for future reference.
Important: Upon receiving the product, water droplets may be present inside the carpet cleaning device. This is normal, as we test each unit before shipment to ensure proper functioning.

2. Safety Instructions

- Always ensure the power cord is unplugged before performing any maintenance or assembly.
- Do not immerse the main unit in water or other liquids.
- Keep the appliance away from children and pets.
- Use only cleaning solutions recommended for carpet and upholstery cleaners.
- Do not use the appliance to pick up flammable or combustible liquids, or anything that is burning or smoking.
- Ensure all tanks and attachments are securely in place before operation.
- Do not exceed the MAX fill line in the dirty water tank to prevent loss of suction.

3. Product Components

Familiarize yourself with the parts of your EUARY Carpet Cleaner:

- Main Unit with Power Button and Spray Button

- Fresh Water Tank (2 Liters capacity)
- Dirty Water Tank (1.4 Liters capacity)
- Flexible Hose (1.2 meters long)
- Cleaning Nozzle/Brush Head (with self-cleaning feature)
- Interchangeable Brush Heads (0.2mm for upholstery/hard floors, 0.3mm for carpets/car interiors)
- Power Cable (5 meters long)




Figure 3.1: Labeled diagram of the EUARY Carpet Cleaner components, including fresh water tank, dirty water tank, hose, and cleaning nozzle.

4. Setup

1. **Prepare the Fresh Water Tank:** Remove the fresh water tank from the main unit. Fill it with clean water and an appropriate carpet cleaning solution (if desired) up to the MAX fill line. Securely close the tank and place it back into the main unit.
2. **Attach the Hose and Nozzle:** Connect the flexible hose to the designated port on the main unit. Attach the desired cleaning nozzle/brush head to the end of the hose. Ensure all connections are firm.
3. **Select Brush Head:** Choose the appropriate brush head for your cleaning task. Use the 0.2mm brush for delicate upholstery and hard surfaces, and the 0.3mm brush for carpets and car interiors.
4. **Power Connection:** Plug the power cable into a suitable electrical outlet.



Figure 4.1: The dual tank system allows for separate storage of clean and dirty water, simplifying the cleaning process.



Figure 4.2: Select the appropriate brush head for optimal cleaning results on different surfaces.

5. Operating Instructions

The EUARY Carpet Cleaner employs a three-step cleaning process: spray, scrub, and vacuum.

1. **Power On:** Press the power button on the main unit to turn on the appliance.
2. **Spray:** Hold the cleaning nozzle over the stained area. Press the spray trigger on the nozzle to dispense cleaning solution onto the surface. Allow the solution to penetrate the stain for a few moments.
3. **Scrub:** Gently scrub the stained area with the brush head. The 115mm wide brush head is designed for efficient cleaning.
4. **Vacuum:** Release the spray trigger and slowly move the nozzle over the treated area to vacuum up the dirty solution. Repeat spraying, scrubbing, and vacuuming as needed until the stain is removed and the water extracted is clear.
5. **Long Reach:** The 1.2m hose and 5m power cable allow you to clean distant areas without moving the main unit.



Figure 5.1: The triple-action cleaning method effectively removes embedded dirt and stains.



Figure 5.2: The cleaner effectively removes dirt from carpets and rugs.



Figure 5.3: Ideal for cleaning upholstery and pet-related messes.



Figure 5.4: The long hose and power cable provide extended reach for cleaning.

Your browser does not support the video tag.

Video 5.1: Demonstration of the EUARY Carpet Cleaner's cleaning function on a rug, showing the spray, scrub, and vacuum process.

6. Maintenance

Regular maintenance ensures optimal performance and longevity of your cleaner.

1. **Empty and Clean Dirty Water Tank:** After each use, remove the dirty water tank, empty its contents, and rinse it thoroughly with clean water.
2. **Clean Brush Head and Hose:** The device features a self-cleaning brush head. After cleaning, detach the brush head cover and removable tubes to easily remove hair and debris. Rinse all parts under running water.
3. **Store Properly:** Once all components are clean and dry, store the hose and cable on the cleaner's integrated

holder. Store the appliance in a cool, dry place.



Figure 6.1: The self-cleaning design helps maintain hygiene and performance.

Your browser does not support the video tag.

Video 6.1: Demonstration of periodic cleaning for the EUARY Carpet Cleaner, including rinsing the brush head and emptying/cleaning the dirty water tank.

7. Troubleshooting

Problem	Possible Cause	Solution
No power	Appliance not plugged in; power outlet faulty.	Ensure the power cord is securely plugged into a working outlet. Check the circuit breaker.
No spray	Fresh water tank empty; spray nozzle clogged.	Refill the fresh water tank. Clean the spray nozzle.
Low or no suction	Dirty water tank full or overfilled; hose/nozzle clogged; tank not properly seated.	Empty the dirty water tank (do not exceed MAX line). Clear any blockages in the hose or nozzle. Ensure tanks are correctly installed.
Water leakage	Tanks not properly sealed; hose connections loose.	Ensure both fresh and dirty water tanks are securely closed and seated. Check all hose connections for tightness.

Problem	Possible Cause	Solution
Poor cleaning results	Incorrect cleaning solution; brush head worn; insufficient passes.	Use appropriate cleaning solution. Replace brush head if worn. Make more passes over the stained area.

8. Specifications

Feature	Specification
Brand	EUARY
Model Name	600W/18Kpa
Power Source	Corded Electric
Motor Power	600 W
Suction Power	18 Kpa
Fresh Water Tank Capacity	2 Liters
Dirty Water Tank Capacity	1.4 Liters
Item Weight	5.03 Kilograms
Hose Length	1.2 meters
Power Cable Length	5 meters
Color	White
UPC	784365965302

9. Warranty

The EUARY Carpet Cleaner comes with a standard manufacturer's warranty. Please refer to your purchase documentation or contact customer support for specific warranty terms and conditions.

10. Support

For further assistance, product inquiries, or technical support, please contact EUARY customer service through the retailer's platform or visit the official EUARY website.

© 2023 EUARY. All rights reserved.

Ask a question about this manual

Ask about setup, troubleshooting, compatibility, parts, safety, or missing instructions. Manuals+ will review the question and use this page's manual context to help answer it.

Name

Anonymous

Email

you@example.com

After a successful submission, we securely hash the supplied account or form email before sending it to Microsoft Advertising for conversion attribution. Privacy details.

Question

Example: How do I reset this device or fix this error?

Details

Model number, symptoms, what you tried, or the section of the manual you are using.

Submit question

Open the live page

https://manuals.plus/asin/B0CGJ24R7H

More documents and user manuals: **https://manuals.plus/**