

[Manuals.plus](#) /

› [Lamshaw](#) /

› Lamshaw Smartwatch Band for Mgaolo H79 1.54 Inches Smartwatch - Instruction Manual

Lamshaw H79 1.54 Inches Smartwatch Band

Lamshaw Smartwatch Band for Mgaolo H79 1.54 Inches Smartwatch - Instruction Manual

1. INTRODUCTION

This manual provides essential instructions for the proper installation, usage, and maintenance of your Lamshaw Classic Soft Silicone Smartwatch Band. This band is specifically designed for compatibility with the Mgaolo H79 1.54 Inches Smartwatch. Please read this manual thoroughly before attempting installation or use.

Important Compatibility Note:

- This band is exclusively compatible with the Mgaolo H79 1.54 Inches Smartwatch.
- It is not compatible with other smartwatch models.
- The smartwatch itself is not included with this product.

2. SAFETY INFORMATION

- Keep the band out of reach of small children to prevent choking hazards from small parts.
- Avoid exposing the band to extreme temperatures or direct sunlight for prolonged periods, as this may affect material integrity.
- If skin irritation occurs, discontinue use and consult a medical professional.

3. PACKAGE CONTENTS

Please verify that all items are present in your package:

- 1 x Lamshaw Classic Soft Silicone Smartwatch Band (consisting of two strap pieces)

4. SETUP AND INSTALLATION

Follow these steps to attach the Lamshaw smartwatch band to your Mgaolo H79 1.54 Inches Smartwatch:

1. **Prepare Your Smartwatch:** Ensure your Mgaolo H79 smartwatch is powered off. Place it on a soft, clean surface to prevent scratches.
2. **Identify Band Sections:** The Lamshaw band consists of two separate pieces: one with the buckle and one with the adjustment holes.
3. **Locate Quick Release Pins:** Each band piece has a small metal pin with a spring-loaded lever on one end. These are the quick-release pins.

4. **Attach First Band Piece:**

- Hold one band piece with the quick-release pin facing the smartwatch lug.
- Insert one end of the pin into the corresponding hole on the smartwatch lug.
- Pull the spring-loaded lever on the pin inwards, then align the other end of the pin with the opposite hole on the smartwatch lug.
- Release the lever, ensuring both ends of the pin are securely seated within the smartwatch lug holes. Gently tug on the band to confirm it is locked in place.

5. **Attach Second Band Piece:** Repeat the process from step 4 for the second band piece on the other side of your smartwatch.




Image: Components of the Lamshaw Smartwatch Band, illustrating the quick-release pin mechanism.



Image: Detailed view of the band's attachment point with the quick-release pin.

5. OPERATING AND USAGE

Once installed, wearing and adjusting your Lamshaw smartwatch band is straightforward:

1. **Wearing the Smartwatch:** Place the smartwatch on your wrist.
2. **Adjusting the Fit:** Thread the end of the band through the buckle and select an adjustment hole that provides a comfortable yet secure fit. The band should not be too tight to restrict circulation, nor too loose to allow the smartwatch to move freely on your wrist.
3. **Securing the Band:** Fasten the tang buckle through the chosen hole. Use the keeper loop to secure any excess strap length.



Image: The Lamshaw Smartwatch Band worn on a wrist.



Image: Wrist circumference guide for the Lamshaw Smartwatch Band, showing a range of 5.5 to 8.7 inches.

6. MAINTENANCE

To ensure the longevity and appearance of your silicone smartwatch band, follow these maintenance guidelines:

- **Cleaning:** Wipe the band regularly with a soft, damp cloth. For deeper cleaning, use mild soap and water, then rinse thoroughly and dry completely before reattaching to your smartwatch.
- **Avoid Harsh Chemicals:** Do not use abrasive cleaners, solvents, or strong detergents, as these can damage the silicone material.
- **Storage:** When not in use, store the band in a cool, dry place away from direct sunlight.

7. TROUBLESHOOTING

If you encounter any issues with your smartwatch band, refer to the following common problems and solutions:

- **Band does not attach securely:**

- Ensure the quick-release pins are fully engaged in the smartwatch lugs.
- Verify that you are using the correct band for your Mgaolo H79 1.54 Inches Smartwatch.

- **Skin irritation:**

- Clean the band thoroughly to remove any residue.
- Ensure the band is not worn too tightly.
- If irritation persists, discontinue use.

- **Band appears discolored or damaged:**

- Review maintenance instructions to ensure proper care.
- Contact customer support if the damage is unexpected or due to a manufacturing defect.

8. SPECIFICATIONS

Product Type	Smartwatch Band
Brand	Lamshaw
Material	Silicone
Compatibility	Mgaolo H79 1.54 Inches Smartwatch
Clasp Type	Tang Buckle
Product Dimensions	0.39 x 1.97 x 3.94 inches (approximate)

9. WARRANTY AND SUPPORT

For any questions, concerns, or support needs regarding your Lamshaw smartwatch band, please contact the seller or manufacturer directly through your purchase platform. Specific warranty details may vary and are typically provided at the point of purchase or by the seller.

ASK A QUESTION ABOUT THIS MANUAL

Ask about setup, troubleshooting, compatibility, parts, safety, or missing instructions. Manuals+ will review the question and use this page's manual context to help answer it.

Name

Anonymous

Email

you@example.com

After a successful submission, we securely hash the supplied account or form email before sending it to Microsoft Advertising for conversion attribution. [Privacy details](#).

Question

Example: How do I reset this device or fix this error?

Details

Model number, symptoms, what you tried, or the section of the manual you are using.

Submit question

Open the live page

<https://manuals.plus/asin/B0CGJ27N5P>

More documents and user manuals: <https://manuals.plus/>