

Bulbrite 776654

Bulbrite LED Light Bulb User Manual

MODEL: 776654 - LED7A19/30K/FIL/M/D/B

1. Introduction

This manual provides essential information for the safe and efficient use of your Bulbrite LED A19 Light Bulb. This 7-watt LED bulb is designed to replace traditional incandescent bulbs, offering energy efficiency and a long lifespan. It features a standard A19 pear shape, a medium screw (E26) base, and emits a natural white light at 3,000 Kelvin. The bulb is also dimmable, allowing for adjustable light levels.



This image displays the Bulbrite A19 LED light bulb, featuring a classic pear shape and a standard medium screw (E26) base. The bulb has a frosted or diffused finish, indicating even light distribution.

2. Important Safety Instructions

- **Risk of Electric Shock:** Always turn off power to the fixture and allow the bulb to cool before replacing.
- **Risk of Burns:** Do not touch the bulb when it is operating or immediately after turning it off.
- **Indoor Use Only:** This bulb is designed for indoor applications unless specifically rated for outdoor use.
- **Dimmable Feature:** Use only with compatible LED dimmers. Incompatible dimmers may cause flickering or damage to the bulb.
- **Proper Disposal:** Dispose of bulbs according to local regulations.

3. Setup

Installation Guide

1. Ensure the power to the light fixture is turned off at the circuit breaker or wall switch.

- Carefully remove the old bulb from the fixture by twisting it counter-clockwise.
- Screw the Bulbrite LED A19 bulb into the fixture's E26 medium screw base by twisting it clockwise until snug. Do not overtighten.
- Restore power to the fixture.

4. Operating

Usage

Once installed, operate the Bulbrite LED A19 bulb using your standard wall switch. If connected to a compatible dimmer switch, you can adjust the light output from full brightness to a lower dimmed level. Ensure your dimmer is specifically designed for LED lighting to prevent performance issues.

5. Maintenance

Care and Cleaning

The Bulbrite LED A19 bulb requires minimal maintenance. To clean, ensure the power is off and the bulb is cool. Gently wipe the bulb with a soft, dry cloth. Do not use liquid cleaners or abrasive materials, as these can damage the bulb's finish or internal components. Replace the bulb when it reaches the end of its operational life.

6. Troubleshooting

Common Issues and Solutions

Problem	Possible Cause	Solution
Bulb does not light up.	No power to fixture, loose connection, or bulb failure.	Check power switch and circuit breaker. Ensure bulb is screwed in tightly. Test bulb in another working fixture.
Bulb flickers or hums.	Incompatible dimmer switch or loose connection.	Ensure dimmer is LED compatible. Tighten bulb. If problem persists, try a non-dimmable fixture.
Light output is too low or too high.	Dimmer setting or incorrect bulb for fixture.	Adjust dimmer setting. Verify the bulb's wattage and lumen output are suitable for your needs.

7. Specifications

Technical Data

Attribute	Value
Manufacturer	Bulbrite

Attribute	Value
Part Number	776654
Model Number	776654
Type of Bulb	LED
Shape	Arbitrary (A19 Pear)
Base Type	Medium Screw (E26)
Wattage	7 watts
Voltage	120 volt
Luminous Flux	800 Lumen
Color Temperature	3,000K (Natural White)
Color Rendering Index (CRI)	80
Average Lifetime	15,000 hours
Special Features	Dimmable
Material	Copper
Item Package Quantity	1
ASIN	B0CGJ5LSJ1
Date First Available	August 24, 2023

8. Warranty and Support

Warranty Information

Bulbrite products are manufactured to high-quality standards. For specific warranty details regarding your LED A19 light bulb, please refer to the packaging or the official Bulbrite website. Keep your purchase receipt as proof of purchase for any warranty claims.

Customer Support

If you have any questions, require technical assistance, or encounter issues not covered in this manual, please contact Bulbrite customer support. Visit the official Bulbrite website for contact information and additional resources.

