

## COSTWAY 04723681

# COSTWAY 48-inch Mobile Computer Desk Instruction Manual

Model: 04723681

## INTRODUCTION

Thank you for choosing the COSTWAY 48-inch Mobile Computer Desk. This manual provides essential information for the proper assembly, operation, and maintenance of your new desk. Please read all instructions carefully before use to ensure safe and efficient functionality.

This versatile desk features a spacious 48-inch tabletop, ideal for various activities such as working, studying, or gaming. Its design incorporates four universal wheels, two of which are lockable, allowing for effortless mobility and stable positioning. Constructed with carbon structural steel tubes and durable engineered board, this desk is built for longevity and stability.

## ASSEMBLY INSTRUCTIONS

Before beginning assembly, ensure all parts are present and undamaged. It is recommended to assemble the desk on a soft, clean surface to prevent scratches. A Phillips head screwdriver and an Allen wrench (6mm) will be required. The workbench is designed for straightforward assembly, typically taking about 30 minutes.

### Unpacking and Preparation

Carefully remove all components from the packaging. Lay out the wood tabletop upside down on a protective surface. Identify all metal frame pieces, hardware, and tools. The packaging includes markings on the cardboard to aid in initial positioning of the frame components.

### Attaching the Frame

Attach the side frame pieces to the wood tabletop using the provided screws. Insert two screws into each of the four corners. Do not fully tighten these screws yet; leave them slightly loose to allow for minor adjustments. This flexibility will help align the components correctly.

Next, secure the angle brackets to the frame. These brackets fit into designated holes and are fastened with screws. Ensure the larger hole on the bracket aligns with the screw hole on the frame. Again, do not fully tighten these screws at this stage.

### Securing the Tabletop

Once all frame pieces and brackets are loosely attached, carefully adjust the frame to ensure the wood tabletop is centered and aligned. Use the provided positioning stickers on the tabletop as a guide. Once aligned, proceed to tighten all screws securely. Use a power drill with a clutch setting to avoid overtightening and damaging the screws or wood.

### Adjusting Leg Height and Attaching Casters

The desk legs are adjustable. To raise the height, loosen the nuts on the adjustable legs using a 13mm socket or crescent wrench. Extend the inner square tube to your desired height, ensuring the plastic sleeve is properly seated for smooth and rattle-free operation. Re-tighten the nuts to secure the legs at the chosen height.

If your model includes swivel casters, attach them to the bottom of the legs. For easier installation, lock the casters before

screwing them in. This prevents unwanted rotation during the process. Once installed, unlock the casters for mobility or keep them locked for stability.

**Video:** Mobile Small Computer Desk, Folding Laptop Table with Wheels. This video demonstrates the mobility and folding capabilities of a similar desk, which can aid in understanding the caster functionality and space-saving design.

**Video:** How to set up. This short video illustrates the basic setup process, including unfolding the tabletop and securing it for use.

## OPERATING INSTRUCTIONS

### Mobility and Stability

The desk is equipped with four 360° rotatable universal wheels for easy movement. Two of these wheels feature locking mechanisms. To move the desk, ensure both lockable wheels are in the unlocked position. To secure the desk in place, push down the levers on the two lockable wheels until they click into the locked position.



**Image:** Universal Wheels. This image shows a close-up of one of the desk's universal wheels, highlighting its 360° rotation capability and the integrated locking mechanism for stability.

### Storage Options

The desk may include detachable and reversible storage options, such as a foldable fabric bag for notebooks, pens, and phones, and two hanging hooks for earphones, bags, or keys. These can be positioned as needed for convenience.

## Detachable & Reversible Storage Options

### Foldable Fabric Bag



Notebooks



Pens



Phones



### 2 Hanging Hooks



Earphones



Bags



Keys

**Image:** Detachable & Reversible Storage Options. This image illustrates the optional storage features, including a foldable fabric bag for small items and two hanging hooks for accessories, enhancing the desk's utility.

## MAINTENANCE

The desk's tabletop is made of thickened engineered board with premium edge sealing, making it anti-scratch and non-cracking. The smooth surface is easy to clean. Simply wipe off any stains with a damp cloth. Avoid using harsh chemicals or abrasive cleaners that could damage the finish. Regularly check and tighten all screws to maintain structural integrity.

## SAFETY GUIDELINES

- Ensure stability before loading any items onto the desk.
- Do not exceed the maximum load capacity of 210 lbs (95 kg).
- Keep the desk away from high-traffic areas to prevent accidental collisions.
- Regularly inspect all fasteners and connections to ensure they are secure.
- Avoid placing hot items directly on the tabletop without protective padding.

## PRODUCT SPECIFICATIONS

Brand	COSTWAY
-------	---------

<b>Model Number</b>	04723681
<b>Product Dimensions</b>	24"D x 48"W x 30"H (61 cm D x 122 cm W x 76 cm H)
<b>Desktop Thickness</b>	0.7" (1.8 cm)
<b>Material</b>	Carbon Steel, Engineered Wood
<b>Max Load Capacity</b>	210 lbs (95 kg)
<b>Net Weight</b>	37 lbs (16.8 kg)
<b>Special Feature</b>	Mobile with 4 Lockable Wheels

## Dimensions



**Image:** Dimensions and Capacity. This diagram provides a clear visual representation of the desk's overall dimensions and its maximum weight capacity, aiding in space planning and safe usage.

## WARRANTY AND SUPPORT

For specific warranty information or customer support, please refer to the documentation included with your purchase or contact COSTWAY customer service directly. Keep your purchase receipt for warranty claims.