

Emerson EAS-3000

Emerson EAS-3000 Portable Bluetooth Speaker User Manual

1. INTRODUCTION

This manual provides essential instructions for the safe and efficient operation of your Emerson EAS-3000 Portable Bluetooth Speaker. Please read this manual thoroughly before using the device and retain it for future reference.



Image 1.1: The Emerson EAS-3000 Portable Bluetooth Speaker, showcasing its compact design and integrated carrying strap.

2. PACKAGE CONTENTS

Ensure all items are present upon unpacking:

- Emerson EAS-3000 Portable Bluetooth Speaker
- USB Charge Cable
- Carrying Strap
- User Manual (this document)

3. PRODUCT OVERVIEW

3.1 Speaker Components



Image 3.1: Front view of the Emerson EAS-3000 speaker, showing the speaker grille and Emerson logo.

FM Radio

Tune into your favorite local stations



Image 3.2: Rear view of the Emerson EAS-3000 speaker, highlighting the control panel and input ports.

3.2 Controls and Ports

The speaker features an intuitive control panel and various ports for connectivity:

- **Power Button:** Press and hold to turn the speaker on or off.
- **Mode Button:** Cycle through input modes (Bluetooth, AUX, USB).
- **Play/Pause Button:** Play or pause audio playback.
- **Volume Up/Next Track Button:** Short press for volume up, long press for next track.
- **Volume Down/Previous Track Button:** Short press for volume down, long press for previous track.
- **USB Port:** For charging the speaker and playing audio from a USB drive.
- **AUX Input (3.5mm):** For wired audio connection.

Your browser does not support the video tag.

Video 3.1: A 360-degree video showcasing the physical design and features of the Emerson EAS-3000 Portable Bluetooth Speaker.

4. SETUP

4.1 Charging the Speaker

1. Connect the included USB charge cable to the speaker's USB port.
2. Connect the other end of the USB cable to a compatible USB power adapter (not included) or a computer's USB port.
3. The charging indicator light will illuminate. Once fully charged, the indicator light may change or turn off, depending on the model.

A full charge provides approximately 3 hours of playtime.

4.2 Attaching the Carrying Strap

Locate the two attachment points on the speaker, typically on opposite sides. Securely fasten each end of the carrying strap to these points. Ensure the strap is firmly attached before carrying the speaker.



Image 4.1: Side view of the Emerson EAS-3000 speaker with the carrying strap attached, demonstrating portability.

5. OPERATING INSTRUCTIONS

5.1 Power On/Off

Press and hold the Power button located on the control panel to turn the speaker on or off.

5.2 Bluetooth Pairing

1. Turn on the speaker. It will automatically enter Bluetooth pairing mode, indicated by a flashing LED light.
2. On your Bluetooth-enabled device (smartphone, tablet, etc.), navigate to the Bluetooth settings.
3. Search for available devices and select "EAS-3000" from the list.
4. Once paired, the LED indicator will stop flashing and remain solid, and you may hear a confirmation tone.
5. You can now stream audio wirelessly from your device to the speaker.

5.3 AUX Input Mode

1. Connect one end of a 3.5mm audio cable (not included) to the AUX input port on the speaker.
2. Connect the other end of the cable to the headphone jack or audio output of your external device.
3. Press the Mode button on the speaker until it switches to AUX input mode.

4. Play audio from your external device.



Image 5.1: The Emerson EAS-3000 speaker connected to a smartphone via a 3.5mm AUX cable for wired audio playback.

5.4 USB Playback Mode

1. Insert a USB flash drive containing audio files into the speaker's USB port.
2. Press the Mode button on the speaker until it switches to USB playback mode.
3. The speaker will automatically begin playing audio files from the USB drive.

Trendy and Portable

Enjoy your tunes anytime, anywhere



Image 5.2: A hand inserting a USB flash drive into the Emerson EAS-3000 speaker for direct audio playback.

5.5 Volume and Track Control

- **Volume Adjustment:** Short press the Volume Up (+) or Volume Down (-) buttons.
- **Track Navigation:** Long press the Volume Up (+) button for the next track, and long press the Volume Down (-) button for the previous track.

6. MAINTENANCE

- Keep the speaker away from water and excessive moisture. This product is not waterproof.
- Clean the speaker with a soft, dry cloth. Do not use abrasive cleaners or solvents.
- Avoid exposing the speaker to extreme temperatures or direct sunlight for extended periods.
- Store the speaker in a cool, dry place when not in use.

7. TROUBLESHOOTING

Problem	Possible Cause	Solution
Speaker does not turn on	Battery is depleted	Charge the speaker using the USB cable.
No sound from speaker	Volume is too low or muted	Increase the volume on both the speaker and the connected device.

Problem	Possible Cause	Solution
	Incorrect input mode selected	Press the Mode button to select the correct input (Bluetooth, AUX, USB).
	Device not properly connected (Bluetooth/AUX)	Ensure Bluetooth is paired or AUX cable is fully inserted.
Bluetooth device cannot pair	Speaker is not in pairing mode	Ensure the speaker is on and the LED indicator is flashing, indicating pairing mode.
	Device is too far from speaker	Move the Bluetooth device closer to the speaker (within 33 feet).
Poor audio quality via Bluetooth	Interference or distance	Reduce obstacles between devices or move closer. Disconnect other Bluetooth devices.

8. SPECIFICATIONS



Image 8.1: Physical dimensions and weight of the Emerson EAS-3000 Portable Bluetooth Speaker.

Feature	Detail
Model Name	EAS-3000
Brand	Emerson

Feature	Detail
Connectivity Technology	Bluetooth
Wireless Communication Technology	Bluetooth
Bluetooth Range	33 Feet
Audio Output Mode	Stereo
Surround Sound Channel Configuration	2.0
Speaker Maximum Output Power	20 Watts
Special Feature	Hi Res Audio
Power Source	Battery Powered (1 Lithium Ion battery included)
Product Dimensions	11.2"D x 4.75"W x 4.7"H
Item Weight	2.71 Pounds
Material	Plastic
Color	Black
Compatible Devices	Desktop, Laptop, MP3 Player, Projector, Smartphone, Tablet
UPC	840005018170

9. WARRANTY AND SUPPORT

The Emerson EAS-3000 Portable Bluetooth Speaker comes with a limited warranty. For detailed warranty information, please refer to the warranty card included in your product packaging or visit the official Emerson website. For technical support or customer service inquiries, please contact Emerson customer support through their official channels.