



[Manuals.plus](#) /

› [T4TREAM](#) /

› T4TREAM 60-inch Farmhouse Dresser with 4 Drawers and Sliding Barn Doors Instruction Manual

## T4TREAM 60" 4 Drawers Dresser

# T4TREAM 60-inch Farmhouse Dresser with 4 Drawers and Sliding Barn Doors Instruction Manual

## INTRODUCTION

---

This manual provides detailed instructions for the assembly, operation, and maintenance of your T4TREAM 60-inch Farmhouse Dresser. Please read all instructions carefully before beginning assembly and retain this manual for future reference. Ensure all components are present and undamaged before proceeding.

## PRODUCT OVERVIEW AND FEATURES

---

The T4TREAM 60-inch Farmhouse Dresser is designed for versatile storage and display. It features a rustic dark oak finish and combines drawers with sliding barn doors for functional and aesthetic appeal.



Image: The T4TREAM 60-inch Farmhouse Dresser in a living room, showcasing its dark rustic oak finish, four central drawers, and two sliding barn doors.

- **Dimensions:** 60 inches (W) x 15.75 inches (D) x 31.25 inches (H).
- **Storage:** Four central drawers (each 16.2"W x 12"D x 4.1"H) and two side cabinets with sliding barn doors.
- **Adjustable Shelves:** Each side cabinet includes two shelves with 3 height-adjustable positions, which are also removable for flexible storage configurations.
- **Material:** Constructed from FSC-Certified P2 manufactured wood, designed for durability and scratch resistance.
- **Weight Capacity:** Each drawer supports up to 25 lbs. The thickened top surface can support up to 150 lbs.
- **Versatility:** Suitable for use as a dresser in bedrooms, a TV stand in living rooms, or a buffet cabinet in kitchens/dining areas.

# VERSATILE AND CAN BE USED IN VARIOUS LIVING SPACES

It can serve as a dresser in your bedroom, a tv stand in the living room or buffet cabinet in the kitchen/dinning room.



Image: The dresser displayed in a bedroom, living room, and kitchen/dining room, illustrating its multi-functional design.

## SPECIFICATIONS

Attribute	Detail
Brand	T4TREAM
Color	Dark Rustic Oak

Product Dimensions	15.75"D x 60"W x 31.25"H
Special Feature	Shelved cabinets with sliding barn doors
Mounting Type	Freestanding
Room Type	Bedroom, Buffet, Kitchen, Living Room
Door Style	Sliding Barn Door
Finish Type	Distressed finish
Number of Shelves	2 (adjustable)
Base Type	Legs
Top Material Type	Engineered Wood
Assembly Required	Yes
Frame Material	Engineered Wood



Image: Detailed diagram illustrating the overall dimensions of the dresser (60"W x 15.75"D x 31.2"H) and the internal dimensions of a drawer (16.2"W x 12"D x 4.1"H).

## SETUP AND ASSEMBLY

Assembly of the T4TREAM 60-inch Farmhouse Dresser is required. The package includes detailed, step-by-step instructions. All parts and accessories are labeled with numbers, and precise holes are pre-drilled to facilitate accurate and faster installation.

### Before You Begin:

- **Unpack Carefully:** Lay out all components on a clean, soft surface to prevent scratches.
- **Verify Parts:** Cross-reference all parts and hardware with the included parts list. Contact customer support immediately if any parts are missing or damaged.
- **Tools Required:** A screwdriver is typically needed for assembly. Power tools are not recommended as they may overtighten screws and damage the wood.
- **Assistance:** Assembly may be easier with two people.

### Assembly Steps:

1. Follow the numerical sequence provided in the instruction manual.
2. Attach all panels and hardware securely, ensuring screws are tightened but not over-tightened.
3. Install the drawer slides and assemble the drawers according to the instructions.
4. Mount the metal track for the sliding barn doors and attach the doors.
5. Insert the adjustable shelves into the side cabinets at your desired height.
6. Attach any provided anti-tip hardware to the back of the dresser and secure it to a wall stud to prevent accidental tipping.

## OPERATING INSTRUCTIONS

### Drawers:

The four central drawers are designed with smooth-glide mechanisms for easy opening and closing. To operate, gently pull the drawer handle to open and push to close. Avoid forcing drawers if they encounter resistance.



Image: A top-down view of the dresser with its drawers partially open, demonstrating their capacity for storing items like socks and t-shirts.

### **Sliding Barn Doors:**

The two side cabinets feature sliding barn doors that move along a metal track. To open, gently slide the door horizontally along the track. This allows access to the adjustable shelf space within the cabinet. The doors can be positioned to cover either the central drawers or one of the side cabinets, offering flexible display and concealment options.



Image: A close-up view of the sliding barn door and its metal track, highlighting the smooth operation.

### **Adjustable Shelves:**

Each side cabinet contains two shelves that can be adjusted to three different height positions. To adjust, carefully remove the shelf, reposition the shelf pins to the desired height, and then reinsert the shelf. The shelves are also removable if you require a larger single storage space within the cabinet.



Image: A close-up view of an adjustable shelf within the cabinet, showing the peg holes for height customization.

## SPACIOUS STORAGE FOR MULTI-PURPOSE

Deep side cabinet with adjustable shelves to satisfy your different storage demands 🧦 🧺 🧺 🍴 🍴 🍴 🍴

### #Kitchen Storage



### #Bedroom Storage



Image: The side cabinets configured for multi-purpose storage, demonstrating use for kitchen items on the left and folded linens on the right.

## MAINTENANCE

Proper care will ensure the longevity and appearance of your dresser.

- **Cleaning:** Wipe surfaces with a soft, damp cloth. Avoid using abrasive cleaners, harsh chemicals, or polishes that may damage the distressed finish.
- **Spills:** Immediately wipe up any spills to prevent staining or moisture damage.
- **Heat and Moisture:** Avoid placing hot items directly on the surface. Use coasters or protective pads. Keep the dresser away from excessive moisture or direct sunlight to prevent warping or fading.
- **Hardware:** Periodically check all screws and fasteners to ensure they remain tight. Retighten as necessary.

## TROUBLESHOOTING

Common Issues and Solutions:

- **Sliding Barn Door Obstructed by Drawer Knobs:** If the sliding barn doors catch on the drawer knobs, ensure the knobs are fully tightened and not protruding excessively. If the issue persists, consider replacing the drawer knobs with flatter or recessed designs to allow for smooth door movement.
- **Dresser is Not Level:** Ensure the dresser is placed on a flat, even surface. Check that all legs or leveling feet (if provided) are properly installed and adjusted. If the unit has front-only leveling feet, shims can be placed under the back legs to achieve stability and levelness.
- **Drawers Stick or Do Not Close Smoothly:** Verify that the drawer slides are correctly installed and aligned. Ensure no objects are obstructing the drawer's path. Check that all screws on the drawer slides and drawer boxes are tight.
- **Wobbling or Instability:** Confirm that all assembly hardware is securely tightened. Ensure the dresser is placed on a stable surface. Utilize the provided anti-tip kit to secure the dresser to a wall, significantly enhancing stability.

## WARRANTY AND CUSTOMER SUPPORT

---

T4TREAM is committed to product quality and customer satisfaction. While specific warranty details are not provided in this manual, the manufacturer performs a quality check before delivery. If you encounter any questions or issues regarding your product, please do not hesitate to contact T4TREAM customer support. They aim to provide a satisfactory answer within 24 hours.

For assistance, please refer to the contact information provided with your purchase documentation or visit the official T4TREAM website.