Saved from manuals.plus.
Open the live page for links to other documents and user manuals.

Bellemave FST00021-T-AK1

Bellemave FST00021-T-AK1 Twin Loft Bed with Desk User Manual

Model: FST00021-T-AK1

Introduction

This manual provides essential information for the safe assembly, proper use, and maintenance of your Bellemave FST00021-T-AK1 Twin Loft Bed with Desk. Please read all instructions carefully before assembly and retain this manual for future reference.
The Bellemave FST00021-T-AK1 loft bed is designed to optimize space, featuring an elevated sleeping area and an integrated desk underneath. This design provides a dedicated space for study or activities, making it suitable for children's rooms or compact living areas.

Safety Information

WARNING: Failure to follow these warnings and instructions could result in serious injury or death.

- **Maximum Weight Capacity:** The loft bed is designed to support a maximum weight of 200 lbs (approximately 90 kg). Do not exceed this limit.
- **Guardrails:** Always use the provided guardrails on both sides of the upper bunk. Ensure they are securely attached to prevent falls.
- **Ladder Safety:** Ensure the ladder is securely attached before use. Always use the ladder for entry and exit from the upper bunk. Do not use the bed as a climbing frame.
- **Mattress Requirements:** Use only a mattress that is 74-75 inches long and 37.5-38.5 inches wide. The mattress thickness should not exceed 6 inches to ensure adequate guardrail height.
- **Assembly:** This product requires adult assembly. Follow all assembly instructions precisely. Do not use power tools for assembly unless specifically instructed, as overtightening fasteners can damage the wood.
- **Regular Checks:** Periodically check all fasteners (screws, bolts) to ensure they remain tight. Retighten as necessary.
- **Ventilation:** Ensure adequate ventilation around the bed.
- **Placement:** Position the bed away from windows, cords, or other items that could pose a strangulation hazard.

Setup and Assembly

The Bellemave FST00021-T-AK1 loft bed requires assembly. All necessary tools and a detailed assembly guide are provided with the product. Please follow the step-by-step instructions in the included guide for proper and safe assembly.

Before You Begin:

- Clear a spacious area for assembly.
- Unpack all components and verify against the parts list in your assembly guide.
- Ensure all hardware is present.
- Keep children and pets away from the assembly area.

Assembly Overview:

1. Assemble the main bed frame components.
2. Attach the ladder and desk components.
3. Install the bed slats and guardrails.
4. Ensure all connections are secure and stable.



Image: The Bellemave FST00021-T-AK1 Twin Loft Bed with Desk in white, showcasing its elevated design and integrated workspace.

Image: Technical diagram illustrating the dimensions and structural components of the Bellemave FST00021-T-AK1 Loft Bed.

Operating and Usage

The Bellemave FST00021-T-AK1 loft bed is designed for sleeping and study activities. The upper bunk provides a sleeping area, while the integrated desk underneath offers a functional workspace.

Using the Loft Bed:

- **Sleeping Area:** Place a suitable twin-size mattress on the slat foundation. Ensure the mattress fits snugly within the frame and does not exceed the recommended thickness to maintain guardrail effectiveness.
- **Desk Area:** The built-in desk provides a surface for homework, reading, or other activities. The under-bed clearance of 51 inches allows for comfortable seating.
- **Ladder Access:** Always use the integrated ladder to access and descend from the upper bunk. Ensure a firm grip and stable footing.



Image: A view of the Bellemave loft bed, highlighting the integrated desk and the ladder for accessing the upper bunk.



Image: A detailed view of the desk area beneath the Bellemave loft bed, showing space for a laptop and other items.

Maintenance

Regular maintenance ensures the longevity and safety of your Bellemave loft bed.

- **Cleaning:** Wipe the wooden surfaces with a dry, soft cloth. Avoid abrasive cleaners or harsh chemicals that may damage the finish.
- **Fastener Checks:** Periodically inspect all screws, bolts, and other fasteners. Tighten any loose connections to maintain structural integrity and prevent wobbling.
- **Structural Integrity:** Regularly check for any signs of wear, damage, or cracks in the wood. If any damage is found, discontinue use and contact customer support for assistance.
- **Slat Inspection:** Ensure all bed slats are properly seated and undamaged. Replace any broken or cracked slats immediately.



Image: A close-up view of the wooden slats that form the mattress support for the Bellemave loft bed.

Troubleshooting

This section addresses common issues you might encounter with your loft bed.

Bed Feels Wobbly:

- **Solution:** This is often caused by loose fasteners. Carefully re-tighten all screws and bolts throughout the entire bed frame, including the ladder and desk supports. Ensure the bed is placed on a level surface.

Missing or Damaged Parts:

- **Solution:** If you discover any missing or damaged parts upon unboxing, do not proceed with assembly. Contact Bellemave customer support immediately for replacement parts.

Difficulty Assembling:

- **Solution:** Refer to the detailed assembly instruction guide provided with your product. Ensure you are following each step in the correct order. If issues persist, contact customer support.

Specifications

Feature	Detail
Brand	Bellemave
Model Number	FST00021-T-AK1
Type	Loft Bed
Size	Twin
Material	Wood (Pine wood / PB / plywood)
Color	White
Finish Type	Lacquered
Product Dimensions (L x W x H)	2.02L x 1.11W x 1.65H Meters (79.5" L x 43.6" W x 65" H)
Item Weight	20.4 kg (45 lbs)
Weight Capacity	200 lbs
Special Feature	Integrated Desk
Included Components	Slat, Slide (Note: 'Slide' likely refers to the bed frame components, not a playground slide)
Assembly Required	Yes

Warranty and Support

Bellemave provides a one-year product warranty covering manufacturing issues for the FST00021-T-AK1 Twin Loft Bed.

To Claim Warranty or for Support:

- Please retain your proof of purchase.
- Contact Bellemave customer service through the retailer where the product was purchased or via the official Bellemave website for assistance with warranty claims, missing parts, or technical support.

© 2024 Bellemave. All rights reserved.

Ask a question about this manual

Ask about setup, troubleshooting, compatibility, parts, safety, or missing instructions. Manuals+ will review the question and use this page's manual context to help answer it.

Name

Anonymous

Email

you@example.com

After a successful submission, we securely hash the supplied account or form email before sending it to Microsoft Advertising for conversion attribution. Privacy details.

Question

Example: How do I reset this device or fix this error?

Details

Model number, symptoms, what you tried, or the section of the manual you are using.

Submit question

Open the live page

https://manuals.plus/asin/B0CGLMV9WB

More documents and user manuals: **https://manuals.plus/**