

Manuals.plus /

› HOOBRO /

› HOOBRO End Table BB106BZ01 Instruction Manual

## HOOBRO BB106BZ01

# HOOBRO End Table BB106BZ01 Instruction Manual

Model: BB106BZ01

## INTRODUCTION

---

Thank you for choosing the HOOBRO End Table Model BB106BZ01. This manual provides detailed instructions for the assembly, operation, and maintenance of your new end table. Please read this manual thoroughly before assembly and retain it for future reference.

## Safety Information

- Ensure all parts are present and undamaged before assembly. Do not use if any parts are missing or broken.
- Assemble the product on a soft, clean surface to prevent scratches.
- Do not overtighten screws during assembly to avoid damaging the material.
- Keep small parts away from children during assembly.
- Place the table on a level surface to ensure stability.
- Do not exceed the maximum weight capacity of the table.

## PACKAGE CONTENTS

---

Please verify that all components listed below are included in your package:

- Top Panel (1)
- Bottom Shelf (1)
- Metal Frame Legs (4)
- Fabric Drawers (2)
- Accessory Kit (Screws, Allen Key, etc.) (1)







Image: The fully assembled HOOBRO End Table BB106BZ01, showcasing its black metal frame, black top, two fabric drawers with round pulls, and a lower storage shelf.

## SETUP AND ASSEMBLY INSTRUCTIONS

---

Assembly is required for this product. It is recommended that one person assembles this unit. Please follow the steps below carefully.

- Unpack Components:** Carefully remove all parts from the packaging and lay them out on a soft, clean surface to prevent damage. Identify each component using the parts list.
- Attach Legs to Top Panel:** Secure the four metal frame legs to the underside of the top panel using the provided screws from the accessory kit. Ensure the legs are oriented correctly. Do not fully tighten screws yet.
- Install Bottom Shelf:** Attach the bottom shelf to the lower section of the metal frame legs using the appropriate screws. Ensure it is level and stable.
- Tighten All Screws:** Once all structural components are in place, gradually tighten all screws until secure. Avoid overtightening.
- Insert Fabric Drawers:** Unfold the two fabric drawers and insert the bottom panel into each drawer to give them shape. Slide the assembled drawers into their designated slots in the metal frame.
- Final Check:** Gently shake the assembled table to ensure stability. If any wobbling occurs, re-check all screw connections.

## OPERATING INSTRUCTIONS

---

The HOOBRO End Table BB106BZ01 is designed for versatile use in bedrooms or living rooms.

- Drawer Usage:** The two fabric drawers provide enclosed storage for personal items. Pull the decorative handles to open and push to close.
- Top Surface:** Use the top surface for lamps, books, beverages, or decorative items. Ensure items are placed stably.
- Bottom Shelf:** The open bottom shelf offers additional storage or display space for larger items like books, baskets, or small plants.
- Weight Capacity:** Distribute weight evenly. Avoid placing excessively heavy items on any single part of the table.

## MAINTENANCE AND CARE

---

Proper care will extend the life and appearance of your end table.

- Cleaning:** Wipe the metal frame and top panel with a soft, damp cloth. Avoid harsh chemicals or abrasive cleaners. For the fabric drawers, spot clean with a mild detergent and allow to air dry.
- Dusting:** Regularly dust all surfaces with a dry, soft cloth.
- Liquid Spills:** Immediately wipe up any liquid spills to prevent staining or damage to the surfaces.
- Sunlight Exposure:** Avoid prolonged direct sunlight exposure to prevent fading or material degradation.
- Screw Tightness:** Periodically check and tighten all screws to ensure the table remains stable.

## TROUBLESHOOTING

---

Problem	Possible Cause	Solution
Table is wobbly after assembly.	Screws are not fully tightened or unevenly tightened.	Ensure all screws are securely tightened. Place the table on a level surface.
Parts are missing from the package.	Packaging error or parts lost during unpacking.	Carefully check all packaging materials. Contact customer support for replacement parts.
Drawers do not slide smoothly.	Drawers are not fully unfolded or bottom panel not inserted correctly.	Ensure fabric drawers are fully expanded and the bottom panel is firmly in place. Check for any obstructions.

## SPECIFICATIONS

---

- **Model:** BB106BZ01
- **Brand:** HOOBRO
- **Material:** Metal Frame, Engineered Wood Top, Fabric Drawers
- **Color:** Black (Frame, Top, and Drawers)
- **Dimensions:** Approximately 15.7" L x 11.8" W x 26.7" H
- **Assembly Required:** Yes
- **Recommended Number of People for Assembly:** 1

*Note: Dimensions are approximate and may vary slightly.*

## WARRANTY AND SUPPORT

---

For warranty information, missing parts, or any questions regarding your HOOBRO End Table BB106BZ01, please contact HOOBRO customer support through the retailer's platform or the official HOOBRO website. Please have your model number (BB106BZ01) and purchase details ready when contacting support.

We are committed to providing quality products and support.

