

[Manuals.plus](#) /

› [Lenovo](#) /

› Lenovo IdeaPad Slim 3 Laptop User Manual | Model IPS3 15AMN8

Lenovo IPS3 15AMN8

Lenovo IdeaPad Slim 3 Laptop User Manual

Model: IPS3 15AMN8

INTRODUCTION

This manual provides essential information for the safe and efficient use of your Lenovo IdeaPad Slim 3 laptop. Please read this manual thoroughly before using your device to ensure proper setup, operation, and maintenance. Keep this manual for future reference.

PRODUCT OVERVIEW

The Lenovo IdeaPad Slim 3 is a portable laptop designed for daily computing tasks, offering a balance of performance and mobility. It features a 15.6-inch Full HD display, an AMD Ryzen 5 7520U processor, 16 GB of RAM, and a 512 GB SSD.



Figure 1: Front view of the Lenovo IdeaPad Slim 3 laptop.

Key Features:

- **Reliable Daily Performance:** Equipped with an efficient processor and sufficient RAM for internet browsing, email, word processing, and media streaming.
- **Portable Mobility:** Lightweight and slim design for convenient portability, allowing productivity on the go.
- **High-Resolution Display:** A 15.6-inch Full HD screen provides clear visuals and sharp text for work and entertainment.
- **Long Battery Life:** Energy-efficient design ensures extended use without constant recharging.

SETUP INSTRUCTIONS

1. Unpacking and Initial Inspection

Carefully remove the laptop and all accessories from the packaging. Inspect the device for any signs of damage. Retain the packaging for potential future transport or service.

2. Connecting the Power Adapter

Connect the power adapter to the laptop's power input port and then plug it into a wall outlet. It is recommended to fully charge the battery before first use.



Figure 2: Left side of the laptop with power port and USB ports.

3. First Boot and Operating System Setup

Press the power button to turn on the laptop. Follow the on-screen instructions to complete the initial setup of Windows 11 Home. This includes selecting your language, region, connecting to a network, and creating a user account.

4. Connecting Peripherals

You can connect external devices such as mice, keyboards, external monitors, and storage devices using the available USB and HDMI ports. Bluetooth devices can be paired through the Windows settings.



Figure 3: Right side of the laptop with SD card reader and USB port.

OPERATING INSTRUCTIONS

Power On/Off and Sleep Mode

- **Power On:** Press the power button located on the top right of the keyboard.
- **Power Off:** Click the Start button in Windows, then select Power > Shut down.
- **Sleep Mode:** Close the laptop lid or select Power > Sleep from the Start menu.

Keyboard and Touchpad

The laptop features a QWERTZ keyboard layout and a multi-touch touchpad for navigation. Refer to the image below for the keyboard layout.



Figure 4: Keyboard and touchpad layout.

Wireless Connectivity

- **Wi-Fi:** To connect to a wireless network, click the Wi-Fi icon in the taskbar, select your desired network, and enter the password if prompted.
- **Bluetooth:** To pair Bluetooth devices, go to Windows Settings > Bluetooth & devices, and follow the instructions to add a new device.

Using the Webcam

The integrated front-facing webcam can be used for video calls and conferences. Access it through applications like Microsoft Teams, Zoom, or the built-in Camera app in Windows.

MAINTENANCE

Cleaning the Laptop

- **Screen:** Use a soft, lint-free cloth lightly dampened with water or a screen cleaner. Do not spray liquid directly onto the screen.
- **Keyboard and Casing:** Use a soft, dry cloth. For stubborn dirt, a slightly damp cloth with mild soap solution can be used, ensuring no liquid enters openings.
- **Ports:** Use compressed air to gently remove dust from ports.

Battery Care

- Avoid extreme temperatures.
- Do not fully discharge the battery frequently.

- For long-term storage, charge the battery to about 50-60%.

Software Updates

Regularly check for and install Windows updates and driver updates from the Lenovo support website to ensure optimal performance and security.

Storage Management

Periodically clean up unnecessary files and applications to maintain sufficient free space on your 512 GB SSD for optimal system responsiveness.

TROUBLESHOOTING

This section addresses common issues you might encounter with your laptop. For more complex problems, refer to the Lenovo support website or contact customer service.

Problem	Possible Cause	Solution
Laptop does not power on.	Battery discharged, power adapter not connected, or hardware issue.	Ensure power adapter is securely connected and plugged into a working outlet. Allow battery to charge for a few minutes before attempting to power on again.
Screen is blank or black.	Laptop in sleep mode, display settings issue, or hardware problem.	Press any key or move the mouse to wake from sleep. Try connecting to an external monitor to check if the display output works. Restart the laptop.
Wi-Fi connection issues.	Incorrect password, router issue, or Wi-Fi adapter problem.	Verify Wi-Fi password. Restart your router and modem. Check Wi-Fi settings in Windows to ensure the adapter is enabled.
Slow performance.	Too many applications running, low disk space, or outdated software.	Close unnecessary applications. Free up disk space. Ensure Windows and drivers are up to date.

TECHNICAL SPECIFICATIONS

Below are the detailed technical specifications for the Lenovo IdeaPad Slim 3 (Model IPS3 15AMN8).




Figure 5: AMD Ryzen 5 processor.

Feature	Detail
Brand	Lenovo
Model Name	IPS3 15AMN8
Screen Size	15.6 inches
Optimal Resolution	1920 x 1080 pixels (Full HD)
Color	Arctic Grey
CPU Model	AMD Ryzen 5 7520U
CPU Speed	2.8 GHz
RAM Size	16 GB DDR5 SDRAM
Storage Size	512 GB SSD
Operating System	Windows 11 Home
Graphics Card	Integrated AMD Radeon Graphics
Item Weight	1.62 Kilograms
Dimensions (L x W x T)	35.9L x 1.8W x 23.5T cm
Battery Cell Composition	Lithium Ion
Battery Energy Content	47 Watt-hours
Total USB Ports	2
Video Output	HDMI
Wireless Standard	802.11n
Bluetooth Support	Yes
Keyboard Layout	QWERTZ
Webcam	Front-facing
Year Model	2023
UPC	197532833449
ASIN	B0CGLSRFXB

WARRANTY AND SUPPORT

Warranty Information

Your Lenovo IdeaPad Slim 3 comes with a **24-month warranty**. Please refer to the "Additional Technical Information" section on the product page for detailed warranty conditions. Your statutory warranty rights remain unaffected. This product also includes **3 months of Premium Care**, offering enhanced support from experts.



Figure 6: Lenovo Premium Care details.

Customer Support

For technical assistance, troubleshooting, or warranty claims, please visit the official Lenovo support website or contact their customer service. You may also find additional resources and drivers there.

Official documents for this product include a [User Guide \(PDF\)](#) and a [Data Transparency Declaration \(PDF\)](#).