

Manuals+

[Q & A](#) | [Deep Search](#) | [Upload](#)

[manuals.plus](#) /

> [Blestan](#) /

> [Blestan Handheld Cordless Car Vacuum Portable with LED Light User Manual](#)

Blestan LT-114

Blestan Handheld Cordless Vacuum User Manual

Model: LT-114

1. INTRODUCTION

Thank you for choosing the Blestan Handheld Cordless Car Vacuum. This portable vacuum cleaner is designed for efficient and convenient cleaning of various surfaces, especially in vehicles and small spaces. Featuring a powerful motor, LED light, and multiple attachments, it provides versatile cleaning solutions. Please read this manual thoroughly before operation to ensure proper use, maintenance, and longevity of your device.

2. SAFETY INSTRUCTIONS

- Do not use the vacuum cleaner to pick up flammable or combustible liquids, such as gasoline, or use in areas where they may be present.
- Do not pick up anything that is burning or smoking, such as cigarettes, matches, or hot ashes.
- Keep hair, loose clothing, fingers, and all parts of body away from openings and moving parts.
- Do not immerse the vacuum cleaner in water or other liquids.
- Use only as described in this manual. Use only manufacturer's recommended attachments.
- Do not use with damaged cord or plug. If appliance is not working as it should, has been dropped, damaged, left outdoors, or dropped into water, return it to a service center.
- Exercise extra care when cleaning on stairs.
- Unplug from outlet when not in use and before cleaning or servicing.
- This appliance is not intended for use by persons (including children) with reduced physical, sensory or mental capabilities, or lack of experience and knowledge, unless they have been given supervision or instruction concerning use of the appliance by a person responsible for their safety.

3. PACKAGE CONTENTS

Verify that all items are present and in good condition upon opening the package.

- Blestan Handheld Cordless Vacuum Unit
- Crevice Tool
- Brush Tool
- Extended Hose

- USB-C Charging Cable
- Washable HEPA Filter (pre-installed)
- Spare Washable HEPA Filter
- Carrying Case
- User Manual



Image: The Blestan Handheld Cordless Vacuum shown with its various accessories, including the crevice tool, brush tool, extended hose, USB-C charging cable, and carrying case. Two washable HEPA filters are also depicted.

4. PRODUCT COMPONENTS

Familiarize yourself with the main parts of the vacuum cleaner.

- **Dust Cup:** Transparent container for collecting debris.
- **HEPA Filter:** Located inside the dust cup, filters fine particles.
- **Power Button:** Activates and deactivates the vacuum.

- **Mode Button:** Switches between suction power modes.
- **LED Light:** Integrated light for illuminating dark areas.
- **Charging Port:** USB-C port for charging the internal battery.
- **Nozzle Release Button:** Releases the dust cup for emptying and filter access.



Image: The Blestan Handheld Cordless Vacuum in use, demonstrating its built-in LED light effectively illuminating a dark corner to reveal dust and debris.

5. SETUP

5.1 Initial Charging

Before first use, fully charge the vacuum cleaner. This typically takes approximately 3 hours.

1. Connect the provided USB-C charging cable to the charging port on the vacuum.
2. Connect the other end of the USB-C cable to a compatible USB power adapter (not included) or a computer USB port.

3. The indicator lights on the vacuum will illuminate to show charging status. All lights will be solid when fully charged.



Image: The Blestan Handheld Cordless Vacuum connected to a power outlet via its USB-C charging cable, illustrating the charging process.

5.2 Attaching Accessories

Select the appropriate attachment for your cleaning task and firmly push it onto the vacuum's nozzle until it clicks into place.

- **Crevice Tool:** Ideal for narrow gaps, corners, and hard-to-reach areas.
- **Brush Tool:** Suitable for upholstery, carpets, and surfaces that require gentle agitation to loosen debris.
- **Extended Hose:** Provides flexibility for reaching deep or awkward spaces, often used with other attachments.

Multipurpose Nozzles to Meet All Your Cleaning Needs



Image: A visual representation of the Blestan Handheld Cordless Vacuum's multipurpose nozzles, including the crevice tool for narrow gaps, the brush tool for hair and sofa cleaning, and the extended hose for deep and dark corners.

6. OPERATING THE VACUUM

6.1 Power On/Off

Press the Power Button once to turn the vacuum on. Press it again to turn it off.

6.2 Adjusting Suction Power

The vacuum features two suction power modes: Standard (7KPA) and Max (9KPA).

1. With the vacuum powered on, press the Mode Button to cycle between the two suction levels.
2. Use Standard mode for general cleaning and extended battery life.
3. Switch to Max mode for tougher debris and deeper cleaning.

Two Speeds for Ultimate Cleaning Power

- Max 9KPA
- Standard 7KPA



Dust



Pet Hair



Sand



Food Residue



Cat Litter

Image: The Blestan Handheld Cordless Vacuum illustrating its two speed settings (Max 9KPA and Standard 7KPA) and its effectiveness in picking up various types of debris such as dust, pet hair, sand, food residue, and cat litter.

6.3 Using the LED Light

The integrated LED light automatically activates when the vacuum is turned on, providing illumination for dark areas like under seats or in tight corners.

7. MAINTENANCE

7.1 Emptying the Dust Cup

For optimal performance, empty the dust cup regularly, especially when debris reaches the MAX fill line.

1. Ensure the vacuum is turned off.
2. Press the Nozzle Release Button to detach the dust cup from the main unit.
3. Hold the dust cup over a trash bin and open the dust cup lid to empty the contents.

7.2 Cleaning the HEPA Filter

The HEPA filter is washable and reusable. Clean it regularly to maintain suction power.

1. After emptying the dust cup, twist and pull out the HEPA filter assembly.
2. Tap the filter gently to remove loose dust.
3. Rinse the filter under cool running water until the water runs clear. Do not use detergent.
4. Allow the filter to air dry completely for at least 24 hours before reinserting it into the vacuum. Do not use a dryer or direct heat.
5. Reassemble the filter into the dust cup and attach the dust cup back to the vacuum unit.

A spare HEPA filter is included for convenience, allowing you to use the vacuum while one filter is drying.

7.3 Battery Care

- Charge the vacuum fully before storing for extended periods.
- Recharge the vacuum every 3-6 months even if not in use to maintain battery health.
- Avoid exposing the vacuum to extreme temperatures.

8. TROUBLESHOOTING

Problem	Possible Cause	Solution
Vacuum does not turn on.	Battery is depleted.	Charge the vacuum fully.
Low suction power.	Dust cup is full. Filter is clogged. Nozzle or hose is blocked.	Empty the dust cup. Clean or replace the HEPA filter. Check and clear any blockages in the nozzle or hose.
Vacuum stops during operation.	Battery is low. Overheating protection activated.	Recharge the battery. Turn off the vacuum and let it cool down for 30 minutes before resuming use.
Charging indicator lights blink but vacuum doesn't charge.	Faulty charging cable or adapter. Battery issue.	Try a different USB-C cable and power adapter. If the issue persists, contact customer support.

9. SPECIFICATIONS

Feature	Detail
Brand	Blestan
Model Number	LT-114
Form Factor	Handheld
Special Feature	Bagless, Built-in LED Light
Filter Type	HEPA Filter (Washable & Reusable)

Feature	Detail
Power Source	Battery Powered (Cordless)
Battery Type	Lithium-Ion (3 batteries required)
Wattage	100 watts
Suction Power	Standard: 7KPA, Max: 9KPA (2 Speeds)
Runtime	Up to 30 minutes
Charging Time	Approx. 3 hours (via USB-C)
Dust Cup Capacity	1.5 Pounds (approximate)
Noise Level	70 dB
Product Dimensions	12 x 7 x 3 inches
Item Weight	1.6 pounds
Indoor/Outdoor Usage	Indoor

10. WARRANTY AND SUPPORT

For warranty information or technical support, please refer to the contact details provided on the product packaging or the official Blestan website. Keep your purchase receipt as proof of purchase for any warranty claims.

Manufacturer: Blestan

Model: LT-114

