Saved from manuals.plus.
Open the live page for links to other documents and user manuals.

NOBLEWELL DGMT-4600-SBN5

NOBLEWELL Ergonomic Office Chair User Manual

Model: DGMT-4600-SBN5
Brand: NOBLEWELL

Introduction

This manual provides comprehensive instructions for the assembly, operation, maintenance, and troubleshooting of your NOBLEWELL Ergonomic Office Chair. Please read this manual thoroughly before assembly and use to ensure proper function and longevity of your chair.



Image: The NOBLEWELL Ergonomic Office Chair, white frame with grey mesh, positioned in a modern home office environment.

Safety Information

Please observe the following safety guidelines to prevent injury or damage to the product:

- The recommended maximum weight capacity for this chair is **300 pounds**. Do not exceed this limit.
- Use the chair only on hard, even surfaces to ensure stability.
- Follow all assembly instructions carefully. Ensure all components are securely fastened before use.
- This product does not have specific safety certifications beyond BIFMA durability stress tests.
- Keep hands and fingers clear of moving parts during adjustment.

Package Contents

Before beginning assembly, please verify that all components are present. The package should include:

- Office chair components (backrest, seat, armrests, base, gas lift, casters, headrest)
- Required accessories (screws, washers, tools)
- Installation manual

If any parts are missing or damaged, please contact NOBLEWELL customer support.

Setup and Assembly

The NOBLEWELL Ergonomic Office Chair is designed for easy assembly, typically taking about 10 minutes with 8 simple steps. Refer to the included installation manual for detailed, step-by-step visual instructions.

1. Attach the casters to the chair base.
2. Insert the gas lift into the center of the base.
3. Attach the armrests to the seat cushion.
4. Secure the backrest to the seat cushion.
5. Place the assembled seat and backrest onto the gas lift.
6. Attach the headrest to the top of the backrest.
7. Ensure all screws are tightened securely.
8. Test the chair's stability and adjustments before regular use.



Image: The NOBLEWELL Ergonomic Office Chair, white frame with grey mesh, situated in a professional office cubicle, demonstrating its suitability for various work environments.

Operating and Adjustments

Your NOBLEWELL Ergonomic Office Chair offers multiple adjustment features to customize your seating experience for optimal comfort and support.

Seat Height Adjustment

Locate the lever on the right side beneath the seat. Pull the lever up to raise the seat. While seated, pull the lever up to lower the seat. The seat height can be adjusted by approximately 3.9 inches (from 18.1 to 22 inches).

Headrest Adjustment

The headrest can be adjusted vertically by up to 2.0 inches to provide optimal neck and head support for users between 5'1" and 6'1" in height. Gently push or pull the headrest up or down to your desired position.

Lumbar Support Adjustment

The lumbar support can be fine-tuned by approximately 2.0 inches to provide tailored support to your lower back. Adjust the knob or lever located on the backrest to move the lumbar support up or down.

Backrest Recline and Locking

The backrest offers a recline range from 90° (upright working position) to 135° (relaxed resting position). Use the recline lever (typically on the left side) to unlock the backrest, lean back to your desired angle, and then push the lever down to lock it in place.



Image: A visual representation of the NOBLEWELL Ergonomic Office Chair's recline function, illustrating the range from 90 degrees for work to 135 degrees for relaxation.

2D Armrest Adjustment

The 2D armrests can be adjusted vertically by approximately 3.9 inches. Press the button on the side of each armrest and move them up or down to find your comfortable height, supporting your arms and shoulders.



Image: A diagram highlighting the multi-adjustable features of the NOBLEWELL Ergonomic Office Chair, including headrest, armrest height, waist height (lumbar), and seat height adjustments.

Swivel Function

The chair features a 360-degree swivel function, allowing for easy movement and access to different areas of your workspace without needing to reposition the entire chair.

Maintenance

Proper care and maintenance will extend the life of your NOBLEWELL Ergonomic Office Chair.

- **Cleaning:** The manufacturer recommends dry cleaning for the fabric components. For general cleaning, wipe down plastic and metal parts with a soft, damp cloth. Avoid harsh chemicals or abrasive cleaners.
- **Mesh Backrest:** The breathable mesh backrest can be gently wiped with a damp cloth and mild soap solution if necessary. Allow to air dry completely.
- **Casters:** Periodically check the silent caster wheels for any accumulated debris (hair, dust, etc.) and clean them to ensure

smooth movement.

- **Fasteners:** Occasionally check all screws and bolts to ensure they remain tight. Retighten if necessary to maintain stability.



Image: A close-up view of the durable mute casters on the NOBLEWELL Ergonomic Office Chair, highlighting their design for smooth and quiet movement on various floor types.

Troubleshooting

If you encounter issues with your NOBLEWELL Ergonomic Office Chair, refer to the following common troubleshooting steps:

Problem	Possible Cause	Solution
Chair wobbles or feels unstable.	Loose screws or uneven assembly.	Check all assembly screws and tighten them securely. Ensure the chair is on a flat, even surface.

Problem	Possible Cause	Solution
Gas lift not adjusting height.	Lever not engaged properly or gas lift malfunction.	Ensure the height adjustment lever is fully engaged. If the issue persists, the gas lift may need replacement. Contact customer support.
Casters not rolling smoothly.	Debris caught in casters or damaged casters.	Turn the chair over and remove any hair, dust, or debris from the caster wheels. If casters are damaged, they may need replacement.
Backrest not reclining or locking.	Recline mechanism not engaged or damaged.	Ensure the recline lever is fully engaged to unlock/lock the backrest. Check for any obstructions.

For issues not covered here, please contact NOBLEWELL customer support.

Specifications

Detailed specifications for the NOBLEWELL Ergonomic Office Chair (Model: DGMT-4600-SBN5):

Brand	NOBLEWELL
Model Number	DGMT-4600-SBN5
Color	White
Product Dimensions (D x W x H)	21.2"D x 18.9"W x 45.3"H
Maximum Weight Recommendation	300 Pounds
Seat Height	Adjustable, 18.1" - 22"
Seat Depth	19 inches
Back Style	Breathable Mesh
Special Features	Adjustable Lumbar Support, 2D Armrest, Adjustable Headrest, Reclining Backrest (90°-135°)
Material	Sponge (seat fill), Breathable Mesh (backrest)
Base Movement	Swivel
Item Weight	33 pounds
Included Components	Office chair, required accessories, installation manual
UPC	810145632871



Image: A comprehensive diagram illustrating the key dimensions of the NOBLEWELL Ergonomic Office Chair, including height, width, depth, and adjustable ranges for various components.

Customer Support

For further assistance, warranty information, or to purchase replacement parts, please visit the official NOBLEWELL store on Amazon or contact their customer service directly.

NOBLEWELL Store: https://www.amazon.com/stores/NOBLEWELL/page/1B59810E-22B0-4850-AEBC-35C70EF4C334

© 2023 NOBLEWELL. All rights reserved.

Ask a question about this manual

Ask about setup, troubleshooting, compatibility, parts, safety, or missing instructions. Manuals+ will review the question and use this page's manual context to help answer it.

Name

Anonymous

Email

you@example.com

After a successful submission, we securely hash the supplied account or form email before sending it to Microsoft Advertising for conversion attribution. Privacy details.

Question

Example: How do I reset this device or fix this error?

Details

Model number, symptoms, what you tried, or the section of the manual you are using.

Submit question

Open the live page

https://manuals.plus/asin/B0CGLVJ6NN

More documents and user manuals: **https://manuals.plus/**