

Manuals+

[Q & A](#) | [Deep Search](#) | [Upload](#)

[manuals.plus](#) /

› [aiprotabket](#) /

› [aiprotabket K12 Android 14 Tablet User Manual](#)

aiprotabket K12

aiprotabket K12 Android 14 Tablet User Manual

Model: K12

1. OVERVIEW

The aiprotabket K12 is a versatile 10-inch Android 14 tablet designed for productivity, entertainment, and learning. It features a powerful quad-core processor, ample memory, and expandable storage, making it suitable for a wide range of applications. This manual provides essential information for setting up, operating, maintaining, and troubleshooting your device.

2. WHAT'S IN THE BOX

Please verify that all items listed below are included in your package:

- 1 x aiprotabket K12 Tablet
- 1 x Bluetooth Keyboard
- 1 x Wireless Mouse
- 1 x Stylus
- 1 x Foldable Protective Case
- 1 x Protective Film (pre-applied or separate)
- 1 x Charger
- 1 x USB Cable
- 1 x Instruction Manual (this document)



Image: The aiprotab K12 Tablet shown with its full set of accessories, including the Bluetooth keyboard, wireless mouse, stylus, protective case, charger, and USB cable.

3. PRODUCT FEATURES

The aiprotab K12 is equipped with advanced features to enhance your digital experience:

- **Operating System:** Latest Android 14.0 for enhanced privacy, security, and customizable settings like split-screen and widgets.
- **Performance:** 2.0GHz Quad-core CPU, 6GB RAM, and 64GB ROM for faster responsive performance.
- **Expandable Storage:** Supports microSD card expansion up to 1TB.
- **Display:** 10.1-inch IPS HD screen with 1280x800 resolution for clear images and vivid colors.
- **Connectivity:** Bluetooth 5.0, 2.4G/5G WiFi for reliable wireless connections.
- **Battery:** 6000mAh battery providing 6-10 hours of usage on a single charge.
- **2-in-1 Functionality:** Transforms into a laptop-style device with the included Bluetooth keyboard, wireless mouse, and stylus.
- **Multimedia:** Dual cameras (front and rear) and Widevine L1 support for high-definition streaming.


<p>Android 14</p> 	<p>10-inch tablet HD screen delivers vibrant colours</p> 	<p>Dual Camera</p> 
<p>6GB RAM</p> 	<p>6000mAh large battery Type-c Charging</p> 	<p>Bluetooth 5.0</p> 
<p>64GB ROM</p> 		<p>WiFi 2.4G+5G WiFi 5</p> 
<p>Quad-Core</p> 	<p>Widevine L1 With IPS screen</p> 	<p>Dual Speaker</p> 
		

Image: A visual summary of the tablet's core features, including its operating system, memory, storage, display, and connectivity options.



Android 14

Increased performance and improved design for greater safety

- Improved performance
- Enhanced privacy protection
- Feature enhancements
- Increased safety

Watching made fun

Experience ultimate clarity: Certified with Widevine L1, HD streaming dimension!






NETFLIX Prime Video Youtube Hulu



Image: Highlights of the Android 14 operating system, emphasizing its improvements in performance, privacy, and overall user experience.

4. SETUP

4.1 Initial Charging

Before first use, fully charge your tablet. Connect the provided charger to the tablet's USB-C port and plug it into a power outlet. The battery indicator on the screen will show charging progress.

4.2 Powering On/Off

- **To Power On:** Press and hold the Power button (usually on the side) until the aiprotablet logo appears.
- **To Power Off:** Press and hold the Power button until the power options menu appears, then select "Power off".
- **To Restart:** Press and hold the Power button, then select "Restart".

4.3 Initial Android Setup

Upon first power-on, follow the on-screen prompts to complete the initial setup:

1. Select your language.
2. Connect to a Wi-Fi network.
3. Sign in with your Google account or create a new one.
4. Review and accept the terms and conditions.
5. Set up screen lock (PIN, pattern, or password).

4.4 Connecting Accessories

Your aiprotablet K12 comes with a Bluetooth keyboard, wireless mouse, and stylus for enhanced usability.

- **Bluetooth Keyboard:** Turn on the keyboard and enable Bluetooth on your tablet (Settings > Connected devices > Bluetooth). Select the keyboard from the list of available devices and follow pairing instructions.
- **Wireless Mouse:** The mouse typically connects via a USB dongle. Insert the dongle into the tablet's USB-C port using an adapter if necessary, or pair via Bluetooth if it's a Bluetooth mouse.
- **Stylus:** The stylus is generally passive and does not require pairing. Simply use it directly on the screen.

5. OPERATING THE TABLET

5.1 Basic Navigation

Navigate your tablet using standard Android touch gestures:

- **Tap:** Select an item or open an app.
- **Swipe:** Scroll through pages or lists.
- **Pinch-to-Zoom:** Zoom in or out on images and web pages.
- **Long Press:** Access contextual menus or move icons.

5.2 Split-Screen Mode

The Android 14 operating system supports split-screen functionality, allowing you to run two applications simultaneously.

1. Open the first app you want to use.
2. Swipe up from the bottom of the screen to access the recent apps view.
3. Tap the app icon at the top of the first app's card, then select "Split top".
4. Choose the second app from your recent apps or app drawer to fill the other half of the screen.



Image: The tablet displaying two applications side-by-side in split-screen mode, demonstrating its multitasking capability.

5.3 Wi-Fi and Bluetooth Connectivity

Access and manage your wireless connections through the Quick Settings panel (swipe down from the top of the screen) or via Settings > Network & internet for Wi-Fi, and Settings > Connected devices for Bluetooth.

5.4 Installing and Managing Apps

Download and install applications from the Google Play Store. To uninstall an app, long-press its icon on the home screen or in the app drawer, then drag it to "Uninstall" or select "App info" and choose "Uninstall".

5.5 Using the Cameras

The tablet features dual cameras. Open the Camera app to take photos or record videos. Switch between front and rear cameras using the icon on the screen.

6. MAINTENANCE

6.1 Cleaning the Device

Use a soft, lint-free cloth to clean the screen and body of the tablet. For stubborn smudges, slightly dampen the cloth with water or a screen cleaner. Avoid harsh chemicals or abrasive materials.

6.2 Battery Care

To maximize battery lifespan:

- Avoid extreme temperatures.
- Do not leave the tablet charging for extended periods after it's full.
- For long-term storage, charge the battery to about 50% and power off the device.

10.1 inch tablet with split screen

			
10.1 inch Display	1280x800 Resolution	84% Screen-to-Body Ratio	Split Screen




Image: An illustration of the tablet's 6000mAh battery capacity and its estimated usage times for video playback, web browsing, and e-book reading.

6.3 Software Updates

Regularly check for and install system updates (Settings > System > System update) to ensure optimal performance, security, and access to new features.

6.4 Storage Management

Periodically review your tablet's storage (Settings > Storage) to free up space by deleting unnecessary files, apps, or moving media to an external microSD card.

7. TROUBLESHOOTING

If you encounter issues with your aiprottablet K12, try the following common solutions:

- **Device Not Turning On:** Ensure the tablet is charged. Connect it to the charger and wait a few minutes before attempting to power on again.
- **Screen Unresponsive:** Force restart the tablet by holding the Power button for about 10-15 seconds.

- **Wi-Fi Connection Issues:** Restart your Wi-Fi router. On the tablet, forget the network and reconnect.
- **Bluetooth Accessory Not Connecting:** Ensure the accessory is in pairing mode and within range. Try restarting both the tablet and the accessory.
- **Apps Crashing/Freezing:** Clear the app's cache (Settings > Apps > [App Name] > Storage & cache > Clear cache). If the issue persists, try uninstalling and reinstalling the app.
- **Slow Performance:** Close unused apps, clear cache, and ensure sufficient free storage space.
- **Factory Reset:** As a last resort, you can perform a factory data reset (Settings > System > Reset options > Erase all data (factory reset)). **Warning: This will erase all data on your tablet. Back up important data before proceeding.**

8. SPECIFICATIONS

Feature	Specification
Model Name	K12
Operating System	Android 14
Screen Size	10.1 Inches
Screen Resolution	1280 x 800 Pixels
Processor	2.0 GHz Quad-core (Unisoc)
RAM	6 GB DDR3 SDRAM
Internal Storage	64 GB Flash Memory
Expandable Storage	Up to 1 TB via microSD card
Wireless Type	802.11ax (Wi-Fi), Bluetooth 5.0
Battery Capacity	6000 mAh Lithium Polymer
Average Battery Life	8 Hours (typical usage)
Rear Webcam Resolution	5 MP
Item Weight	2.2 pounds
Product Dimensions	9.5 x 7 x 0.5 inches
Color	Gray

9. WARRANTY AND SUPPORT

Your aiprottablet K12 comes with a standard manufacturer's warranty. Please refer to the warranty card included in your package for specific terms and conditions. For technical support, troubleshooting assistance, or warranty claims, please contact aiprottablet customer service through their official website or the contact information provided with your purchase.

For the latest information and support resources, visit the official aiprottablet store page on Amazon:[aiprottablet](#)

Store

© 2025 aiprotablet. All rights reserved.