

Manuals+

[Q & A](#) | [Deep Search](#) | [Upload](#)

[manuals.plus](#) /

› [Monoprice](#) /

› [Monoprice 106852 Keystone Jack HDMI Female to Female Coupler Adapter User Manual](#)

Monoprice 106852

Monoprice 106852 Keystone Jack HDMI Female to Female Coupler Adapter User Manual

Model: 106852



PRODUCT OVERVIEW

The Monoprice 106852 Keystone Jack HDMI Female to Female Coupler Adapter is designed to provide a clean and professional HDMI connection point within a wall plate or patch panel. This coupler features female HDMI connectors on both the front and back, allowing for easy integration of HDMI cables into a structured cabling system. It is ideal for extending HDMI signals or creating accessible HDMI ports in custom installations.



Image: Two Monoprice 106852 Keystone Jack HDMI Female to Female Coupler Adapters. These white adapters feature female HDMI ports on one end, designed to snap into standard keystone wall plates or patch panels.



Image: A single Monoprice 106852 Keystone Jack HDMI Female to Female Coupler Adapter. This view highlights the compact design and the vertical orientation of the HDMI connector when installed in a wall plate.

KEY FEATURES

- **HDMI Style Keystone Jack:** Designed to fit standard keystone wall plates and patch panels.
- **Coupler Type:** Features female HDMI connectors on both the front and back for easy pass-through connections.
- **Vertical Orientation:** The HDMI connector is oriented vertically when installed in a wall plate.
- **Durable Construction:** Built for reliable performance in various installations.

SETUP INSTRUCTIONS

Follow these steps to properly install your Monoprice 106852 Keystone Jack HDMI Coupler Adapter:

1. **Prepare Wall Plate/Panel:** Ensure you have a standard keystone wall plate or patch panel with an available keystone port.
2. **Insert Coupler:** Align the Monoprice HDMI keystone coupler with an empty keystone port on your wall plate or patch panel. Gently push the coupler into the port until it clicks securely into place. The coupler should sit flush with the plate.
3. **Connect HDMI Cables:**
 - Connect one end of your HDMI cable from your source device (e.g., Blu-ray player, game console, PC) to the

front female HDMI port of the keystone coupler.

- Connect the other end of an HDMI cable from your display device (e.g., TV, projector, monitor) to the rear female HDMI port of the keystone coupler.

4. **Secure Cables (Optional):** If routing cables through walls, ensure they are properly secured and protected to prevent damage or strain on the connections.

Note: This keystone orients the HDMI connector vertically into the wall-plate. Ensure adequate space behind the wall plate for cable bending if necessary.

OPERATING INSTRUCTIONS

The Monoprice 106852 Keystone Jack HDMI Coupler Adapter is a passive device that facilitates HDMI signal pass-through. No specific operational steps are required beyond proper installation and connection of HDMI cables.

- Ensure all HDMI cables are securely connected to both the keystone coupler and your source/display devices.
- Power on your source and display devices.
- Select the correct HDMI input on your display device.
- The HDMI signal should now pass through the keystone coupler to your display.

MAINTENANCE

The Monoprice 106852 Keystone Jack HDMI Coupler Adapter requires minimal maintenance.

- **Cleaning:** If necessary, gently wipe the exterior of the coupler with a soft, dry cloth. Avoid using liquid cleaners or abrasive materials.
- **Connection Check:** Periodically check that all HDMI cables are firmly seated in the coupler and connected devices to ensure optimal signal integrity.
- **Environmental Conditions:** Store and operate the coupler in a dry environment, away from extreme temperatures and direct sunlight.

TROUBLESHOOTING

If you experience issues with your Monoprice 106852 Keystone Jack HDMI Coupler Adapter, consider the following troubleshooting steps:

Problem	Possible Cause	Solution
No video/audio signal	Loose cable connections	Ensure all HDMI cables are securely plugged into the keystone coupler and connected devices.
No video/audio signal	Incorrect input selected on display	Verify that your display device is set to the correct HDMI input.
No video/audio signal	Faulty HDMI cable	Test with different HDMI cables to rule out cable issues.

Problem	Possible Cause	Solution
Intermittent signal	Long cable runs or signal degradation	For very long HDMI cable runs, signal boosters or active HDMI cables may be required. Ensure total cable length is within HDMI specifications for your resolution.
Coupler does not fit wall plate	Non-standard keystone port	Ensure your wall plate or patch panel uses standard keystone ports.

SPECIFICATIONS

Attribute	Value
Model Number	106852
Product Dimensions (L x W x H)	1.9 x 1.8 x 1 inches
Item Weight	0.64 ounces
Connector Type	HDMI Female to Female
Color	White
Manufacturer	Monoprice
First Available Date	August 25, 2023

WARRANTY AND SUPPORT

For warranty information and technical support, please refer to the official Monoprice website or contact Monoprice customer service directly. Keep your purchase receipt for warranty claims.

Monoprice Official Website: www.monoprice.com

© 2023 Monoprice. All rights reserved.

Related Documents - 106852

 <p>BLACKBIRD™ 4K Pro 4x4 HDMI™ True Matrix RS-232 GUIDE</p>	<p>Blackbird 4K Pro 4x4 HDMI True Matrix RS-232 Control Guide</p> <p>This guide provides detailed instructions for controlling the Blackbird 4K Pro 4x4 HDMI True Matrix using RS-232 serial commands and its accompanying GUI software. Learn about connection setup, firmware upgrades, and specific RS-232 commands for port switching, EDID management, status queries, and IR control.</p>
--	---

 <p>BLACKBIRD™ 8K 2x1 HDMI® 2.1 Switcher P/N 44434 Quick Start Guide</p>	<p>Monoprice BLACKBIRD 8K 2x1 HDMI 2.1 Switcher Quick Start Guide Quick start guide for the Monoprice BLACKBIRD 8K 2x1 HDMI 2.1 Switcher (P/N 44434), detailing features, operation, specifications, and regulatory compliance.</p>
<p>HDMM Matrix 4x4 User manual</p>	<p>HDMI Matrix 4x4 User Manual - Monoprice User manual for the Monoprice HDMI Matrix 4x4 (Blackbird 4K Pro), detailing features, specifications, operation controls, remote control functions, and PC software guide for managing HDMI signal distribution.</p>
 <p>BLACKBIRD™ 4K 2x4 HDMI® Splitter and Extender Kit P/N 43960 User's Manual</p>	<p>Monoprice Blackbird 4K 2x4 HDMI Splitter and Extender Kit User Manual User manual for the Monoprice Blackbird 4K 2x4 HDMI Splitter and Extender Kit (P/N 43960). This document provides detailed information on installation, features, product overview, IR control, RS-232 commands, specifications, and regulatory compliance for the device.</p>
 <p>BLACKBIRD™ 4K 3x1 HDMI® Switch P/N 43963 User's Manual</p>	<p>Monoprice Blackbird 4K 3x1 HDMI Switch User Manual User's manual for the Monoprice Blackbird 4K 3x1 HDMI Switch (P/N 43963). Provides safety guidelines, introduction, features, package contents, product overview, switching modes, specifications, technical support, and regulatory compliance information.</p>
 <p>BLACKBIRD™ 8K Dual Function HDMI® Splitter/Switch P/N 44086 User's Manual</p>	<p>Monoprice Blackbird 8K Dual Function HDMI Splitter/Switch (P/N 44086) User Manual User manual for the Monoprice Blackbird 8K Dual Function HDMI Splitter/Switch (P/N 44086). This guide covers safety, features, setup, specifications, and troubleshooting for seamless 8K video distribution.</p>