

[Manuals.plus](#) /

› [SEDETA](#) /

› SEDETA Corner Desk Instruction Manual

SEDETA home office desk corner desk

SEDETA Corner Desk

Instruction Manual

Model: home office desk corner desk | Brand: SEDETA

1. PRODUCT OVERVIEW

The SEDETA Corner Desk is a versatile and space-saving solution designed for home offices, gaming setups, and general computer use. It features integrated power outlets, LED lighting, a monitor riser, a keyboard tray, and ample storage shelves, making it ideal for optimizing small spaces.

Key Features:

- Integrated power outlets (2 AC outlets, 2 USB charging ports) for convenient device charging.
- RGB LED light strip with APP control, multiple colors, 29 flashing modes, music sync, and timer function.
- Extra-long monitor shelf designed to accommodate up to three monitors, reducing neck and back strain.
- Spacious 24-inch keyboard tray suitable for 108-key or 87-key keyboards and a mouse.
- Three storage shelves for organizing office supplies, books, or a printer.
- Durable construction with P2-degree engineered wood and heavy-duty metal frame, supporting up to 325 lbs.
- Adjustable leg pads for stability on uneven surfaces.



Figure 1.1: The SEDETA Corner Desk in a typical setup, showcasing its LED lighting, monitor shelf, and storage capabilities.

2. SETUP AND ASSEMBLY

This desk requires assembly. Please follow the included installation instructions carefully. It is recommended to have a second person assist with assembly for easier handling of larger components.

2.1 Unpacking and Inspection

Carefully unpack all components and verify that all parts listed in the instruction paper are present and undamaged. If any parts are missing or damaged, please contact customer support immediately.

2.2 Assembly Steps

1. **Prepare the Workspace:** Clear a spacious area for assembly. Lay down a blanket or cardboard to protect the desk components and your floor from scratches.
2. **Initial Fastening:** Begin by loosely attaching all screws, especially where the tabletop sections combine. This allows

for minor adjustments and alignment.

3. **Align Components:** Gently pat and adjust the tabletop and frame components to ensure they are level and properly aligned before fully tightening any screws.
4. **Tighten All Screws:** Once all parts are correctly positioned and aligned, systematically tighten all screws using the provided installation tool. Ensure all connections are secure for stability.
5. **Attach Power Outlets and LED Strip:** Follow the specific instructions in the included manual for attaching the power outlet module and the LED light strip to the desk. Ensure all cables are routed safely and neatly.
6. **Adjust Leg Pads:** Once assembled, adjust the leg pads at the bottom of the desk legs to ensure the desk is stable and level on your floor, even if it's carpeted or uneven.



Figure 2.1: Dimensional diagram of the SEDETA Corner Desk, indicating overall size and weight distribution capabilities.

3. OPERATING INSTRUCTIONS

3.1 Power Outlets and USB Charging

The desk is equipped with a built-in power strip featuring 2 AC outlets (125V/12A) and 2 PowerIQ-enabled USB charging ports (5V/2A). To use, simply plug the desk's main power cord into a wall outlet. You can then plug your devices directly into the desk's integrated outlets and USB ports.



Figure 3.1: Illustration of the integrated power outlets and USB charging ports, highlighting their specifications and the 5-foot power cord.

3.2 LED Light Strip Operation

The RGB LED light strip can be controlled via a dedicated mobile application. Download the app (refer to the LED strip's specific instructions for app name and QR code, if provided). Once connected, you can:

- Change between multiple colors.
- Select from 29 different flashing modes.
- Activate music sync function: The lights will change rhythmically with sound and music, detected by a built-in sensitivity-adjustable microphone.
- Set a timer for automatic on/off.



Figure 3.2: The SEDETA Corner Desk illuminated by its RGB LED light strip, creating an immersive gaming or working atmosphere.

3.3 Keyboard Tray Usage

The 24-inch extra-large keyboard tray is designed to smoothly slide in and out, providing ample space for a 108-key or 87-key keyboard and a mouse. This feature helps free up valuable desktop space.

24"Extra Large Keyboard Tray



- Perfect for any 108-key or 87-key keyboard+mouse
- No wobble, smoothly sliding

Figure 3.3: The spacious 24-inch keyboard tray, demonstrating its capacity for a full-size keyboard and mouse, designed for smooth operation.

3.4 Monitor Shelf and Storage Shelves

The elevated monitor shelf is designed to raise your monitors to an ergonomic height, promoting better posture and reducing strain. The desk can comfortably accommodate up to three monitors. The three additional shelves provide convenient storage for printers, books, and other office essentials, helping to keep your workspace tidy.

Bigger than others



Figure 3.4: The SEDETA Corner Desk showcasing its ample storage space on the side shelves and the elevated monitor shelf, designed to keep the desktop neat and organized.




Figure 3.5: A visual comparison illustrating the SEDETA desk's larger monitor shelf capacity, capable of holding three monitors compared to typical desks.

4. MAINTENANCE

4.1 Cleaning

To maintain the appearance and longevity of your SEDETA Corner Desk, follow these cleaning guidelines:

- **Surface Cleaning:** Wipe the engineered wood surfaces with a soft, damp cloth. For stubborn marks, a mild, non-abrasive cleaner can be used, followed by wiping dry immediately. Avoid harsh chemicals or abrasive cleaning tools that could damage the PVC surface.
- **Metal Frame:** Clean the metal frame with a damp cloth. Dry thoroughly to prevent rust.
- **Power Outlets:** Ensure the desk is unplugged from the wall outlet before cleaning around the power outlets and USB ports. Use a dry cloth to wipe away dust. Do not spray liquids directly onto electrical components.

4.2 General Care

- Avoid placing extremely hot or cold items directly on the desk surface without protective coasters.
- Do not drag heavy objects across the desk surface to prevent scratches.
- Periodically check and tighten all screws to ensure the desk remains stable and secure.
- Keep the desk away from direct sunlight and excessive humidity to prevent material degradation.

5. TROUBLESHOOTING

If you encounter any issues with your SEDETA Corner Desk, please refer to the following common solutions:

Problem	Possible Cause	Solution
Desk is wobbly or unstable.	Screws are not fully tightened; uneven floor.	Ensure all assembly screws are fully tightened. Adjust the adjustable leg pads at the bottom of the desk legs to level the desk on uneven surfaces.
Power outlets/USB ports are not working.	Desk not plugged into wall outlet; faulty wall outlet; internal wiring issue.	Check if the desk's main power cord is securely plugged into a functioning wall outlet. Test the wall outlet with another device. If the issue persists, contact customer support.
LED lights are not turning on or responding.	Power connection issue; app not connected; faulty LED strip.	Ensure the LED strip is properly connected to its power source. Verify your mobile device is connected to the LED strip via the app. Try restarting the app or your device. If still unresponsive, contact customer support.
Keyboard tray does not slide smoothly.	Obstruction in the rails; dirty rails; misaligned.	Check for any obstructions in the sliding rails. Clean the rails with a dry cloth. Ensure the tray was installed correctly and is not misaligned.

Important Note: If your item arrives damaged, scratched, or with missing parts, or if you encounter issues not covered here, please do not attempt to repair it yourself. Contact SEDETA customer support for assistance.

6. SPECIFICATIONS

Feature	Detail
Brand	SEDETA
Model Number	home office desk corner desk
Color	Black
Product Dimensions	87.88 x 132.08 x 87.38 cm (34.6 x 52 x 34.4 inches)
Item Weight	20.87 kg (46 lbs)
Material	Engineered Wood (P2-degree) with PVC surface, Alloy Steel frame

Feature	Detail
Special Features	Cord Rewind, Power Outlets (2 AC, 2 USB), LED Lights, Monitor Riser, Keyboard Tray, Storage Shelves, Adjustable Leg Pads
Desktop Load Capacity	Up to 325 lbs (Metal frames)
AC Outlet Specs	125V/12A
USB Port Specs	5V/2A (PowerIQ-enabled)
Power Cord Length	5 feet

7. WARRANTY AND SUPPORT

SEDETA is committed to providing high-quality products and customer satisfaction. While specific warranty terms are not detailed here, the manufacturer offers support for product issues.

If your SEDETA Corner Desk arrives damaged, scratched, or with missing parts, or if you experience any functional issues, please contact SEDETA customer service directly. They will assist you with free replacements or partial refunds as applicable.

For the most up-to-date support information, please refer to the contact details provided in your product packaging or visit the official SEDETA website.

© 2023 SEDETA. All rights reserved.
This manual is for informational purposes only. Product specifications are subject to change without notice.

ASK A QUESTION ABOUT THIS MANUAL

Ask about setup, troubleshooting, compatibility, parts, safety, or missing instructions. Manuals+ will review the question and use this page’s manual context to help answer it.

Name

Anonymous

Email

you@example.com

After a successful submission, we securely hash the supplied account or form email before sending it to Microsoft Advertising for conversion attribution. [Privacy details](#).

Question

Example: How do I reset this device or fix this error?

Details

Model number, symptoms, what you tried, or the section of the manual you are using.

Submit question

Open the live page

<https://manuals.plus/asin/B0CGMY4SCT>

More documents and user manuals: <https://manuals.plus/>