

Airspark AS200

Airspark AS200 Air Purifier User Manual

Model: AS200

Brand: Airspark

1. INTRODUCTION

Thank you for choosing the Airspark AS200 Air Purifier. This device is designed to provide powerful and effective air purification for large rooms up to 1375 sq ft, refreshing the air once per hour with a CADR of 187 m³/h (110 CFM). It features an advanced 4-in-1 True HEPA filtration system to capture common airborne particles and odors, ensuring a cleaner and healthier living environment.

Please read this manual thoroughly before operating the unit and retain it for future reference.

2. SETUP GUIDE

Follow these steps to set up your Airspark AS200 Air Purifier:

1. **Unpack the Unit:** Carefully remove the air purifier and all packaging materials from the box. Ensure all protective plastic wraps are removed, especially from the filter.
2. **Filter Installation:** The filter may come pre-installed but wrapped in plastic for protection.
 - Turn the air purifier upside down.
 - Twist the filter cover counter-clockwise to unlock and remove it.
 - Remove the plastic packaging from the 4-in-1 True HEPA filter.
 - Place the unwrapped filter back into the air purifier.
 - Replace the filter cover and twist clockwise to lock it securely.
3. **Placement:** Place the air purifier on a flat, stable surface. Ensure there is at least 15 inches (38 cm) of clear space around all sides for optimal air circulation.
4. **Connect Power:** Plug the power cord into a standard electrical outlet.



Figure 2.1: Illustration of the 4-stage filtration system, showing the Nylon Pre-Filter, Enhanced Pollen & Pet Filter, H13 True HEPA Filter, and Active Carbon Filter.

Your browser does not support the video tag.

Video 2.1: Demonstrates the functions of the AS200, including filter installation and control panel overview. (Source: Airspark Direct)

3. OPERATING INSTRUCTIONS

The Airspark AS200 features a simple and functional touch control panel on the top of the unit.



Figure 3.1: Overview of the touch control panel.

- **Power Button ():** Touch to turn the unit ON or OFF.
- **Fan Speed ():** Tap to cycle through 4 adjustable fan speeds (1, 2, 3, 4). Speed 1 is the quietest, while Speed 4 provides maximum purification.
- **Night Light & Sleep Mode ():**
 - Tap once to turn the night light ON.

- Tap twice to activate Sleep Mode. In Sleep Mode, all lights turn off, and the fan operates at its lowest, quietest setting (23dB) for undisturbed sleep.
- Tap a third time to turn off Sleep Mode and the night light.
- **Timer ()**: Tap to set the operating timer for 2, 4, 8, or 12 hours. The unit will automatically power off once the set time has elapsed.
- **HEPA Filter Indicator ()**: This light will illuminate red to remind you when it's time to replace the filter. (See Maintenance section for details).

4. KEY FEATURES

- **Powerful & Effective Purification**: Equipped with a long-life motor and 360-degree air intake circulation. CADR of 187 m³/h (110 CFM). Refreshes an 825 Sq Ft space once per hour, suitable for rooms up to 1375 Sq Ft.
- **Advanced 4-Stage Filtration**:
 - **Ultra Fine Pre-Filter**: Captures large particles like pet hair, lint, and fibers.
 - **Enhanced Pollen & Pet Filter**: Specifically designed to capture pollen and pet dander.
 - **H13 True HEPA Filter**: Captures at least 99.97% of 0.3 micron particles such as smoke, dust, and other airborne particles.
 - **Active Carbon Filter**: Absorbs smoke, kitchen odors, cooking smells, and pet smells.

Your browser does not support the video tag.

Video 4.1: Demonstrates the Airspark Air Purifier's effectiveness in purifying smoke and pollutants. (Source: Airspark Direct)

- **Whisper Quiet Operation**: Operates at a near-silent noise level as low as 23dB, ensuring a peaceful environment.
- **Night Light Function**: Soft night light can be used for baby care or as a gentle ambient light.

5. MAINTENANCE

Regular maintenance ensures optimal performance and longevity of your Airspark AS200 Air Purifier.

Filter Replacement

The red HEPA filter indicator light () on the control panel will illuminate when it's time to replace the filter. It is recommended to replace the Airspark air filter every 3-6 months, depending on air quality and usage.

1. Unplug the air purifier from the power outlet.
2. Turn the unit upside down and twist the filter cover counter-clockwise to remove it.
3. Carefully remove the old filter and dispose of it.
4. Unpack the new Airspark replacement filter (Search for B0CH7VVB1J on Amazon).
5. Insert the new filter into the unit.
6. Replace the filter cover and twist clockwise to lock it securely.
7. Plug the air purifier back in.
8. **Reset Filter Indicator**: Long press the HEPA filter indicator button () for 5 seconds until the red light turns off. This resets the filter replacement timer.

Higher Efficiency. Faster Purification



Figure 5.1: Steps for replacing the filter and resetting the indicator.

Your browser does not support the video tag.

Video 5.1: Demonstrates how to reset the red filter indicator light after replacement. (Source: Airspark Direct)

6. TROUBLESHOOTING

If you encounter any issues with your Airspark AS200, please refer to the common problems and solutions below:

Problem	Possible Cause	Solution
Unit does not turn on.	Power cord not securely plugged in. Filter cover not properly locked.	Ensure power cord is firmly plugged into outlet. Twist filter cover clockwise until it clicks into place.
Reduced airflow or unusual noise.	Filter is dirty or clogged. Obstruction in air intake/outlet.	Check and replace the filter if the indicator light is red. Ensure no objects are blocking the air intake (bottom) or outlet (top).
Odor persists after purification.	Filter needs replacement.	Replace the filter. The activated carbon layer may be saturated.

If the issue persists after trying these steps, please contact Airspark customer support.

7. SPECIFICATIONS

Feature	Detail
Model Number	AS200
Product Dimensions	7.9"D x 7.9"W x 16.9"H (7.9 x 7.9 x 16.9 inches)
Item Weight	6.5 Pounds
Coverage Area	Up to 1375 Sq Ft

Feature	Detail
CADR	187 m³/h 110 CFM
Noise Level	As low as 23dB
Filtration System	4-in-1 True HEPA (Nylon Pre-Filter, Enhanced Pollen & Pet Filter, H13 True HEPA Filter, Active Carbon Filter)
Fan Speeds	4 (1, 2, 3, 4)
Timer Settings	2, 4, 8, 12 Hours
Wattage	36 watts
Certifications	ETL, FCC, CA65
Country of Origin	China

8. WARRANTY AND SUPPORT

The Airspark AS200 Air Purifier comes with a **2-year free replacement warranty** (filters are excluded) and **lifetime technical support**. For any product-related inquiries, technical assistance, or warranty claims, please contact Airspark customer support through your purchase platform or the official Airspark website.

9. MORE INFORMATION

For a detailed PDF version of this user manual, please visit:[Airspark AS200 User Manual \(PDF\)](#)

ASK A QUESTION ABOUT THIS MANUAL

Ask about setup, troubleshooting, compatibility, parts, safety, or missing instructions. Manuals+ will review the question and use this page’s manual context to help answer it.

Name

Anonymous

Email

you@example.com

After a successful submission, we securely hash the supplied account or form email before sending it to Microsoft Advertising for conversion attribution. [Privacy details](#).

Question

Example: How do I reset this device or fix this error?

Details

Model number, symptoms, what you tried, or the section of the manual you are using.

Submit question