L LAVAREDO L6628

L LAVAREDO Men's Minimalist Analog Leather Wrist Watch User Manual

Model: L6628

Introduction

This manual provides detailed instructions for the L LAVAREDO Men's Minimalist Analog Leather Wrist Watch (Model L6628). Please read this manual carefully before using your watch to ensure proper operation and maintenance.



Figure 1: Front view of the L LAVAREDO Minimalist Analog Leather Wrist Watch.

Product Overview

The L LAVAREDO Minimalist Analog Leather Wrist Watch features an ultra-thin design with a black dial and a brown leather band. It is equipped with a quartz movement for accurate timekeeping and includes a date display function. The watch is designed for daily wear with 3ATM water resistance.

- **Ultra-thin Dial:** The watch features an ultra-thin 0.26" (6.7mm) thickness dial, contributing to its minimalist aesthetic.
- **Durable Materials:** The watch strap is made of high-quality leather, and the mineral glass is scratch-resistant and wear-resistant.
- **Accurate Timekeeping:** Utilizes an imported quartz movement for precise time.

- **Water Resistance:** Rated 3ATM waterproof, suitable for daily use such as hand washing or light rain. Not suitable for swimming or diving.



Figure 2: Illustration of the watch's ultra-thin dial and 6.7mm thickness.



Figure 3: Detailed views of watch components including the stainless steel back, leather strap, rose gold pointer, and date display.

Setup

1. Unboxing and Initial Inspection

Carefully remove the watch from its packaging. Inspect the watch for any visible damage or defects. Ensure all protective films are removed from the watch face and case back.

2. Setting the Time

1. Pull the crown (the small knob on the side of the watch) out to the first click position.
2. Turn the crown clockwise or counter-clockwise to set the hour and minute hands to the correct time.
3. Once the time is set, push the crown back in to its original position. The second hand will begin to move, indicating the watch is running.

3. Setting the Date

1. Pull the crown out to the second click position (further out than for time setting).
2. Turn the crown to adjust the date. Turn it until the correct date is displayed in the date window.
3. Once the date is set, push the crown back in to its original position.
4. **Note:** To avoid issues, it is recommended to set the date when the hour hand is between 4 AM and 8 PM. If setting the date between 9 PM and 3 AM, the date might not change correctly at midnight.

Operating the Watch

The L LAVAREDO watch is designed for straightforward operation. Once the time and date are set, the watch will continuously display the current time and date as long as the battery is functional.

Wearing the Watch

Adjust the leather strap to fit comfortably around your wrist. The strap should be snug enough to prevent the watch from rotating freely, but not so tight as to restrict circulation or cause discomfort.



Figure 4: Example of the watch being worn on a wrist.

Maintenance

Cleaning Your Watch

- Wipe the watch case and crystal with a soft, dry cloth to remove dust and fingerprints.
- For the leather strap, avoid prolonged exposure to water, direct sunlight, and harsh chemicals. If the strap gets wet, dry it thoroughly with a soft cloth and allow it to air dry completely before wearing.
- Do not use chemical cleaners or abrasive materials on any part of the watch.

Water Resistance (3ATM)

The watch is 3ATM (30 meters) water resistant. This means it is suitable for daily use and can withstand splashes, rain, and brief immersion in water (e.g., hand washing). It is **not** suitable for showering, bathing, swimming, diving, or any water sports. Avoid pressing the crown or operating buttons when the watch is wet.



Figure 5: Visual representation of the watch's 30M water resistance capabilities.

Battery Replacement

The watch uses a quartz movement with a battery life of up to 2 years. When the watch stops or the second hand starts skipping, it indicates a low battery. Battery replacement should be performed by a qualified watch technician to ensure proper sealing and water resistance.

Troubleshooting

Problem	Possible Cause	Solution
Watch stops or runs intermittently.	Low battery.	Replace the battery.
Date does not change at midnight.	Date was set during the "forbidden" period (9 PM - 3 AM).	Reset the date during the recommended time (4 AM - 8 PM).
Condensation inside the watch.	Exposure to extreme temperature changes or water ingress.	Immediately take the watch to a qualified technician for inspection and repair to prevent damage.
Watch strap discomfort or irritation.	Strap too tight, or allergic reaction to material.	Adjust strap for comfort. If irritation persists, consult a doctor and consider a different strap material.

Specifications

Feature	Detail
Model Number	L6628
Movement Type	Quartz
Dial Thickness	6.7 mm (0.26 inches)
Dial Color	Black
Case Diameter	39.5 mm
Strap Material	Leather
Strap Color	Brown (Orange-brown for this specific variant)
Strap Width	20 mm
Strap Length	217 mm
Water Resistance	3ATM (30 meters)
Weight	82 g
Crystal Material	Mineral Glass (Scratch-resistant)



Figure 6: Visual summary of key product parameters.

Warranty and Support

Warranty Information

L LAVAREDO products are manufactured with attention to quality. For specific warranty details, please refer to the warranty card included with your purchase or contact customer support.

Customer Support

If you have any questions, concerns, or require assistance with your L LAVAREDO watch, please do not hesitate to contact our customer support team. You can reach us via email through the seller contact option on the platform where you purchased the product.
We are committed to providing prompt and helpful assistance.

© 2024 L LAVAREDO. All rights reserved.

Ask a question about this manual

Ask about setup, troubleshooting, compatibility, parts, safety, or missing instructions. Manuals+ will review the question and use this page's manual context to help answer it.

Name

Anonymous

Email

you@example.com

After a successful submission, we securely hash the supplied account or form email before sending it to Microsoft Advertising for conversion attribution. Privacy details.

Question

Example: How do I reset this device or fix this error?

Details

Model number, symptoms, what you tried, or the section of the manual you are using.

Submit question