

[Manuals.plus](#) /

› [ATOZEE](#) /

› ATOZEE Android Tablet 2-in-1 (Model ATCP206IN1) User Manual


ATOZEE ATCP206IN1

ATOZEE Android Tablet 2-in-1 User Manual

Model: ATCP206IN1 | Brand: ATOZEE

INTRODUCTION

The ATOZEE 10-inch Android Tablet 2-in-1 is a versatile device designed for both productivity and entertainment. Featuring a stable Android 15.0 system, 5G Wi-Fi 6, and Bluetooth connectivity, it offers a responsive performance for various tasks. With 8GB RAM (including 6GB virtual memory) and 64GB ROM, expandable up to 1TB via microSD, you have ample space for applications, media, and documents. The tablet's 2-in-1 design allows it to transform into a laptop or computer mode with the included keyboard and mouse, making it suitable for home, school, or office use.



The ATOZEE tablet seamlessly transitions into a laptop-like setup with its accompanying keyboard and mouse, enhancing productivity.

WHAT'S IN THE BOX

Your ATOZEE Android Tablet package includes the following items:

- 10-inch Tablet PC
- Bluetooth Keyboard
- Bluetooth Mouse
- Standable Protective Case
- Flexible Stylus
- Type-C Cable


2MP

Front Camera



8MP

Rear Camera



All components included in your ATOZEE tablet package, ready for setup.

SETUP GUIDE

1. Initial Charging

Before first use, fully charge your tablet. Connect the provided Type-C cable to the tablet's charging port and the other end to a compatible power adapter. The 6000mAh battery provides approximately 6-8 hours of regular operation on a full charge.

6000mah battery

Equipped with 6000mah large-capacity battery, even the large 10.1-inch screen can last longer. Input power 5v / 2a.



6000mAh



The 6000mAh battery ensures extended usage for various activities.

2. Powering On/Off

- **To Power On:** Press and hold the power button located on the side of the tablet until the screen lights up.
- **To Power Off:** Press and hold the power button, then select 'Power Off' from the options that appear on the screen.

3. Connecting Accessories (Keyboard, Mouse, Stylus)

The included Bluetooth keyboard and mouse can be easily paired with your tablet:

1. Turn on the Bluetooth keyboard/mouse.
2. On your tablet, go to **Settings > Connected devices > Bluetooth**.
3. Enable Bluetooth and scan for available devices.
4. Select the keyboard/mouse from the list and follow any on-screen prompts to complete pairing.

The flexible stylus does not require pairing and can be used directly on the touch screen for navigation, drawing, or writing.



The Bluetooth keyboard provides a comfortable typing experience for extended use.



The flexible stylus enhances interaction for drawing, note-taking, and precise navigation.

4. Screen Protector Application

If your tablet comes with a pre-applied protective film, gently peel it off from the corner to reveal the main screen protector or the tablet's display. Ensure the screen is clean before applying any additional screen protection.

OPERATING INSTRUCTIONS

1. Basic Navigation

Your tablet runs on Android 15.0. Navigate through the interface using touch gestures:

- **Tap:** Select an item.
- **Swipe:** Scroll through pages or lists.
- **Pinch:** Zoom in or out.
- **Long Press:** Access contextual menus or move icons.

2. Wi-Fi and Bluetooth Connectivity

To connect to Wi-Fi or Bluetooth devices:


1. Go to **Settings**.
2. Select **Network & internet** for Wi-Fi or **Connected devices** for Bluetooth.
3. Toggle the respective switch to 'On' and select your desired network or device to connect.

3. Camera Usage

The tablet features a 2MP front camera for video calls and an 8MP rear camera with autofocus and flash for capturing photos and videos. Open the 'Camera' app to start. Tap to focus and press the shutter button to capture.

2 in 1 Tablet & PC





10.1" / 1280*800



8GB+64GB



Wi-Fi



6000mAh Battery



2MP+8MP Camera



Quad-Core

Capture moments with the 2MP front and 8MP rear cameras.

4. Storage Expansion

The tablet comes with 64GB of internal storage. You can expand this up to 1TB using a microSD card. Insert the microSD card into the designated slot on the tablet. The system will prompt you to format it for use.

MAINTENANCE AND CARE

1. Cleaning the Tablet

Use a soft, lint-free cloth to clean the tablet screen and body. Avoid using harsh chemicals or abrasive materials that could damage the surface.

2. Battery Care

To prolong battery life, avoid exposing the tablet to extreme temperatures. It is recommended to fully charge the battery before it completely drains, and avoid leaving it plugged in for extended periods after it's fully charged.

3. Software Updates

Regularly check for and install software updates to ensure optimal performance and security. Go to **Settings > System > System update** to check for available updates.

TROUBLESHOOTING

If you encounter issues with your ATOZEE tablet, try the following common solutions:

- **Tablet not turning on:** Ensure the battery is charged. Connect the charger and wait a few minutes before attempting to power on again.
- **Slow performance:** Close unnecessary background applications. Clear cache from apps or consider a factory reset if the issue persists (back up your data first).
- **Wi-Fi/Bluetooth connectivity issues:** Toggle Wi-Fi/Bluetooth off and on. Restart the tablet and the router/Bluetooth device.
- **Touchscreen unresponsive:** Restart the tablet. If the issue continues, ensure the screen is clean and free of debris.
- **Accessories not pairing:** Ensure the accessory is in pairing mode and within range. Check the tablet's Bluetooth settings and try re-pairing.

For persistent issues, please refer to the customer support section.

PRODUCT SPECIFICATIONS

Feature	Specification
Standing Screen Display Size	10.1 Inches
Screen Resolution	1280 x 800 pixels
Max Screen Resolution	1280*800 Pixels
Processor	2 GHz
RAM	8 GB
Hard Drive (ROM)	64 GB
Card Description	Integrated
Wireless Type	802.11ac (5G Wi-Fi 6)

Average Battery Life	7 Hours
Operating System	Android 15
Item Weight	1 pounds
Product Dimensions	12 x 8 x 0.3 inches
Color	Pink
Rear Webcam Resolution	8 MP
Front Webcam Resolution	2 MP
Flash Memory Size	64 GB
Power Source	Battery Powered

WARRANTY AND CUSTOMER SUPPORT

Your ATOZEE Android Tablet is covered by a standard manufacturer's warranty. For specific warranty details, including coverage period and terms, please refer to the documentation included with your purchase or contact ATOZEE customer support directly. If you require technical assistance, have questions about product functionality, or need to report an issue, please reach out to our support team through the contact information provided on the official ATOZEE website or your purchase platform.

ASK A QUESTION ABOUT THIS MANUAL

Ask about setup, troubleshooting, compatibility, parts, safety, or missing instructions. Manuals+ will review the question and use this page's manual context to help answer it.

Name

Anonymous

Email

you@example.com

After a successful submission, we securely hash the supplied account or form email before sending it to Microsoft Advertising for conversion attribution. [Privacy details](#).

Question

Example: How do I reset this device or fix this error?

Details

Model number, symptoms, what you tried, or the section of the manual you are using.

Submit question

