

Bower WA-BXLT9

Bower Mini Photo Studio Light Box - 9" Portable Folding Product Photography Shooting Tent Kit User Manual

Model: WA-BXLT9

1. INTRODUCTION

The Bower 9-inch Portable Lightbox Studio Kit is designed to provide an efficient and versatile solution for high-quality product photography. This compact and foldable studio tent is ideal for capturing small to medium-sized items with professional lighting and various background options. Its durable PVC construction ensures longevity, while the integrated LED lighting system helps eliminate harsh shadows, enhancing the visual appeal of your product shots.

Key features include:

- **All-Inclusive Lighting Solution:** Comes with a foldable light box, two built-in LED strips (rear and front), and six colored backgrounds.
- **Enhanced Lighting:** Rear and front LED light strips provide optimal illumination, reducing shadows.
- **Versatile Backgrounds:** Includes white, yellow, red, green, blue, and black backgrounds to suit various product aesthetics.
- **Multi-Angle Shooting:** Features both a front horizontal and a vertical shooting window for diverse photographic perspectives.
- **Portable and Easy to Use:** Assembles in seconds, crafted from durable PVC, and includes a convenient carry bag for transport.



Figure 1.1: The Bower Mini Photo Studio Light Box with a selection of colored backgrounds visible at the front.

2. PACKAGE CONTENTS

Please verify that all items listed below are included in your package. If any items are missing or damaged, please contact customer support.

- 1 x Foldable Light Box (with 2 built-in LED strips)
- 6 x Double-Sided Color Backgrounds (White, Yellow, Red, Green, Blue, Black)
- 1 x USB Power Cable
- 1 x Carry Bag



Figure 2.1: The back of the product packaging, illustrating the included components and key features such as multi-angle shooting and LED light strips.

3. SETUP INSTRUCTIONS

1. **Unfold the Light Box:** Carefully remove the light box from its carry bag. Unfold the flat PVC panels to form the cubic structure of the studio tent. The magnetic clasps on the edges will help secure the sides together.
2. **Position the Background:** Select one of the six colored backgrounds. Insert the chosen background into the slots at the bottom rear of the light box, allowing it to curve gently upwards to create a seamless backdrop.
3. **Connect Power:** Locate the integrated USB power cable. Connect the USB end to a compatible USB power source (e.g., a wall adapter, power bank, or computer USB port). The LED strips will illuminate.



Figure 3.1: An illustration showing the compact folded size (9.06 x 9.06 x 0.59 inches) and the expanded unfolded size (8.66 x 9.06 x 9.45 inches) of the light box, highlighting its portability and ease of setup.

4. OPERATING INSTRUCTIONS

Once assembled and powered, the Bower Mini Photo Studio is ready for use. Follow these steps to optimize your product photography:

1. **Place Your Product:** Carefully place the item you wish to photograph inside the light box, centered on the chosen background.
2. **Adjust Lighting:** The built-in front and rear LED strips provide balanced illumination. No further adjustment is typically needed for the light intensity. Ensure the USB power source is providing sufficient power for consistent lighting.
3. **Choose Shooting Angle:** The light box features multiple shooting ports. Use the front horizontal opening for standard shots. For top-down or unique angles, utilize the circular opening on the top panel.
4. **Experiment with Backgrounds:** Change the background color to best complement your product. For example, a white background provides a clean, minimalist look, while a black background can create a dramatic effect.

5. **Capture Images:** Use your smartphone or camera to take photos through the desired opening. Adjust your device's settings (e.g., white balance, exposure) as needed to achieve optimal results.



Figure 4.1: The light box in use, displaying a necklace on a stand against a white background, demonstrating its suitability for jewelry photography.

Unfolded Size:
8.66 X 9.06 X 9.45in

Folded Size:
9.06 X 9.06 X 0.59in



Figure 4.2: A product shot of a watch inside the light box, with a smartphone displaying the resulting high-quality image, illustrating the multi-angle shooting capability.



Figure 4.3: A potted plant positioned inside the light box, demonstrating its use for various small items and the effectiveness of the white background.



Figure 4.4: A toy truck photographed inside the light box, utilizing a vibrant red background to highlight the product.



Figure 4.5: The same toy truck photographed with a green background, showcasing the versatility of the included colored backdrops.

5. MAINTENANCE

Proper care and maintenance will ensure the longevity and optimal performance of your Bower Mini Photo Studio Light Box.

- **Cleaning:** Use a soft, dry cloth to wipe down the PVC surfaces of the light box. For stubborn marks, a slightly damp cloth with mild soap can be used, followed by immediate drying. Avoid abrasive cleaners or solvents.
- **Backgrounds:** The colored backgrounds can be wiped clean with a dry or slightly damp cloth. Store them flat or rolled to prevent creases.
- **LED Strips:** Do not attempt to clean the LED strips directly with liquids. If dust accumulates, gently brush it off with a soft, dry brush.
- **Storage:** When not in use, fold the light box back into its compact form and store it in the provided carry bag to

protect it from dust and damage.

6. TROUBLESHOOTING

If you encounter any issues with your light box, refer to the following common troubleshooting tips:

- **LEDs Not Lighting Up:**
 - Ensure the USB cable is securely connected to both the light box and a functioning USB power source.
 - Try a different USB port or power adapter to rule out a faulty power source.
- **Uneven Lighting/Shadows:**
 - Verify that both the front and rear LED strips are illuminated.
 - Adjust the position of your product within the light box.
 - Ensure your camera's flash is off, as it can create unwanted shadows.
- **Difficulty Folding/Unfolding:**
 - Apply gentle, even pressure when folding or unfolding. Do not force the panels.
 - Ensure no foreign objects are obstructing the folding mechanism.

7. SPECIFICATIONS







Feature	Detail
Model Number	WA-BXLT9
Package Dimensions	9.5 x 9 x 9 inches
Item Weight	14.4 ounces
Material	Polyvinyl Chloride (PVC)
Light Source Type	LED
Included Background Colors	White, Yellow, Red, Green, Blue, Black
Folded Size	9.06 x 9.06 x 0.59 inches
Unfolded Size	8.66 x 9.06 x 9.45 inches

8. WARRANTY & SUPPORT

Bower products are manufactured with quality and performance in mind. For specific warranty information, please refer to the documentation included with your purchase or visit the official Bower website. If you require technical assistance, have questions about product operation, or need to report a defect, please contact Bower customer support.

For further assistance, please visit the [Bower Store on Amazon](#).

Related Documents - WA-BXLT9

	<p>Bower Grappling Vlogpod User Manual: Features, Installation, and Specifications</p> <p>Comprehensive user manual for the Bower Grappling Vlogpod, detailing its features, step-by-step installation for smartphones, DSLRs, and action cameras, usage instructions, specifications, and warranty information.</p>
	<p>Bower Desk Mount Stand User Manual and Installation Guide</p> <p>Comprehensive user manual for the Bower Desk Mount Stand, detailing installation steps, product specifications, and warranty information for this versatile aluminum camera and lighting mount.</p>
	<p>B325 Cabinet Assembly Instructions</p> <p>Detailed assembly instructions for the B325 cabinet, including parts list and step-by-step guidance for construction and installation.</p>
	<p>BOWER Green Screen Backdrop 5' x 7' - User Manual and Features</p> <p>User manual for the BOWER 5' x 7' Green Screen Backdrop. Covers product introduction, installation, usage for photography, video, and streaming, features, specifications, care instructions, and limited one-year warranty.</p>
	<p>Brugervejledning til Mitsubishi Heavy Industries Air-Conditioner</p> <p>Denne brugervejledning fra Mitsubishi Heavy Industries giver detaljerede instruktioner til sikker og effektiv brug, installation og vedligeholdelse af deres airconditioner-modeller.</p>
	<p>Bower Multi-Pod 6-in-1 Tripod User Manual</p> <p>User manual for the Bower Multi-Pod 6-in-1 Tripod, detailing its use with smartphones, action cameras, and digital cameras, including installation and warranty information.</p>

Documents - Bower – WA-BXLT9

[\[pdf\]](#) User Manual Specifications

WA BXLT9 LTBX12 manual site Download Manual User Manuals v 1696007605 cdn shopify s files 1 2150 8455 |||

FOLDABLE LIGHT BOX STUDIO WITH 6 COLOR BACKGROUNDS PRODUCT PARTS INTRODUCTION HOW TO SET UP Unfold the Studio Light Box Light Box with 2 LED Strips 6 Color Backgrounds Connect the Corresponding Snap Buckle HOW TO SET UP When connecting/disconnecting the USB cable to/from the micro USB interf...

lang:en score:33 filesize: 9.32 M page_count: 1 document date: 2023-09-21

