

GVODE HLG2306

GVODE Masticating Juicer Attachment for KitchenAid Stand Mixer (Model HLG2306) - Instruction Manual

1. INTRODUCTION AND OVERVIEW

This manual provides essential instructions for the safe and efficient operation, maintenance, and care of your GVODE Masticating Juicer Attachment, Model HLG2306. This attachment is designed to integrate with KitchenAid Stand Mixers, transforming your mixer into a cold press juicer. Please read all instructions thoroughly before first use and retain this manual for future reference.



Figure 1: GVODE Masticating Juicer Attachment in operation with a KitchenAid Stand Mixer.

2. IMPORTANT SAFETY INSTRUCTIONS

- Always unplug the KitchenAid Stand Mixer before attaching, detaching, or cleaning the juicer attachment.
- Do not operate the juicer attachment without all parts properly assembled.
- Keep hands and utensils out of the feed chute during operation to prevent injury. Always use the food pusher provided.
- Ensure the KitchenAid Stand Mixer is on a stable, flat surface during use.
- This appliance is not intended for use by persons with reduced physical, sensory, or mental capabilities, or lack of experience and knowledge, unless they have been given supervision or instruction concerning use of the appliance by a person responsible for their safety.
- Do not immerse the main body of the KitchenAid Stand Mixer in water or other liquid.

- Do not use the attachment for purposes other than its intended use.

3. PACKAGE CONTENTS

Verify that all components are present:

- Main Juicer Body
- Auger
- Filter
- End Cap
- Food Pusher
- Juice Cup (with measurements)
- Pulp Cup
- Cleaning Brush

EASY TO INSTALL



Figure 2: Exploded view of the juicer attachment components.

4. SETUP AND ASSEMBLY

Follow these steps to assemble the juicer attachment:

1. **Prepare the Mixer:** Ensure your KitchenAid Stand Mixer is unplugged. Remove the accessory hub cover on the front of the mixer.
2. **Insert Auger:** Insert the auger into the main juicer body.
3. **Attach Filter:** Place the filter over the auger.
4. **Secure End Cap:** Twist the end cap onto the main juicer body until it locks securely.
5. **Connect to Mixer:** Insert the assembled juicer attachment shaft into the accessory hub of your KitchenAid Stand Mixer. Ensure the shaft is fully engaged.
6. **Tighten Knob:** Tighten the accessory hub knob on the mixer to secure the attachment.
7. **Position Cups:** Place the juice cup under the juice spout and the pulp cup under the pulp outlet.

Your browser does not support the video tag.

Video 1: Demonstrates the assembly process of the GVODE Masticating Juicer Attachment onto a KitchenAid Stand Mixer.

5. OPERATING INSTRUCTIONS

The GVODE Masticating Juicer Attachment uses a slow-pressure juicing technology to extract juice from various fruits and vegetables, minimizing oxidation and preserving nutrients.

5.1 Preparing Produce

- Wash all fruits and vegetables thoroughly.
- Cut produce into pieces small enough to fit into the dual feed chute. The attachment features two openings: 1.5 inches and 2 inches.
- Remove hard seeds, pits, or thick skins from fruits like peaches, mangoes, or pineapples before juicing.

FITS FRUITS & LONG VEGS



Figure 3: The dual feed chute accommodates various sizes of produce.

5.2 Juicing Process

1. Ensure the juicer attachment is securely installed and cups are in place.
2. Plug in your KitchenAid Stand Mixer.
3. Turn the mixer to the recommended speed setting:
 - **Speed 1-2 (Soft):** Recommended for soft fruits like oranges, apples, berries, and watermelon.
 - **Speed 3-4 (Hard):** Recommended for harder produce like celery, carrots, and beets.
4. Gradually feed prepared produce into the chute using the food pusher. Do not force ingredients.
5. The juicer will separate juice into the juice cup and pulp into the pulp cup.
6. Once juicing is complete, turn off and unplug the mixer.

MASTICATING JUICER ATTACHMENT

Matching stand mixer **1-4 speed**

Healthier, Richer, Tastier

SPEED 1-2
SOFT



Orange


SPEED 3-4
HARD



Celery



Apple



Carrot



Berries



Cucumber



Watermelon



Beet

Figure 4: Recommended speed settings for various types of produce.

6. MAINTENANCE AND CLEANING

Proper cleaning ensures the longevity and optimal performance of your juicer attachment.

- **Disassembly:** Unplug the KitchenAid Stand Mixer. Remove the juicer attachment. Disassemble all parts: end cap, filter, auger, and main juicer body.
- **Hand Wash Only:** All detachable parts of the juicer attachment should be hand-washed with warm, soapy water. Use the provided cleaning brush to remove any pulp residue from the filter and other intricate areas.
- **Rinse and Dry:** Rinse all parts thoroughly with clean water. Allow them to air dry completely before reassembling or storing.
- **Mixer Cleaning:** Wipe the accessory hub of the KitchenAid Stand Mixer with a damp cloth. Do not immerse the mixer in water.

EASY TO CLEAN



Figure 5: Hand-washing disassembled juicer components.

Note: The pomace (pulp) generated by the juicer can be used as a nutrient-rich fertilizer for plants.



**DEAR JUICER FOR YOUR
"DAY BY DAY"**



**FRUIT DREGS IS A GOOD
FERTILIZER, LET YOUR PLANTS
GROW HEALTHLY**

Figure 6: Utilizing fruit pomace as fertilizer.

7. TROUBLESHOOTING

Problem	Possible Cause	Solution
Juicer not operating	Mixer not plugged in; attachment not properly installed; mixer speed too low.	Ensure mixer is plugged in. Re-install attachment securely. Increase mixer speed.
Low juice yield / Wet pulp	Produce fed too quickly; produce too soft for current speed; end cap not adjusted correctly.	Feed produce slowly. Adjust mixer speed according to produce type (refer to Section 5.2). Ensure end cap is tightened for optimal pressure.

Problem	Possible Cause	Solution
Pulp or juice leakage	Attachment not securely fastened; parts not correctly assembled.	Check that the attachment is tightly secured to the mixer hub. Ensure all juicer components are correctly assembled and locked.
Attachment jams	Too much produce fed at once; hard seeds/pits not removed.	Turn off and unplug the mixer. Disassemble and clear any blockages. Ensure produce is cut appropriately and hard elements are removed.

8. SPECIFICATIONS

- **Brand:** GVODE
- **Model Name:** HLG2306
- **Product Dimensions:** 12"D x 11.4"W x 5.1"H
- **Item Weight:** 3.56 pounds
- **Material:** High-quality Plastic
- **Power Source:** Utilizes KitchenAid Stand Mixer power (Corded Electric)
- **Capacity:** 0.6 Liters (Juice Cup)
- **Product Care Instructions:** Hand Wash Only (detachable parts)
- **Special Feature:** Easy to Clean, Masticating, Dual Feed Chute

9. WARRANTY AND SUPPORT

GVODE products are manufactured with quality and durability in mind. For any questions regarding product operation, maintenance, or warranty claims, please refer to the contact information provided with your purchase documentation or visit the official GVODE website for customer support.

© 2023 GVODE. All rights reserved.

ASK A QUESTION ABOUT THIS MANUAL

Ask about setup, troubleshooting, compatibility, parts, safety, or missing instructions. Manuals+ will review the question and use this page’s manual context to help answer it.

Name

Anonymous

Email

you@example.com

After a successful submission, we securely hash the supplied account or form email before sending it to Microsoft Advertising for

conversion attribution. [Privacy details](#).

Question

Example: How do I reset this device or fix this error?

Details

Model number, symptoms, what you tried, or the section of the manual you are using.

Submit question