

Manuals.plus /

› tkwser /

› LOBOY Acrylic Cutlery Organizer with Lid Instruction Manual

## tkwser LB-OG885

# LOBOY Acrylic Cutlery Organizer with Lid

Model: LB-OG885 | Manufacturer: tkwser

## 1. PRODUCT OVERVIEW

---

The LOBOY Acrylic Cutlery Organizer with Lid is designed to keep your kitchen utensils neatly arranged and easily accessible. Crafted from high-quality, transparent acrylic, this organizer combines elegance with practical functionality, making it an essential addition to any kitchen or dining area. Its multi-compartment design ensures efficient storage for various types of cutlery, while the included lid provides protection and maintains hygiene.

### Key Features:

- **Sophisticated Design:** Combines crystal-clear transparency with an elegant design, enhancing your kitchen or dining table.
- **Multiple Compartments:** Organizes forks, knives, spoons, and other cutlery with specific compartments for practical selection.
- **Premium Material:** Made from high-quality, durable, and resistant acrylic, maintaining its aesthetic appeal over time.
- **Versatility:** Can be used for kitchen utensils, office supplies, or other items, adding value to various environments.
- **Decorative Touch:** Beyond its functionality, it serves as a decorative piece that adds sophistication to any space.
- **Easy to Clean:** Simple and quick cleaning process for maintaining hygiene.



Figure 1: The LOBOY Acrylic Cutlery Organizer with its lid open, showcasing the organized compartments filled with cutlery.

## 2. SETUP

---

The LOBOY Acrylic Cutlery Organizer is designed for immediate use with minimal setup required. Follow these simple steps to prepare your organizer:

1. **Unpack:** Carefully remove the cutlery organizer from its packaging. Inspect for any damage during transit.
2. **Clean:** Before first use, it is recommended to wash the organizer with mild soap and water. Rinse thoroughly and dry completely.
3. **Placement:** Place the organizer in your desired location, such as a kitchen drawer, on a countertop, or inside a cabinet. Ensure the surface is flat and stable.
4. **Lid Placement:** If using the lid, ensure it is properly aligned and seated on top of the organizer to protect the contents from dust and debris.



Figure 2: The cutlery organizer neatly placed within a kitchen drawer, demonstrating its ideal fit and organizational capacity.

### 3. OPERATION

---

Using your LOBOY Acrylic Cutlery Organizer is straightforward. Its multiple compartments are designed to help you categorize and store your cutlery efficiently.

1. **Identify Compartments:** The organizer features six distinct compartments. Typically, longer compartments are suitable for knives and forks, while shorter ones are ideal for spoons and smaller utensils.
2. **Arrange Cutlery:** Place your clean and dry cutlery into the appropriate compartments. For example, place knives in one long section, forks in another, and spoons in the remaining sections. Smaller items like teaspoons or dessert forks can go into the smaller front compartments.
3. **Utilize the Lid:** After placing your cutlery, you can cover the organizer with the transparent lid. This helps to keep your cutlery clean and protected from dust, especially if the organizer is placed on a countertop or in an open shelf.
4. **Accessing Cutlery:** When you need cutlery, simply lift the lid (if in use) and retrieve the desired utensil.



Figure 3: A clear view of the organizer's internal structure, demonstrating how cutlery is separated into different sections for easy access.

## 4. MAINTENANCE AND CARE

---

To ensure the longevity and pristine appearance of your LOBOY Acrylic Cutlery Organizer, follow these simple maintenance guidelines:

- **Regular Cleaning:** Clean the organizer regularly to prevent dust and food residue buildup.
- **Washing:** Wash by hand using warm water and a mild dish soap. Avoid abrasive cleaners or scouring pads, as these can scratch the acrylic surface.
- **Rinsing:** Rinse thoroughly with clean water to remove all soap residue.
- **Drying:** Dry immediately with a soft, lint-free cloth to prevent water spots. Air drying is also an option, but ensure it is completely dry before storing cutlery.
- **Avoid Harsh Chemicals:** Do not use ammonia-based cleaners (like window cleaner), alcohol, or other harsh chemicals, as they can damage the acrylic.
- **Heat Exposure:** Avoid placing the organizer near direct heat sources or in direct sunlight for prolonged periods, as extreme temperatures can cause warping or discoloration.
- **Scratch Prevention:** While durable, acrylic can scratch. Handle with care and avoid dragging sharp or rough objects across its surface.

## 5. TROUBLESHOOTING

---

This simple product is designed for reliability. Should you encounter any minor issues, consider the following:

- **Lid Does Not Close Properly:**
  - Ensure no cutlery or other items are protruding from the compartments, obstructing the lid's path.
  - Check if the lid is aligned correctly with the organizer's edges.
- **Organizer Does Not Fit in Drawer:**

- Verify the dimensions of your drawer against the product specifications (see Section 6).
  - Ensure there are no internal drawer obstructions.
- **Scratches on Surface:**
    - Acrylic is prone to scratches if not handled carefully. Use soft cloths for cleaning and avoid abrasive materials.
    - Minor scratches may sometimes be buffed out with specialized acrylic polish, but this is not guaranteed.

## 6. SPECIFICATIONS

---

Feature	Detail
Model Number	LB-OG885
Brand	tkwser (LOBOY)
Material	Acrylic (with Lid)
Color	Transparent
Finish Type	Powder Coated
Special Features	Crack Resistant
Product Specific Uses	Utensils
Included Components	1 x Drawer Organizer
Number of Compartments	6
Unit Count	1 Unit
Length	31 centimeters (12.2 inches)
Width	5 centimeters (2.0 inches)
Height	34.5 centimeters (13.6 inches)
Product Dimensions (L x W x H)	31 x 5 x 34.5 cm (12.2 x 2.0 x 13.6 inches)
Item Weight	830 grams (1.83 lbs)
Mounting Type	Floor Mount (suitable for drawers/countertops)

## 7. WARRANTY AND SUPPORT

---

For any questions, concerns, or support regarding your LOBOY Acrylic Cutlery Organizer, please contact the manufacturer or your point of purchase. While specific warranty details are not provided in this manual, standard consumer rights and return policies apply.

For further assistance, please refer to the contact information provided by the retailer or visit the official tkwser website.

