

[Manuals.plus](#) /

> [YITAHOME](#) /

> YITAHOME 16x32FT Heavy Duty Party Tent Instruction Manual

YITAHOME MAYIHwgtmy 16x32 FT

YITAHOME 16x32FT Heavy Duty Party Tent Instruction Manual

Model: MAYIHwgtmy | Size: 16x32 FT

1. INTRODUCTION

This manual provides essential instructions for the safe assembly, operation, and maintenance of your YITAHOME 16x32FT Heavy Duty Party Tent. Please read all instructions carefully before beginning assembly and retain this manual for future reference.



Image 1.1: The YITAHOME 16x32FT Party Tent, ideal for various outdoor events.

2. SAFETY WARNINGS

- **Wind Conditions:** Avoid using the tent in wind speeds exceeding 25 mph. High winds can cause structural damage and pose a safety risk.

- **Anchoring:** Always secure the tent to the ground using the provided ground nails for grassy surfaces or expansion screws for cement surfaces. Proper anchoring is crucial for stability.
- **Assembly:** Professional installation is highly recommended. Ensure adequate personnel are available for safe assembly.
- **Fire Safety:** Keep all heat sources and open flames away from the tent fabric. The material is not fireproof.
- **Snow/Ice:** Do not allow heavy accumulation of snow or ice on the tent roof. This can cause the structure to collapse.

3. PACKAGE CONTENTS

Your YITAHOME Party Tent is shipped in 3 separate boxes. Verify all components are present before beginning assembly.

- 1 x Top Cloth (140g PE)
- 2 x Sidewalls with Windows (140g PE)
- 2 x Zipper Doors
- Columns and Connecting Parts (Galvanized Steel)
- 3 x 600D Oxford Cloth Storage Bags
- 8 x Large Ground Nails
- 8 x Pull Ropes
- 24 x Small Ground Nails



Image 3.1: Included storage bags for convenient transport and storage of tent components.

4. ASSEMBLY INSTRUCTIONS

Follow these steps for proper assembly. It is recommended to have multiple people assist with the setup.

4.1 Frame Installation

1. Lay out all steel poles and connectors on a flat, clear surface. Refer to the diagram for component identification.
2. Assemble the roof frame first by connecting the horizontal and angled poles using the appropriate connectors. Ensure all connections are secure.
3. Attach the vertical leg poles to the assembled roof frame.
4. Secure the base of each leg pole with the provided footings and ground nails.

Your browser does not support the video tag.


Video 4.1: Demonstration of frame installation for a similar party tent.

4.2 Top Cloth and Sidewall Installation

1. Carefully drape the top cloth over the assembled roof frame. Ensure it is centered and evenly distributed.
2. Secure the top cloth to the frame using the elastic ball straps, threading them through the grommets and around the poles.
3. Attach the sidewalls and zipper doors to the frame using the hook-and-loop straps and elastic ball straps. The sidewalls are removable and can be adjusted based on weather or event needs.

DETACHABLE TENT ROOF

Enhances the overall stability of the tent



1 Complete dismantling



2 Partial dismantling



3 Fully enclosed

Image 4.1: Illustration of detachable tent roof and various enclosure configurations.



Image 4.2: Hook-and-loop straps provide secure attachment for sidewalls.

4.3 Anchoring the Tent

1. Drive the large ground nails through the footings of the leg poles into the ground.
2. Attach the pull ropes to the designated points on the tent and secure them to the small ground nails, driven into the ground at an angle away from the tent. Adjust tension as needed.

Your browser does not support the video tag.

Video 4.2: Detailed view of tent anchoring and structural components.

5. FEATURES AND DESIGN

- **Upgraded Framework:** Features a heavy-duty white powder-coated galvanized steel structure, resistant to rust and corrosion. The 1.5-inch (38 mm) steel tube diameter and 1.66-inch (42 mm) metal connector diameter provide strong support.
- **Superb Fabric:** The waterproof top is made from 140g PE cloth. The 140g high-quality PE removable sidewalls and zipper doors offer cross-ventilation and block 99% of harmful UV rays. 140-gram PVC windows enhance brightness.
- **Detachable Sidewalls:** The sidewalls can be easily removed or rolled up, offering flexibility for various weather conditions and event styles.
- **Church Window Design:** The PVC windows feature an elegant church window design, adding aesthetic appeal.




Image 5.1: The tent offers protection in various weather conditions, highlighting key attachment points.

DETACHABLE SIDEWALLS

Suitable for all seasons



Image 5.2: Detachable sidewalls provide versatility for different event needs.

6. USAGE GUIDELINES

This canopy party tent is designed as a multi-functional shelter for temporary outdoor gatherings. It is suitable for weddings, graduations, picnics, parties, BBQs, backyard events, and similar occasions.

- **Ventilation:** Utilize the removable sidewalls and zipper doors for cross-ventilation on warm days.
- **Capacity:** The 16x32 FT tent can accommodate approximately 8 round tables (5ft) or up to 80 standing people.



Image 6.1: Interior setup of the tent for an event, demonstrating spaciousness.

Your browser does not support the video tag.

Video 6.1: Overview of the GARTOO Outdoor Party Tent, showcasing its use for events.

7. CARE AND MAINTENANCE

- **Cleaning:** Clean the tent fabric with mild soap and water. Avoid harsh chemicals or abrasive cleaners that could damage the material.
- **Drying:** Ensure the tent fabric is completely dry before disassembling and storing to prevent mold and mildew.
- **Storage:** Store all components in the provided Oxford cloth storage bags in a cool, dry place away from direct sunlight.
- **Frame Inspection:** Periodically inspect the steel frame for any signs of rust or damage. Clean and treat any rust spots promptly to prolong the lifespan of the frame.

8. TROUBLESHOOTING

- **Tent Instability:** Ensure all ground nails and pull ropes are properly installed and tightened. Re-check wind speed and consider additional anchoring if necessary.
- **Water Leakage:** Verify that the top cloth is correctly positioned and taut. Check for any tears or punctures in the fabric and repair as needed.
- **Difficulty Assembling Poles:** Ensure you are using the correct poles and connectors as per the assembly diagram. Some connections may require gentle force.

9. SPECIFICATIONS

- **Brand:** YITAHOME
- **Model Number:** MAYIHWgtmy
- **Product Dimensions:** 384"L x 192"W x 110"H (16x32 FT)
- **Material:** Alloy Steel, Polyethylene (PE)
- **Frame Material:** Metal (Galvanized Steel)
- **Color:** White
- **Ultraviolet Light Protection:** UV-Resistant
- **Water Resistance Level:** Waterproof
- **Item Weight:** 56.9 pounds
- **Assembly Required:** Yes
- **UPC:** 840332334028




Image 9.1: Key dimensions and capacity information for the party tent.

10. WARRANTY AND SUPPORT

For any questions, concerns, or support needs regarding your YITAHOME Party Tent, please refer to the contact information provided with your purchase documentation. Specific warranty details are typically included with the product packaging.

For additional information or to explore other products, visit the [YITAHOME Store](#).