

## Manuals+

[Q & A](#) | [Deep Search](#) | [Upload](#)

manuals.plus /

- › [HAOVM](#) /
- › [HAOVM 10.1 Inch Smart Digital Picture Frame User Manual](#)

## HAOVM 10.1 Inch Smart Digital Picture Frame

# HAOVM 10.1 Inch Smart Digital Picture Frame User Manual

Brand: HAOVM | Model: 10.1 Inch Smart Digital Picture Frame

### INTRODUCTION

The HAOVM 10.1 Inch Smart Digital Picture Frame is designed to keep you connected with loved ones by instantly sharing photos and videos. Featuring a 1280x800 HD IPS touch screen, 64GB of built-in storage (expandable up to 512GB), and 2GB RAM, this Wi-Fi enabled frame offers a seamless experience. Beyond displaying memories, it includes a motion sensor, auto-rotate function, clock, alarm, calendar, and weather display for added convenience.



*The HAOVM 10.1 Inch Smart Digital Picture Frame, showcasing its elegant wood grain design and vibrant display.*

## WHAT'S IN THE BOX

Upon opening the package, you will find the HAOVM 10.1 Inch Smart Digital Picture Frame, along with its power adapter and a detachable stand. The stand allows for both portrait and landscape orientation. A user manual is also included for detailed instructions.

*Video: Demonstrates how to install the frame stand for both portrait and landscape display.*

## SETUP

### 1. Physical Setup

1. **Attach the Stand:** Securely attach the included stand to the back of the digital picture frame. The stand is adjustable to support both portrait and landscape orientations.
2. **Power On:** Plug the power adapter into the frame and then into a power outlet. The frame will automatically power on.

### 2. Initial Configuration

1. **Select Language:** On the welcome screen, tap to select your preferred language.
2. **Connect to Wi-Fi:** Follow the on-screen prompts to connect the frame to your 2.4 GHz Wi-Fi network. This is essential for sharing photos and videos remotely.

### 3. App Installation and Pairing

1. **Download the Biuframe App:** Scan the QR code displayed on the frame or search for "Biuframe" in your mobile device's app store (available for Android and iOS).
2. **Create an Account:** Open the Biuframe app and create a new account or log in if you already have one.
3. **Pair Your Frame:** In the app, select "Add Frame" and enter the Frame ID and Frame Email, which can be found in the frame's Settings > Friends menu. This will link your app to the digital picture frame.

*Video: Provides a detailed overview of the digital picture frame, including initial setup and app functionality.*

# Store All Your Memories

Save 100,000+ photos with 64GB memory  
Expandable via SD card/USB C Drive to 128GB



*The Biuframe app simplifies connecting to Wi-Fi and sharing content with your digital picture frame.*

## OPERATING INSTRUCTIONS

### 1. Sharing Photos and Videos

Once your frame is paired with the Biuframe app, you can easily send photos and videos from your smartphone or tablet. Simply select the desired media in the app and send it to your frame. New moments will appear on the frame within seconds. You can also share photos and videos via email by sending them to your frame's unique email address.

# Keep Every Moment Fresh

Share photos with loved ones anytime anywhere via App or email



*Share photos and videos instantly from your phone to the frame using the Biuframe app or email.*

## 2. Storage and Expansion

The frame comes with 64GB of built-in storage, capable of holding over 100,000 photos. Storage can be expanded up to 512GB using a TF card or USB-C drive (sold separately). These external storage options can also be used to upload, back up, and restore files.

## Store All Your Memories

Save 100,000+ photos with 64GB memory, expandable up to 128GB



SD Card



USB Drive



*The frame offers ample storage and expansion options for all your memories.*

### 3. Auto-Rotate Function

The digital picture frame automatically rotates the displayed image to match its orientation, whether placed in portrait or landscape mode. This ensures optimal viewing without manual adjustments.

## Smart and Energy-saving

The frame wakes up when detects people in the room; sleeps when not



*The auto-rotate feature ensures photos are always displayed correctly.*

### 4. Motion Sensor

The built-in motion sensor detects presence in the room, automatically waking the frame to display photos. When no motion is detected, the frame enters sleep mode to conserve energy and avoid disturbance.

*Video: Demonstrates the motion sensor feature, showing the frame activating when a person approaches.*

# Multi-Function Digital Frame



Photo



Video



Slide Show



Alarm



Sleep Mode



Motion Sensor



Weather



Calendar



*The motion sensor provides smart, energy-saving operation.*

## 5. Additional Functions

Beyond photo display, the frame offers practical features such as a Clock, Alarm, Calendar, and Weather display. These functions can be accessed and configured through the frame's touchscreen interface or the Biufame app.

## Easy to Stay Connected



Connect frame to WiFi



Send photo/video from the free App Biuframeare



Invite others to share



*The frame integrates multiple useful functions for daily convenience.*

### MAINTENANCE

To ensure the longevity and optimal performance of your digital picture frame, follow these maintenance guidelines:

- **Cleaning the Screen:** Use a soft, lint-free cloth to gently wipe the screen. For stubborn smudges, slightly dampen the cloth with water or a screen-safe cleaner. Avoid harsh chemicals or abrasive materials.
- **Cleaning the Frame:** Wipe the frame's exterior with a dry, soft cloth.
- **Power Off When Not in Use:** If storing the frame for an extended period, unplug it from the power source.
- **Avoid Extreme Conditions:** Do not expose the frame to extreme temperatures, direct sunlight for prolonged periods, or high humidity.

## TROUBLESHOOTING

If you encounter issues with your HAOVM Digital Picture Frame, refer to the following common solutions:

- **Frame is Frozen or Unresponsive:** If the frame freezes or displays a static logo, try unplugging it from the power source, waiting for 10-15 seconds, and then plugging it back in to restart.
- **Cannot Connect to Wi-Fi:** Ensure your Wi-Fi network is 2.4 GHz. Verify the Wi-Fi password is correct. Try restarting your Wi-Fi router and the picture frame.
- **Photos Not Displaying or Uploading:** Check your internet connection. Ensure the Biuframe app is updated to the latest version. Verify that the Frame ID and Frame Email entered in the app are correct.
- **External Storage (TF Card/USB Drive) Not Recognized:** Ensure the TF card or USB drive is inserted correctly. If using a TF card, ensure it is formatted to NTFS (not exFAT) for optimal compatibility. Try reformatting the card if issues persist (back up data first).
- **Motion Sensor Not Working:** Check the frame's settings to ensure the motion sensor feature is enabled. Ensure there are no obstructions blocking the sensor.

For further assistance, please contact HAOVM customer support.

## SPECIFICATIONS

Feature	Detail
Screen Size	10.1 Inches
Resolution	1280x800 HD
Product Dimensions	10.5 x 7.2 x 0.99 inches
Item Weight	2.51 pounds
Storage	64GB (expandable up to 512GB with TF card or USB-C drive)
RAM	2GB
Connectivity	2.4 GHz Wi-Fi
Compatible Devices	Android and iOS devices (via Biuframe app)
Color	Wood grain
Special Features	IPS Touch Screen, Motion Sensor, Auto-Rotate, Clock, Alarm, Calendar, Weather

## WARRANTY AND SUPPORT

HAOVM is committed to providing quality products and customer satisfaction. Your digital picture frame comes with

a 30-day money-back guarantee and a 365-day worry-free warranty. Optional 2-Year and 3-Year Protection Plans are also available for purchase.

For any inquiries or support needs, HAOVM offers quick replies within 24 hours. Please refer to the contact information provided in your product packaging or on the official HAOVM website for direct assistance.