

[manuals.plus](#) /› [T'nB](#) /› [T'nB SlidePoint Wireless Presentation Laser Pointer User Manual](#)

## T'nB LASERREMOTE2

# T'nB SlidePoint Wireless Presentation Laser Pointer User Manual

Model: LASERREMOTE2

## INTRODUCTION

Thank you for choosing the T'nB SlidePoint Wireless Presentation Laser Pointer. This device is designed to enhance your presentations with intuitive controls and a reliable wireless connection. Please read this manual carefully to ensure proper use and to maximize the product's lifespan.

## PACKAGE CONTENTS

- T'nB SlidePoint Wireless Presentation Laser Pointer
- 2-in-1 USB A and USB C Receiver Dongle
- USB-C Charging Cable
- User Manual (this document)

## PRODUCT OVERVIEW

Familiarize yourself with the components of your T'nB SlidePoint presenter.



**Figure 1:** T'nB SlidePoint Laser Presenter and its 2-in-1 USB receiver dongle. The presenter is black with grey buttons, and the USB receiver is shown detached from the presenter's base.

1. **Laser Pointer Button:** Activates the red laser beam.
2. **Page Up Button:** Moves to the previous slide in a presentation.
3. **Page Down Button:** Moves to the next slide in a presentation.
4. **Play/Escape Button:** Starts or exits a slideshow.
5. **Volume Up Button:** Increases audio volume.
6. **Volume Down Button:** Decreases audio volume.
7. **USB-C Charging Port:** For recharging the internal battery.
8. **2-in-1 USB A/USB C Receiver Dongle:** Connects wirelessly to your computer.

## SETUP

---

### Connecting the Receiver

1. Locate the 2-in-1 USB receiver dongle, typically stored within the presenter's body for safekeeping.
2. Insert the USB A or USB C end of the receiver dongle into an available USB port on your computer (PC or Mac).
3. The computer should automatically recognize the device. No driver installation is required for most operating systems (Plug and Play).
4. Once recognized, the presenter is ready for use.

## OPERATING INSTRUCTIONS

---

### Presentation Control

- **Page Up (↑):** Press this button to navigate to the previous slide in your presentation software (e.g., PowerPoint, Keynote, Google Slides).
- **Page Down (↓):** Press this button to advance to the next slide in your presentation software.
- **Play/Escape (ESC):** Press once to start a slideshow. Press again to exit the slideshow mode.

### Laser Pointer Function

- **Laser Button (Laser Beam):** Press and hold this button to activate the red laser beam. A small indicator light on the presenter will illuminate when the laser is active. Release the button to turn off the laser.
- *Caution: Do not point the laser beam directly at people's eyes or at reflective surfaces.*

### Volume Control

- **Volume Up Button:** Press to increase the audio output volume of your computer.
- **Volume Down Button:** Press to decrease the audio output volume of your computer.

## CHARGING THE DEVICE

---

The T'nB SlidePoint presenter features a built-in rechargeable battery.

1. Connect the provided USB-C charging cable to the USB-C port on the presenter.
2. Connect the other end of the charging cable to a USB power source (e.g., computer USB port, USB wall adapter).
3. An indicator light on the presenter will show the charging status. Refer to the device's specific indicator behavior for full charge notification (e.g., light turns off or changes color).
4. A full charge provides extended usage time for multiple presentations.

## MAINTENANCE

---

- Keep the device clean by wiping it with a soft, dry cloth.
- Avoid exposing the presenter to extreme temperatures, direct sunlight, or moisture.
- Store the USB receiver dongle inside the presenter when not in use to prevent loss.
- Do not attempt to disassemble the device, as this will void the warranty.

## TROUBLESHOOTING

---

Problem	Possible Cause	Solution
Presenter not responding.	Receiver not properly connected or not recognized.	Ensure the USB receiver is fully inserted into a working USB port. Try a different USB port.
Presenter battery is depleted.	Charge the presenter using the USB-C cable.	
Laser not working.	Laser button not pressed or held correctly.	Press and hold the laser button firmly. Check battery level.
Presentation slides not advancing.	Presentation software not in focus or not compatible.	Ensure your presentation software is the active window. Test with different presentation applications.

## SPECIFICATIONS

---

**Model:** LASERREMOTE2

**Brand:** T'nB

**Connectivity:** 2.4 GHz Wireless (RF) with 2-in-1 USB A/USB C Receiver

**Power:** Rechargeable via USB-C

**Dimensions (L x W x H):** 13.8 x 2 x 1.2 cm (5.43 x 0.79 x 0.47 inches)

**Weight:** 32.3 Grams (1.14 ounces)

**Color:** Black

**Laser Type:** Red Laser

## WARRANTY AND SUPPORT

---

This T'nB product is covered by a **2-year manufacturer warranty** from the date of purchase. For warranty claims or technical support, please contact T'nB customer service.

As a French company, T'nB is committed to providing quality products that comply with European standards. Your satisfaction is a priority. For any questions or defective products, please contact our customer service based in France for assistance.

For more information, visit the official T'nB website or refer to your purchase documentation.