

## Manuals+

[Q & A](#) | [Deep Search](#) | [Upload](#)

[manuals.plus](#) /

› [AGARO](#) /

› [AGARO Galaxy Cordless Tyre Inflator User Manual](#)

## AGARO Galaxy

# AGARO Galaxy Cordless Tyre Inflator User Manual

## INTRODUCTION

This manual provides detailed instructions for the safe and efficient operation of your AGARO Galaxy Cordless Tyre Inflator. Please read this manual thoroughly before using the device and retain it for future reference.

## SAFETY INFORMATION

- Ensure the device is fully charged before first use.
- Do not operate the inflator near flammable liquids or gases.
- Keep out of reach of children.
- Avoid over-inflating. The device features an automatic shut-off function to prevent this.
- Allow the device to cool down for 3-5 minutes after every 10 minutes of continuous use to maintain optimal performance and prevent overheating.
- Do not expose the device to extreme temperatures or direct sunlight for prolonged periods.

## PACKAGE CONTENTS

Verify that all items are present in the package:

- 1 x AGARO Galaxy Cordless Tyre Inflator Main Unit
- 1 x Air Tube (Hose Pipe)
- 3 x Nozzles (for various inflation needs)
- 1 x USB Type-C Charging Cable



Image: The AGARO Galaxy Cordless Tyre Inflator shown with its complete set of accessories, including the main unit, air hose, three different nozzles, and a USB charging cable.

## PRODUCT OVERVIEW

The AGARO Galaxy Cordless Tyre Inflator is a versatile 3-in-1 device designed for convenience and portability. It functions as a tyre inflator, an LED flashlight, and a power bank.

# Inflate, Illuminate, Recharge



Tyre inflator



Flash light



Power bank



White Light      Red SOS Light



Image: The AGARO Galaxy inflator showcasing its three primary functions: tyre inflator, flashlight, and power bank, with a 1-year warranty badge.

# Portable & cord free



Image: A hand holding the compact and cordless AGARO Galaxy inflator, demonstrating its portable design.

## SETUP

### Initial Charging

Before first use, fully charge the device. Connect the provided USB Type-C cable to the charging port on the bottom of the inflator and plug the other end into a suitable USB power adapter (not included). Charging typically takes 3-4 hours.

# Rechargeable Batteries

**4000 mAh  
(2X2000)**

\*Please charge for  
3-4 hrs before first use




Image: An X-ray view of the AGARO Galaxy inflator, highlighting its internal 4000 mAh (2x2000 mAh) rechargeable batteries. A note advises charging for 3-4 hours before first use.

## OPERATING INSTRUCTIONS

Follow these steps to inflate an item:

1. **Connect the Hose:** Remove the valve cap from the item you wish to inflate. Securely connect the air tube (hose pipe) to the valve.

2. **Power On:** Press the power button on the inflator to turn on the device. The digital display will illuminate.

3. **Select Mode and Set Pressure:**

- Short press the mode button (often indicated by a square icon) to cycle through pre-set inflation modes (e.g., car, bike, ball).
- To manually set the desired pressure, use the '+' and '-' buttons.
- To change pressure units (PSI, KPA, BAR, KG/CM<sup>2</sup>), long press the mode button.

- 4. Start Inflation:** Once the desired pressure is set, press the power button again to begin inflation. The real-time pressure will be displayed.
- 5. Automatic Shut-off:** The inflator will automatically stop once the pre-set pressure is reached, preventing over-inflation.

## How to Use



Remove the valve cap & connect the hose pipe



Press power button to turn on the machine



Short press  to choose modes or set desired PSI manually\*



Press power button to inflate. Once done it will auto shut

\*Press +/- to set the pressure manually

Long press  to change unit ( Bar | PSI | kPa | Kg/cm<sup>2</sup> )

Image: A visual step-by-step guide demonstrating how to use the AGARO Galaxy inflator: connecting the hose, powering on, selecting modes/setting pressure, and initiating inflation with auto shut-off.

# No Over-Inflation. No Guesswork.

 **Auto  
Cut Off**



Image: The AGARO Galaxy inflator connected to a car tire, illustrating its automatic cut-off feature to prevent over-inflation.

## Multi-Purpose Use

The inflator comes with multiple nozzles to accommodate various items:

- **Car/Bike Tires:** Standard nozzle for vehicle tires.
- **Bicycles:** Specific nozzle for bicycle tires.
- **Sports Balls:** Needle nozzle for footballs, basketballs, etc.
- **Inflatables:** Cone nozzle for floating tubes, air mattresses, etc.

# High capacity **portable** tyre inflator

Inflates from 3-150 PSI

Ready for Everything



Image: The AGARO Galaxy inflator demonstrating its versatility by inflating tires for cars, bikes, bicycles, and sports balls.

# Multi-Purpose Use



Image: A collage showing the multi-purpose use of the AGARO Galaxy inflator for car/bike tires, floating tubes, bicycles, and playing balls.

## Additional Functions

- LED Flashlight:** The inflator features a 3-mode LED light on top, useful for inflating in low-light conditions, changing tires at night, or as a warning light.
- Power Bank:** The USB output port on the bottom allows the inflator to function as an emergency power supply for charging electronic devices.

## MAINTENANCE

- Cleaning:** Wipe the device with a soft, dry cloth. Do not use abrasive cleaners or immerse in water.
- Storage:** Store the inflator and its accessories in a cool, dry place, away from direct sunlight and extreme temperatures. The bendable air hose can be stored on the appliance.
- Battery Care:** For optimal battery life, charge the device regularly, even if not in frequent use. Avoid completely draining the battery.

## TROUBLESHOOTING

Problem	Possible Cause	Solution
Inflator does not turn on.	Battery is depleted.	Charge the device fully using the provided USB cable.
Inflator stops prematurely.	Pre-set pressure reached.	This is normal operation (auto shut-off). Check the tire pressure.
Slow inflation or low airflow.	Hose not securely connected; Battery low; Device overheating.	Ensure hose is tightly connected. Charge the battery. Allow device to cool down for 3-5 minutes.

Problem	Possible Cause	Solution
Inaccurate pressure reading.	Sensor issue; Incorrect unit selected.	Ensure the hose is properly connected. Verify the correct pressure unit (PSI, BAR, KPA, KG/CM <sup>2</sup> ) is selected.

## SPECIFICATIONS

Feature	Specification
Model	Galaxy
Brand	AGARO
Material	Plastic
Color	Black
Item Weight	408 Grams
Product Dimensions (LxWxH)	9 x 4.5 x 14 cm
Power Source	Battery Powered (2x2000 mAh Lithium Ion)
Air Flow Capacity	17 Liters Per Minute
Maximum Pressure	150 PSI (Pound per Square Inch)
Operation Mode	Automatic
Hose Length	21 Inches
Special Features	Automatic Shut Off, Digital Display, Portable, LED Flashlight, Power Bank Function

## WARRANTY AND SUPPORT

The AGARO Galaxy Cordless Tyre Inflator comes with a 1-year warranty from the date of purchase. For warranty claims, technical support, or any product-related inquiries, please contact AGARO customer service. Refer to your purchase documentation for specific contact details.

© 2025 AGARO. All rights reserved.

## Related Documents - Galaxy

<p>INSTRUCTION MANUAL</p> <p><b>AGARO</b> Oven Toaster Griller</p>  <p>Model : Grand-30L</p> 	<p><a href="#">AGARO Grand-30L Oven Toaster Griller Instruction Manual</a></p> <p>This manual provides detailed instructions for operating and maintaining the AGARO Grand-30L Oven Toaster Griller. It covers safety precautions, component identification, various cooking functions, cleaning, storage, specifications, and warranty information.</p>
<p>USER MANUAL</p> <p><b>AGARO</b> Electric Rice Cooker</p>  <p>Model: Regal</p> 	<p><a href="#">AGARO Regal Electric Rice Cooker User Manual - Features, Specifications, and Operation</a></p> <p>Comprehensive user manual for the AGARO Regal Electric Rice Cooker. Learn about its features, functions, safety precautions, product specifications, and warranty information.</p>
<p>MANUAL</p> <p><b>AGARO</b></p>  <p>Professional Hair Dryer</p> <p>Model : HD1120</p> <p>Item No.: 2602</p> 	<p><a href="#">Agaro HD1120 Professional Hair Dryer User Manual</a></p> <p>User manual for the Agaro HD1120 Professional Hair Dryer, detailing its features, settings, usage instructions, and warranty information.</p>
<p><b>Galaxy</b> VACUUM PACKAGING MACHINE</p>  <p>Galaxy GVME16SS Vacuum Packaging Machine with 16" Seal Bar, Roll Cutter and Dual Piston Pump - 120V, 550W</p> <p>Technical Data</p> <p>Specification</p> <p>Warranty</p> 	<p><a href="#">Galaxy GVME16SS Vacuum Packaging Machine - Features and Specifications</a></p> <p>Discover the features and technical specifications of the Galaxy GVME16SS Vacuum Packaging Machine, including its 16" seal bar, roll cutter, dual piston pump, and adjustable vacuum pressure.</p>
	<p><a href="#">tzumi Pocket Juice 20,000 mAh Portable Charger User Manual</a></p> <p>The tzumi Pocket Juice 20,000 mAh Portable Charger is a high-capacity power bank designed to charge phones and other portable devices. This manual provides product specifications, detailed charging instructions for both the power bank and connected devices, and important safety safeguards for optimal use and longevity.</p>
<p>YFZIN</p> 	<p><a href="#">YFZIN Watch Wireless Charger Power Bank P1 User Manual</a></p> <p>Comprehensive user manual for the YFZIN P1 Watch Wireless Charger Power Bank. Learn about its specifications, compatibility with Apple Watch and Samsung Galaxy Watch, how to use it, understand status alerts, and review important safety warnings and FCC compliance details.</p>