

[Manuals.plus](#) /

> [IQ](#) /

> IQ LEGO Ninjago Magnet - Kai (53347) Instruction Manual

**IQ 53347**

# IQ LEGO Ninjago Magnet - Kai (53347) Instruction Manual

Model: 53347

## PRODUCT OVERVIEW

---

The IQ LEGO Ninjago Magnet - Kai (Model 53347) is a decorative and functional silicone magnet featuring the character Kai from the NINJAGO Dragons Rising TV series. It is designed for use on magnetic surfaces such as refrigerators, lockers, and whiteboards.



Image: Front view of the IQ LEGO Ninjago Kai magnet, depicting the red ninja character with a golden sword. This magnet is made from flexible silicone.

## SETUP INSTRUCTIONS

1. **Unpack the Magnet:** Carefully remove the LEGO Ninjago Kai magnet from its packaging.
2. **Identify Magnetic Surface:** Choose a clean, flat magnetic surface for placement, such as a refrigerator door, metal locker, or whiteboard.

3. **Attach the Magnet:** Place the magnet directly onto the desired magnetic surface. The embedded magnetic backing will adhere to the surface.



Image: The magnet attached to a refrigerator, demonstrating its intended use for holding notes or as decoration.

## OPERATING INSTRUCTIONS

---

The LEGO Ninjago Kai magnet is designed for simple operation:

- **Placement:** Position the magnet on any ferrous metal surface.
- **Holding Items:** The magnet can securely hold lightweight items such as notes, drawings, or photos against the magnetic surface. Ensure the item is flat against the surface for optimal hold.
- **Repositioning:** To move the magnet, gently pull it away from the surface and re-attach it to a new location. Avoid sliding it forcefully across surfaces to prevent scratches.

## MAINTENANCE AND CARE

---

To ensure the longevity and appearance of your LEGO Ninjago Kai magnet, follow these care guidelines:

- **Cleaning:** Wipe the magnet with a soft, damp cloth. For stubborn marks, a mild soap solution can be used, followed by wiping with a clean, damp cloth and then drying thoroughly.
- **Avoid Harsh Chemicals:** Do not use abrasive cleaners, solvents, or harsh chemicals, as these can damage the silicone material and printed design.
- **Storage:** When not in use, store the magnet on a flat, clean surface or attached to a magnetic board to prevent bending or damage.
- **Temperature:** Avoid exposing the magnet to extreme temperatures or direct sunlight for prolonged periods, which could affect the material's integrity.

## TROUBLESHOOTING

---

If you encounter any issues with your magnet, consider the following:

- **Magnet Not Sticking:**
  - Ensure the surface is magnetic. Test with another known magnet if unsure.
  - Check if the surface is clean and free of debris that might prevent full contact.
  - Verify the magnet itself is clean and undamaged.
- **Magnet Appears Damaged:**
  - Inspect the silicone for tears or significant abrasions.
  - Check the embedded magnetic backing for any visible damage or detachment.

## SPECIFICATIONS

---

<b>Model Number</b>	53347 (Manufacturer Part Number: 53346)
<b>Brand</b>	IQ
<b>Character</b>	Kai from NINJAGO Dragons Rising
<b>Material</b>	Flexible Silicone
<b>Color</b>	Red
<b>Approximate Size</b>	83mm / 3 inches tall
<b>Item Weight</b>	0.05 Kilograms
<b>Included Components</b>	1 Silicone Magnet
<b>Manufacturer</b>	IQ Hong Kong, Ltd.




Image: Size reference for the magnet, indicating its approximate height of 3 inches (83mm).



Image: Rear view of the magnet, displaying the embedded magnetic surface and manufacturing details.

## WARRANTY AND SUPPORT

Information regarding specific warranty terms or direct support contacts for this product is not provided in the available documentation. For any inquiries, please refer to the retailer or the official IQ brand website.

This manual provides instructions for the IQ LEGO Ninjago Magnet - Kai (53347).  
© 2023 The LEGO Group. Manufactured by IQ Hong Kong, Ltd.