



Manuals.plus /

› BUAIAHUG /

› BUAIAHUG 10-in-1 Baby Food Maker Instruction Manual - Model BF01

BUAIAHUG BF01

BUAIAHUG 10-in-1 Baby Food Maker Instruction Manual

MODEL: BF01

[Introduction](#)

[What's in the Box](#)
[Maintenance](#)

[Setup](#)
[Troubleshooting](#)

[Operating Instructions](#)
[Specifications](#)

[Making Baby Food](#)
[Warranty & Support](#)

[Cleaning &](#)

1. Introduction

The BUAIAHUG 10-in-1 Baby Food Maker is a versatile appliance designed to simplify the process of preparing healthy and fresh meals for your baby. This device combines multiple functions including steaming, blending, cooking, mashing, pureeing, keeping warm, timing, auto-cleaning, and sterilizing, all controlled via an intuitive touch screen. Its compact design and dishwasher-safe components ensure convenience and ease of use for busy parents.



Image 1.1: The BUAIAHUG 10-in-1 Baby Food Maker, showcasing its compact design and various functions for preparing baby food.

2. What's in the Box

Upon unboxing your BUAIAHUG Baby Food Maker, please ensure all the following components are present:

- Main Unit (275W Motor Base)
- Lid
- Glass Bowl (350ml capacity)
- Blade Assembly
- Cup Holder / Steam Basket
- Silicone Spatula
- Silicone Spoon
- Cleaning Brushes
- Power Cable
- Product Manual & Recipes
- Citric Acid Detergent (for descaling)

- Baby Food Storage Squeeze Pouches

MAKE FRESH & HEALTHY MEALS FOR YOUR LITTLE ONE



Image 2.1: A visual representation of all included accessories and the main unit of the baby food maker.

Video 2.1: An unboxing video demonstrating the contents of the BUAIAHUG Baby Food Maker package.

3. Setup

Before first use, thoroughly wash all detachable parts (glass bowl, blade assembly, cup holder, lid) with warm soapy water or in the dishwasher. Ensure all parts are completely dry before assembly.

1. **Assemble the Blending Unit:** Place the blade assembly securely into the bottom of the glass bowl.
2. **Insert Cup Holder:** Place the cup holder/steam basket into the main unit.
3. **Position Glass Bowl:** Carefully place the assembled glass bowl onto the main unit, ensuring it sits correctly.
4. **Secure the Lid:** Place the main lid onto the glass bowl and twist to lock it into place.
5. **Fill Water Reservoir:** For steaming or sterilizing functions, fill the water reservoir in the main unit with clean water up to the 'MAX' indicated line (220ml).
6. **Connect Power:** Plug the power cable into the back of the unit and then into a suitable power outlet.

SEPARATE DESIGN & SAFETY CERTIFICATION



4. Operating Instructions

The BUAIAHUG Baby Food Maker features a user-friendly touch screen control panel with 10 distinct modes for various food preparation needs.

4.1. Control Panel Overview

The touch screen displays time and various function icons. Buttons include 'Mode', '+ Time', '- Time', 'Timer', 'Pulse', and 'Start/Stop'.



Image 4.1: The touch screen control panel showing various function icons and control buttons.

4.2. Steaming Food

1. Ensure the water reservoir is filled to the 'MAX' line.
2. Place the chopped food (e.g., fruits, vegetables, meat) into the glass bowl with the blade assembly.
3. Close the lid securely.
4. Select the appropriate steaming mode (e.g., 'Vegetable Puree', 'Fruit Puree', 'Meat Puree', 'Fish Puree', 'Porridge'). The device will automatically set a default steaming time.
5. Press 'Start/Stop' to begin steaming. The device will heat the water and steam the food.

4.3. Blending/Pureeing Food

1. After steaming, the device may automatically blend depending on the selected mode.
2. For manual blending or to adjust consistency, press the 'Pulse' button for short bursts or select 'Manual Blend'.
3. Add a small amount of water or breast milk if a thinner consistency is desired.

4.4. Warming Baby Bottles/Food

1. Place the baby bottle or a container of food into the warming area of the main unit.
2. Select the 'Keep Warm' mode.
3. Adjust the warming time using the '+ Time' or '- Time' buttons. The device can maintain a constant 65°C temperature for up to 12 hours.
4. Press 'Start/Stop' to begin warming.

4.5. Sterilizing

1. Ensure the water reservoir is filled to the 'MAX' line.
2. Place the items to be sterilized (e.g., bottle nipples, small utensils) into the steam basket.
3. Close the lid securely.
4. Select the 'Sterilize' mode.
5. Press 'Start/Stop' to begin the sterilization cycle.

ONE-STOP AUTOMATIC STEAMER AND BLENDER

4 STEPS, CUSTOMIZE YOUR BABY'S NUTRITIOUS FOOD

STEPS 1
Fill Water to 220ml Max water levers

STEPS 2
Add healthy food

STEPS 3
Choose mode and start

STEPS 4
Feeding baby or Storage

Image 4.2: A visual guide to the four easy steps of using the baby food maker: add water, add food, choose mode, and serve.

Video 4.1: A demonstration of the AMZCHEF Baby Food Maker with auto steam and blend functions, showing the process from adding ingredients to the final puree.

Video 4.2: A detailed video showcasing the 5-in-1 Baby Food Processor, including auto cooking, grinding, and steaming capabilities.

5. Making Baby Food (Recipes & Examples)

The included recipe booklet provides detailed instructions for various purees suitable for different stages of your baby's development. Here are a few examples:

5.1. Banana Puree

1. Peel and slice ripe bananas.
2. Place banana slices into the glass bowl with the blade assembly.
3. Add water to the reservoir (MAX line).
4. Select 'Fruit Puree' mode. The device will steam and then blend the bananas to a smooth consistency.

Video 5.1: A step-by-step guide on how to prepare banana puree using the baby food maker.

5.2. Carrot Puree

1. Peel and wash carrots thoroughly.
2. Cut carrots into small, thin round pieces or cubes.
3. Place chopped carrots into the glass bowl with the blade assembly.
4. Add water to the reservoir (MAX line).
5. Select 'Vegetable Puree' mode (default 20 minutes steaming time). The device will steam and then blend.

5.3. Avocado Puree

1. Halve and pit a ripe avocado. Scoop out the flesh.
2. Place avocado flesh into the glass bowl with the blade assembly.
3. Select 'Manual Blend' or 'Pulse' until desired consistency is reached. Steaming is not typically required for avocado.

MEETING THE NEEDS OF BABY'S GROWTH STAGES

Growing with your baby



4-6 MONTHS

Super Smooth Puree



7-9 MONTHS

Creamy Puree



9-12 MONTHS

Granular Food Supplements



13+ MONTHS

Block Food

Image 5.2: Different puree consistencies, from super smooth to granular, catering to various baby growth stages (6-13+ months).

6. Cleaning and Maintenance

Proper cleaning and maintenance ensure the longevity and hygienic operation of your baby food maker.

6.1. Daily Cleaning

- Immediately after each use, unplug the device and allow it to cool.
- The glass bowl, cup holder, and blade assembly are dishwasher safe. They can also be hand-washed

with warm soapy water using the provided cleaning brushes.

- Wipe the main unit (motor base) with a damp cloth. Do not immerse the main unit in water.
- Ensure all parts are completely dry before reassembling or storing.

6.2. Auto Clean Function

The device features an 'Auto Clean' mode for convenient cleaning of the internal steaming components. Refer to the product manual for specific instructions on using this function.

6.3. Descaling

Over time, mineral deposits may accumulate in the water reservoir. Use the provided citric acid detergent or a descaling solution as per the instructions in the manual to remove these deposits. Regular descaling helps maintain optimal performance.

AUTO CLEAN AND DISHWASHER-SAFE



Image 6.1: Visual guide highlighting the dishwasher-safe parts (glass bowl, cup holder, blades) and the auto-clean feature.

7. Troubleshooting

If you encounter any issues with your BUAlAHUG Baby Food Maker, please refer to the following common problems and solutions:

- **Device Not Turning On:** Ensure the power cable is securely plugged into both the unit and a working power outlet. Check if the lid is properly closed and locked.
- **Error Code Displayed (e.g., E1):** An error code usually indicates a specific issue. Refer to the

detailed troubleshooting section in your product manual for the meaning of specific codes and recommended actions.

- **Blending Function Not Working:** Ensure the blade assembly is correctly installed and the glass bowl is properly seated. Check if the food quantity is within the recommended limits. If the food is too thick, add a small amount of liquid (water, breast milk) to aid blending.
- **Steaming Not Producing Steam:** Verify that the water reservoir is filled to the 'MAX' line. Ensure the lid is securely closed.
- **Food Not Cooked Properly:** Adjust the steaming time using the '+ Time' or '- Time' buttons. Ensure food is cut into small, uniform pieces for even cooking.

8. Specifications

Model Number	BF01
Product Dimensions	7.5 x 7.5 x 11 inches
Item Weight	4.44 pounds
Water Reservoir Capacity	220ml (MAX line)
Stirring Bowl Capacity	350ml
Power	275W Motor
Material	BPA-Free, Glass Cooking Basket, Tritan Base, Food-Grade Material
Functions	10-in-1 (Steamer, Blender, Cooker, Masher, Puree, Keep Warm, Timer, Auto Clean, Sterilize, Pulse)

9. Warranty and Support

BUAIAHUG is committed to providing high-quality products and excellent customer service. Your baby food maker comes with comprehensive support:

- **24 Hours Quick Reply:** Expect a response to your inquiries within 24 hours.
- **30 Days No Reason to Return:** Enjoy a 30-day return policy for any reason.
- **24 Months Return and Exchange:** Benefit from a 24-month period for returns and exchanges due to product defects.
- **Lifetime After-Sale Service and Technical Support:** Receive ongoing support and technical assistance for the lifetime of your product.



Image 9.1: Visual representation of BUAIAHUG's customer support and warranty policies.