

[Manuals.plus](#) /

› [PERFASCIN](#) /

› PERFASCIN RG52B/BGE Replacement Remote Control Instruction Manual

PERFASCIN RG52B/BGE

PERFASCIN RG52B/BGE Replacement Remote Control Instruction Manual

For Midea Air Conditioner Models RG52B/BGEU, RG52B/BGCE

INTRODUCTION

This manual provides comprehensive instructions for the PERFASCIN RG52B/BGE Replacement Remote Control. This remote is designed to be compatible with various Midea Air Conditioner models, including RG52B/BGEU and RG52B/BGCE. It serves as a direct replacement and does not require programming. Please note that while it functions effectively, it may not replicate every function of your original remote control.

SETUP

Battery Installation

1. Locate the battery compartment on the back of the remote control.
2. Slide the battery compartment cover downwards to open it.
3. Insert two new AAA alkaline batteries, ensuring the positive (+) and negative (-) terminals match the diagrams inside the compartment. **Important:** Use new alkaline batteries. Rechargeable batteries may not provide sufficient power.
4. Slide the battery compartment cover back into place until it clicks securely.



Figure 1: Battery compartment open, ready for battery insertion.

Initial Use

Once batteries are installed, the remote control is ready for use. No programming or pairing is required. Simply point the remote towards your Midea Air Conditioner and begin operation.

OPERATING INSTRUCTIONS

Familiarize yourself with the buttons on your remote control. Below is a description of common functions:



Figure 2: Front view of the remote control with labeled buttons.

- **ON/OFF:** Powers the air conditioner on or off.
- **MODE:** Cycles through operating modes such as Cool, Heat, Fan, Dry, Auto.
- **FAN:** Adjusts the fan speed (e.g., Low, Medium, High, Auto).
- **TEMP ▲/▼:** Increases or decreases the set temperature.
- **SLEEP:** Activates or deactivates the sleep mode, which adjusts temperature for comfortable sleep and saves energy.
- **TURBO:** Engages maximum cooling or heating power for rapid temperature change.
- **TIMER ON:** Sets a timer for the air conditioner to turn on automatically.
- **TIMER OFF:** Sets a timer for the air conditioner to turn off automatically.
- **SHORTCUT:** Used to restore current settings or resume a previous setting. If pressed for more than 2 seconds, the system will automatically restore the current operation setting.
- **SWING DIRECT:** Controls the direction of the air swing louvers.
- **LED:** Turns the display light on the air conditioner unit on or off.

MAINTENANCE

Battery Replacement

Replace batteries when the remote's range decreases or if the air conditioner does not respond to commands. Always replace both batteries with new AAA alkaline batteries simultaneously. Do not mix old and new batteries, or different types of batteries.

Cleaning

Wipe the remote control with a soft, dry cloth. Do not use liquid cleaners, sprays, or abrasive materials, as these can damage the remote's surface or internal components.

Storage

If the remote control will not be used for an extended period, remove the batteries to prevent leakage and potential damage to the device.

TROUBLESHOOTING

- **Remote not responding:**
 - Ensure new AAA alkaline batteries are correctly installed. Replace them if necessary.
 - Check for any obstructions between the remote control and the air conditioner's receiver.
 - Verify that you are within the effective operating range (approximately 33 feet or 10 meters) and pointing the remote directly at the air conditioner.
- **Specific functions not working:**
 - This remote is a replacement and may not support all advanced functions present on your original air conditioner remote. Refer to your air conditioner's manual for specific function compatibility.

If you continue to experience issues after following these troubleshooting steps, please contact customer support for further assistance.

SPECIFICATIONS

Brand	PERFASCIN
Model Number	MB1729-RG52B-BGCE (Compatible with RG52B/BGEU, RG52B/BGCE)
Connectivity Technology	Infrared
Maximum Range	33 Feet (approx. 10 meters)
Battery Type	2 x AAA Alkaline Batteries (not included)
Item Weight	2 Ounces (approx. 56.7 grams)
Special Feature	Ergonomic design

SUPPORT

For any questions regarding the compatibility or operation of your PERFASCIN RG52B/BGE Replacement Remote Control, please contact our customer support. You can typically find contact information on the product packaging or through the retailer where you purchased the item. We are committed to providing assistance and resolving any issues you may encounter.

© 2023 PERFASCIN. All rights reserved.

ASK A QUESTION ABOUT THIS MANUAL

Ask about setup, troubleshooting, compatibility, parts, safety, or missing instructions. Manuals+ will review the question and use this page's manual context to help answer it.

Name

Anonymous

Email

you@example.com

After a successful submission, we securely hash the supplied account or form email before sending it to Microsoft Advertising for conversion attribution. [Privacy details](#).

Question

Example: How do I reset this device or fix this error?

Details

Model number, symptoms, what you tried, or the section of the manual you are using.

Submit question

Open the live page

<https://manuals.plus/asin/B0CGX57RMG>

More documents and user manuals: <https://manuals.plus/>