

vibeadio Hybrid Active Noise Cancelling Headphones

vibeadio Hybrid Active Noise Cancelling Headphones User Manual

Model: Hybrid Active Noise Cancelling Headphones

Brand: vibeadio

1. INTRODUCTION

Thank you for choosing the vibeadio Hybrid Active Noise Cancelling Headphones. These headphones are designed to provide a superior audio experience with advanced noise cancellation technology, comfortable design, and extended battery life. This manual will guide you through the setup, operation, and maintenance of your new headphones.



Image 1: vibeadio Hybrid Active Noise Cancelling Headphones, showcasing the sleek black design.

2. PRODUCT OVERVIEW

The vibeadio Hybrid Active Noise Cancelling Headphones offer a range of features for an enhanced listening experience:

- **Hybrid Active Noise Cancellation:** Reduces ambient noise by up to 33dB, allowing for immersive audio.
- **Transparency Mode:** Allows you to hear your surroundings without removing the headphones, ideal for awareness.
- **Premium Hi-Fi Audio:** Equipped with customized 40mm drivers for rich bass and clear highs.
- **Bluetooth V5.3:** Ensures stable and high-quality wireless audio streaming.
- **Ultra Comfort Design:** Features breathable high-grade protein ear cushions and a lightweight build for extended wear.
- **Crystal Clear Hands-free Calls:** Advanced microphone system with ENC (Environmental Noise Cancellation) technology for clear voice transmission.
- **Extended Playtime:** Up to 30 hours of wireless listening without ANC, or 25 hours with ANC on a single charge.
- **Wired Mode:** Includes a detachable 3.5mm audio cable for continued listening when the battery is depleted.

3. SETUP

3.1 Charging the Headphones

Before first use, fully charge your headphones. Use the provided USB-C cable to connect the headphones to a power source.

1. Locate the USB-C charging port on the right earcup.
2. Connect one end of the USB-C cable to the headphone's charging port.
3. Connect the other end of the USB-C cable to a compatible USB power adapter (not included) or a computer's USB port.
4. The LED indicator will show charging status (e.g., red for charging, green/blue for fully charged).

TRANSPARENCY MODE

Help you stay
connected with the
world even during
playback.



Image 2: The headphones connected via USB-C for charging, highlighting the 30-hour playtime capability.

3.2 Bluetooth Pairing

To connect your headphones to a Bluetooth-enabled device:

1. Ensure the headphones are charged and powered off.

2. Press and hold the Power button until the LED indicator flashes blue and red, indicating pairing mode.
3. On your device (smartphone, tablet, computer), enable Bluetooth and search for available devices.
4. Select "vibeaudio Headphones" (or similar name) from the list of found devices.
5. Once connected, the LED indicator will turn solid blue or flash blue slowly.

4. OPERATING INSTRUCTIONS

4.1 Active Noise Cancellation (ANC) and Transparency Mode

Your headphones feature Hybrid Active Noise Cancellation and Transparency Mode to adapt to your environment.

- **Activating ANC:** Press the dedicated ANC button (often labeled 'NC') once to activate Active Noise Cancellation. This will reduce ambient noise for an immersive listening experience.
- **Activating Transparency Mode:** Press the ANC button a second time to switch to Transparency Mode. This allows external sounds to pass through, keeping you aware of your surroundings.
- **Deactivating:** Press the ANC button a third time to turn off both ANC and Transparency Mode.

OPTIMIZED HI-FI SOUND

40mm customized drivers
offer crisp, detailed listening.




Image 3: Detail of the headphones highlighting external and internal microphones for Hybrid Active Noise Cancelling.



Image 4: A person wearing the headphones, illustrating the use of Transparency Mode to stay connected with surroundings.

4.2 Basic Controls

The headphones feature intuitive controls for media playback and calls:

- **Power On/Off:** Press and hold the Power button.
- **Play/Pause:** Press the Multi-function button once.
- **Volume Up/Down:** Use the Volume + and Volume - buttons.
- **Next Track:** Press and hold Volume + button.
- **Previous Track:** Press and hold Volume - button.

5. COMFORT AND FIT

The headphones are designed for maximum comfort during prolonged use:

- **Adjustable Headband:** Extend or retract the headband to fit your head size comfortably.

- **Swiveling Earcups:** The earcups can swivel to conform to the shape of your ears, ensuring a secure yet gentle fit.
- **Memory Foam Ear Cushions:** The breathable protein ear cushions are soft and designed to reduce pressure, making them suitable for all-day wear.

COMFORT AND BETTER BUILT

30% lighter and breathable protein ear cushions for all-day comfort.



Image 5: Close-up of the headphone earcup, emphasizing the ultra-comfortable and lightweight design with breathable protein ear cushions.

6. CALL FUNCTIONS

The integrated microphone system allows for clear hands-free calls:

- **Answer/End Call:** Press the Multi-function button once.
- **Reject Call:** Press and hold the Multi-function button for 2 seconds.
- **Voice Assistant:** Double-press the Multi-function button to activate your device's voice assistant.
- **Environmental Noise Cancellation (ENC):** The advanced microphone system with ENC technology filters out background noise, ensuring your voice is heard clearly during calls.

CRYSTAL CLEAR CALLS

Advanced microphone system
and amplify your voice in any
setting.



Image 6: A man wearing the headphones, demonstrating the crystal clear call feature with noise filtering.

7. SPECIFICATIONS

Feature	Description
Brand	vibeaudio
Color	Black
Ear Placement	Over Ear
Form Factor	Over Ear
Noise Control	Hybrid Noise Cancellation

Feature	Description
Bluetooth Version	V5.3
Driver Size	40mm
Playtime (ANC Off)	Up to 30 hours
Playtime (ANC On)	Up to 25 hours
Charging Port	USB-C

8. MAINTENANCE

To ensure the longevity and optimal performance of your headphones:

- Clean the ear cushions and headband regularly with a soft, dry cloth.
- Avoid exposing the headphones to extreme temperatures, humidity, or direct sunlight.
- Do not use abrasive cleaners or solvents.
- Store the headphones in a protective case when not in use to prevent damage.

9. TROUBLESHOOTING

If you encounter issues with your headphones, refer to the following common solutions:

- **No Power:** Ensure the headphones are fully charged.
- **Cannot Pair:** Make sure Bluetooth is enabled on your device and the headphones are in pairing mode. Try restarting both devices.
- **No Sound:** Check the volume levels on both the headphones and your connected device. Ensure the headphones are correctly paired.
- **Poor Sound Quality:** Move closer to your connected device to avoid interference. Check for any obstructions between the headphones and the device.
- **ANC Not Working:** Ensure the ANC feature is activated by pressing the dedicated button.

If the problem persists, please contact customer support.

10. SAFETY INFORMATION

Please read and follow these safety guidelines:

- Do not use the headphones at high volume for extended periods to prevent hearing damage.
- Do not use the headphones in situations where inability to hear ambient sounds could be dangerous (e.g., driving, cycling, walking in traffic).
- Keep the headphones away from water and moisture.
- Do not attempt to disassemble or modify the headphones.
- Dispose of the product responsibly according to local regulations.

11. WARRANTY AND SUPPORT

Your vibeadio Hybrid Active Noise Cancelling Headphones come with a standard manufacturer's warranty. For detailed warranty information, product support, or service inquiries, please refer to the warranty card included in your product packaging or visit the official vibeadio website.

ASK A QUESTION ABOUT THIS MANUAL

Ask about setup, troubleshooting, compatibility, parts, safety, or missing instructions. Manuals+ will review the question and use this page's manual context to help answer it.

Name

Anonymous

Email

you@example.com

After a successful submission, we securely hash the supplied account or form email before sending it to Microsoft Advertising for conversion attribution. [Privacy details](#).

Question

Example: How do I reset this device or fix this error?

Details

Model number, symptoms, what you tried, or the section of the manual you are using.

Submit question