

WAMPAT W06F4055C-ET

WAMPAT W06F4055C-ET Rattan Nightstand with Charging Station Instruction Manual

Model: W06F4055C-ET | Brand: WAMPAT

IMPORTANT SAFETY INFORMATION

CAUTION: This product requires assembly. Keep small parts away from children. Do not use the charging station if the cord is damaged or if liquid has been spilled on it. Always follow the instructions provided with the product.

PRODUCT OVERVIEW

The WAMPAT Rattan Nightstand is designed to provide both storage and convenience. It features a simple appearance with round gourd furniture legs, suitable for various room aesthetics. This versatile piece can function as a nightstand, bedside table, sofa side table, or a record player stand. The nightstand includes a built-in charging station with 2 standard AC outlets and 2 USB ports, allowing for convenient charging of mobile phones, lamps, and other devices. The power cable length is 6.5 ft. An open shelf and two deep rattan drawers offer ample storage for books, glasses, and personal items. The rattan design on the drawer faces promotes air circulation. Drawers are equipped with smooth metal slides for easy operation.

Constructed from P2 MDF material and supported by four solid wood legs, this nightstand offers stability and durability. The wood used is FSC certified. The distance between the bottom plate and the floor is designed to allow robot vacuum cleaners to pass freely.



Image: Front view of the WAMPAT Rattan Nightstand with Charging Station, showcasing its light oak finish and rattan drawers.

Display Personality




Image: Detailed dimensions of the nightstand, showing its height, width, and depth, along with drawer measurements.



120V/12A
{2 AC Outlets}



120V/12A
{2 USB Ports}



6.5-Foot
{Power Cord}

Image: Close-up of the integrated charging station on the nightstand's top surface, featuring two AC outlets and two USB ports.



Wooden Gourd Legs



Elegant Rattan Drawer



Rechargeable Connector

Image: Close-up details highlighting the wooden gourd legs, the elegant rattan drawer face, and the secure rechargeable connector.

ASSEMBLY INSTRUCTIONS

Assembly of the WAMPAT Rattan Nightstand is designed to be straightforward with the provided detailed instructions and included tools. A screwdriver is recommended for assembly.

For a visual guide, please refer to the official assembly video below:

Your browser does not support the video tag.

Video: Official WAMPAT Rattan Side Table Assembly Video. This video provides step-by-step visual instructions for assembling your nightstand, including how to correctly install dowels, cam bolts, slider arms, and the charging socket.

General Assembly Steps:

1. **Prepare Components:** Identify all panels, hardware (dowels, cam bolts, screws), and tools.
2. **Assemble Side Panels:** Insert dowels and screw cam bolts into the designated panels (e.g., panels 4, 5, 9).
3. **Attach Support Panels:** Secure panels (6) to panels (4, 5) using cam locks.

4. **Install Slider Arms:** Separate the slide bracket from the slide arm. Attach the slider arms to the main panels (4, 5) with screws. Ensure correct orientation as per the diagram.
5. **Construct Main Frame:** Insert dowels into panel (2) and attach panels (4, 5) to panel (2) using cam locks.
6. **Attach Base Panel:** Screw cam bolts into panel (1). Attach panels (4, 5) to panel (1) and secure with cam locks.
7. **Slide in Back Panel:** Carefully slide the back panel (7) into place along the back of the assembly. Attach panel (3) to panels (4, 5) with screws.
8. **Attach Legs:** Secure the legs (8) to panel (3). Apply skid pads (O) to the bottom of the legs.
9. **Install Charging Socket:** Attach the charging socket (U) to panel (1) with screws (P). Secure the power cord with clips (F) and screws (G).
10. **Assemble Drawers:** Screw cam bolts into the drawer front panel (10). Attach handles (L) to panel (10) with bolts (K). Attach side panels (11, 12) to panel (10) and secure with cam locks. Carefully slide the bottom panel (14) into place.
11. **Attach Drawer Brackets:** Attach slider brackets to panels (11, 12) with screws.
12. **Insert Drawers:** Carefully insert the assembled drawers into the nightstand. If a drawer does not go in smoothly, press or lift the plastic release lever on the slider arm. Pull out the slider bracket from the slider arm, loosen the screws on the slider brackets to adjust up or down, then tighten back up. Re-assemble the drawer until it slides smoothly.

Tip for Enhanced Durability: For increased longevity and stability, it is recommended to apply wood glue (such as Titebond Original Wood Glue) to all dowel holes and wood-to-wood joints during assembly. This extra step can significantly strengthen the furniture's construction.



Image: The assembled WAMPAT Rattan Nightstand, showing the power cord extending from the back, ready for use.

OPERATING INSTRUCTIONS

Using the Charging Station:

1. Ensure the nightstand is fully assembled and stable.
2. Plug the 6.5 ft power cable from the charging station into a standard wall outlet.
3. To charge devices, plug them into the 2 standard AC outlets or the 2 USB ports located on the top surface of the nightstand.
4. Always ensure devices are properly connected and the power cable is not damaged or exposed to liquids.

MAINTENANCE

Cleaning and Care:

- To clean the surface of the nightstand, wipe it with a soft, damp cloth.
- Avoid using harsh chemicals or abrasive cleaners, as these may damage the finish.
- Regularly check all screws and connections to ensure they remain tight. Re-tighten if necessary.
- Keep the nightstand away from direct sunlight and excessive moisture to prevent warping or discoloration.
- The product is stain resistant, but spills should be wiped promptly.

TROUBLESHOOTING

Common Issues and Solutions:

- **Difficulty with Drawer Movement:** If drawers are hard to open or close, ensure the slider arms are correctly installed and aligned. You may need to loosen the screws on the slider brackets, adjust their position slightly (up or down), and then re-tighten them. Refer to the assembly video for detailed guidance on slider installation.
- **Wobbly Nightstand:** Check that all cam locks and screws are fully tightened. Ensure the nightstand is placed on a flat, even surface.
- **Charging Station Not Working:** Verify that the power cable is securely plugged into both the nightstand and a functional wall outlet. Check the cable for any visible damage. If issues persist, discontinue use and contact customer support.
- **Missing Parts:** If any parts are missing upon unboxing, please contact WAMPAT customer service immediately for assistance.

SPECIFICATIONS

Feature	Detail
Brand	WAMPAT
Model Name	W06F4055C-ET
Product Dimensions (D x W x H)	15.7" x 19.6" x 23.6"
Maximum Weight Recommendation	70 Pounds (Total)
Weight Capacity (Each Drawer)	10 Pounds
Frame Material	Wood (P2 MDF, Solid Wood Legs)
Top Material Type	Engineered Wood
Color	Light Oak
Number of Drawers	2
Number of Shelves	1

Handle Material	Metal (Black)
Charging Station	2 AC Outlets, 2 USB Ports
Power Cable Length	6.5 ft
Assembly Tools Included	Yes
FSC Certified	Yes

WARRANTY AND SUPPORT

WAMPAT offers various protection plans for your product. For detailed information regarding available 2-Year and 3-Year Protection Plans, or the Complete Protect plan, please refer to the product's purchase page or contact your retailer.

For any questions, concerns, or assistance with your WAMPAT Rattan Nightstand, please feel free to contact WAMPAT customer service. We are committed to providing professional service and support.