Saved from manuals.plus.
Open the live page for links to other documents and user manuals.

COMFEE' CKE17L1EHAGT

COMFEE' 1.7L Glass Electric Kettle with Temperature Control

Model: CKE17L1EHAGT | Brand: COMFEE'

Introduction

Thank you for choosing the COMFEE' 1.7L Glass Electric Kettle. This appliance is designed for efficient and safe water heating, offering precise temperature control and convenient features to enhance your beverage preparation. Please read this manual thoroughly before use to ensure proper operation and maintenance.

Important Safety Instructions

When using electrical appliances, basic safety precautions should always be followed to reduce the risk of fire, electric shock, and/or injury to persons, including the following:

- Read all instructions.
- Do not touch hot surfaces. Use handles or knobs.
- To protect against fire, electric shock, and injury to persons, do not immerse cord, plugs, or electric kettle in water or other liquid.
- Close supervision is necessary when any appliance is used by or near children.
- Unplug from outlet when not in use and before cleaning. Allow to cool before putting on or taking off parts, and before cleaning the appliance.
- Do not operate any appliance with a damaged cord or plug or after the appliance malfunctions, or has been damaged in any manner. Return appliance to the nearest authorized service facility for examination, repair, or adjustment.
- The use of accessory attachments not recommended by the appliance manufacturer may result in fire, electric shock, or injury to persons.
- Do not use outdoors.
- Do not let cord hang over edge of table or counter, or touch hot surfaces.
- Do not place on or near a hot gas or electric burner, or in a heated oven.
- Always attach plug to appliance first, then plug cord into the wall outlet. To disconnect, turn any control to “off,” then remove plug from wall outlet.

- Do not use appliance for other than intended use.
- Always ensure the lid is closed securely during operation.
- This kettle features automatic shut-off and boil-dry protection for enhanced safety.

Product Overview

The COMFEE' 1.7L Glass Electric Kettle combines functionality with a sleek design, featuring a durable borosilicate glass body and 304 food-grade stainless steel components. It offers a 1.7-liter capacity, ideal for preparing multiple servings of your favorite hot beverages.

Key Features:

- **1500W Fast Heating:** Boils water in 3-7 minutes.
- **6 Preset Temperature Settings:** Ranging from 160-212°F for various beverages (Flower, White, Green, Oolong, Coffee, Black Tea).
- **2-Hour Keep Warm Function:** Maintains desired temperature.
- **Precise Temperature Control:** Advanced thermostat ensures accuracy within ±5°F.
- **Food-Safe Materials:** 304 stainless steel base and BPA-free borosilicate glass body.
- **Built-in Safety:** Auto-off when reaching temperature and boil-dry protection.
- **LED Illumination:** Blue LED lights indicate heating status.
- **Easy to Clean:** Wide mouth and non-removable 50° lid for convenient filling and cleaning.
- **Spout Filter:** Helps keep tea grounds out of your cup.



Image: COMFEE' 1.7L Glass Electric Kettle with blue LED light indicating operation.



Image: Visual guide to the 6 temperature presets for various beverages like Flower, White, Green, Oolong, Coffee, and Black Tea.

Setup

1. **Unpack:** Carefully remove all packaging materials from the kettle and its base.
2. **Initial Cleaning:** Before first use, fill the kettle with water to the MAX line. Boil the water, then discard it. Repeat this process 2-3 times to remove any manufacturing residues.
3. **Placement:** Place the power base on a dry, flat, stable, and heat-resistant surface. Ensure the power cord is not dangling or touching hot surfaces.
4. **Power Connection:** Plug the power base into a standard electrical outlet.

Operating Instructions

1. Filling the Kettle

Open the lid by pressing the button on the handle. Fill the kettle with fresh water between the MIN (0.5L) and MAX (1.7L) fill lines indicated on the glass body. Close the lid securely.



Image: The kettle being filled with water, highlighting the MIN and MAX fill lines.

2. Boiling Water

Place the kettle onto the power base. Press the On/Off button. The blue LED light will illuminate, and the kettle will automatically heat up to boil (212°F). Once boiling, the kettle will automatically shut off.



Image: Step-by-step diagram illustrating how to boil water by pressing the On/Off button.

3. Heating to a Specific Temperature

Place the kettle onto the power base. Press the Temperature Adjustment button (usually marked with a thermometer icon) to cycle through the 6 preset temperatures (160°F, 175°F, 185°F, 190°F, 200°F, 212°F). Once your desired temperature is displayed, press the On/Off button. The kettle will heat to the selected temperature and

then automatically shut off.



Image: Step-by-step diagram illustrating how to select and heat water to a specific temperature.

4. Using the Keep Warm Function

After selecting your desired temperature (or after boiling), press the Keep Warm button (usually marked with a wavy lines icon). The kettle will maintain the set temperature for up to 2 hours. To deactivate, press the On/Off button or remove the kettle from the base.




Image: Step-by-step diagram illustrating how to activate the Keep Warm function after setting a temperature.

Video Demonstration: Temperature Control

Video: A demonstration of the COMFEE' Electric Kettle's temperature control with 6 presets, showing how to select different temperatures for various beverages.

Maintenance and Cleaning

Regular cleaning helps maintain the performance and longevity of your kettle. Always unplug the kettle and allow it to cool completely before cleaning.

Exterior Cleaning:

- Wipe the exterior of the kettle and the power base with a soft, damp cloth.
- Do not use abrasive cleaners or scouring pads, as they may scratch the surface.
- Never immerse the kettle or power base in water or other liquids.

Interior Descaling:

Mineral deposits (limescale) can build up inside the kettle, especially in hard water areas. Descale regularly to ensure optimal performance.

1. Fill the kettle with a solution of 1 part white vinegar and 2 parts water, or use a descaling solution recommended for electric kettles.
2. Bring the solution to a boil and let it stand for 20-30 minutes.
3. Discard the solution and rinse the kettle thoroughly with fresh water several times.
4. For stubborn deposits, you may need to repeat the process or gently scrub with a soft brush.

Troubleshooting

If your kettle is not functioning as expected, please check the following:

- **Kettle does not turn on:** Ensure the power base is securely plugged into a working outlet and the kettle is properly seated on the base.
- **Water is not heating:** Check that the On/Off button has been pressed and the desired temperature is selected. Ensure there is sufficient water in the kettle (above MIN line).
- **Kettle shuts off too quickly:** This may indicate limescale buildup. Refer to the descaling instructions in the Maintenance section.
- **Boil-dry protection activated:** If the kettle is accidentally switched on without water, the boil-dry protection will activate, turning off the heating element. Allow the kettle to cool down before refilling with water and restarting.

Specifications

Brand	COMFEE'
Model Name	CEKS002
Item Model Number	CKE17L1EHAGT
Capacity	1.7 Liters (1.8 Quarts)
Material	Glass (Borosilicate) & 304 Stainless Steel
Color	Transparent Digital
Special Feature	Digital Control, Temperature Control, Keep Warm, Auto-Off, Boil-Dry Protection

Product Dimensions	8.26"L x 6.33"W x 9.52"H
Item Weight	3.08 pounds
Manufacturer	COMFEE'
UPC	840296506028, 840296516072



Image: Dimensions of the COMFEE' 1.7L Glass Electric Kettle.

Warranty and Support

This COMFEE' electric kettle comes with a**1-year manufacturer warranty** from the date of purchase. Please retain your proof of purchase for warranty claims.
For any questions, technical assistance, or warranty service, please refer to the customer service information provided in the user manual included with your product or visit the official COMFEE' website.

Ask a question about this manual

Ask about setup, troubleshooting, compatibility, parts, safety, or missing instructions. Manuals+ will review the question and use this page's manual context to help answer it.

Name

Anonymous

Email

you@example.com

After a successful submission, we securely hash the supplied account or form email before sending it to Microsoft Advertising for conversion attribution. Privacy details.

Question

Example: How do I reset this device or fix this error?

Details

Model number, symptoms, what you tried, or the section of the manual you are using.

Submit question

Open the live page

https://manuals.plus/asin/B0CGZXMGJ5

More documents and user manuals: **https://manuals.plus/**