

## Migecon ZZJ003W

# MIGECON Electric Citrus Juicer Machine User Manual

Model: ZZJ003W

## INTRODUCTION

This manual provides detailed instructions for the safe and efficient operation of your MIGECON Electric Citrus Juicer Machine. Please read all instructions carefully before first use and retain this manual for future reference.

## PRODUCT FEATURES

- **Easy to Use & Clean:** Simple one-button operation and dishwasher-safe detachable parts. Includes a cleaning brush.
- **Portable and Convenient:** Rechargeable cordless design for use anywhere.
- **Versatile Juicing:** Suitable for various citrus fruits up to 2.9 inches (7.5cm) in diameter, including oranges, lemons, limes, and grapefruits.
- **Anti-drip Design:** Prevents juice spills and keeps countertops clean.
- **Safety-Certified Material:** Crafted from BPA-Free ABS material, ensuring safe and wholesome juice.

## SAFETY INFORMATION

- When you get the juicer, please fully charge before use.
- For safety, the juicer cannot be used while charging.
- Do not wash the juicer's main unit to prevent damage.
- If the button is showing a red light, it means the unit needs to be charged.
- If the button is showing a white light, it means it's fully charged and ready for use.

## SETUP

1. **Unpack:** Carefully remove all components from the packaging.
2. **Initial Charge:** Before first use, ensure the juicer is fully charged using the provided USB cable. The indicator light will turn white when fully charged.
3. **Assemble:** Place the juicing cone and filter basket onto the motor base. Ensure all parts are securely fitted.



POWERFUL **45W** MOTOR CAN EXTRACT JUICE IN **20 SECONDS**. CHARGE FOR **1.5 HOURS** AND USE FOR **100 TIMES**

Image: Fully assembled MIGECON Electric Citrus Juicer ready for use.

## OPERATING INSTRUCTIONS

1. **Prepare Fruit:** Cut your citrus fruit (oranges, lemons, limes, grapefruits) in half.
2. **Place Fruit:** Place one half of the fruit onto the juicing cone.

3. **Secure Lid:** Place the top cover over the fruit and twist to lock it into place.
4. **Start Juicing:** Press the power button on the front of the unit. The juicer will automatically rotate to extract juice.
5. **Dispense Juice:** Once juicing is complete, open the anti-drip spout to pour the fresh juice into a glass.



Image: Step-by-step guide for juicing with the MIGECON Electric Citrus Juicer.

Your browser does not support the video tag.

Video: Demonstration of the Electric Juicer Rechargeable in action, showing fruit being placed and juice being extracted and dispensed.

## CLEANING AND MAINTENANCE

1. **Disassemble:** Unlock and remove the top cover, juicing cone, and filter basket.
2. **Wash Detachable Parts:** The detachable parts (top cover, juicing cone, filter basket) are dishwasher safe or can be hand-washed with warm, soapy water. Use the provided cleaning brush for thorough cleaning.
3. **Clean Main Unit:** The main motor unit should *not* be submerged in water. Wipe it clean with a damp cloth.
4. **Dry and Store:** Ensure all parts are completely dry before reassembling and storing the juicer.

# JUICING TO THE MAX



VS



✓  
**MIGECON  
Juicer**



✗  
**Other  
Juicers**





Image: Disassembled juicer components for easy cleaning.

## TROUBLESHOOTING

Problem	Possible Cause	Solution
Juicer does not turn on.	Battery is low or depleted.	Charge the juicer fully. The indicator light will be red when charging and white when full.
Juicer stops during operation.	Fruit is too large or too much pressure is applied.	Ensure fruit size is within recommended limits (up to 2.9 inches). Apply gentle, consistent pressure.
Juice leaks from the spout.	Spout is not properly closed.	Ensure the anti-drip spout is in the closed position before and during juicing.

Problem	Possible Cause	Solution
Low juice yield.	Fruit not fully juiced or improper fruit placement.	Ensure fruit is centered on the cone. Allow the juicer to complete its cycle.

## SPECIFICATIONS

---

- **Brand:** Migecon
- **Model Name:** ZZJ003W
- **Color:** White
- **Special Feature:** Portable
- **Product Dimensions:** 4.4"D x 5.4"W x 9.4"H
- **Power Source:** Battery Powered
- **Maximum Power:** 45 Watts
- **Voltage:** 5 Volts
- **Material:** ABS (Acrylonitrile Butadiene Styrene)
- **Item Weight:** 1.65 pounds
- **Product Care:** Hand Wash Only (detachable parts are dishwasher safe)

## WARRANTY AND SUPPORT

---

For warranty information or product support, please refer to the manufacturer's official website or contact their customer service. Keep your purchase receipt for any warranty claims.

[Visit the Migecon Store for more information.](#)