Saved from manuals.plus.
Open the live page for links to other documents and user manuals.

isinwheel PJ-E9D-QD-6701-1828367601

User Manual

ISINWHEEL HEADLIGHT FOR S9PRO/S9MAX ELECTRIC SCOOTERS

Model: PJ-E9D-QD-6701-1828367601

1. Product Overview

This manual provides instructions for the installation, operation, and maintenance of the isinwheel replacement headlight. This accessory is specifically designed for isinwheel s9pro and s9max adult electric scooters, serving as a direct replacement for the original headlight unit.

2. Safety Information

- Always disconnect power to the scooter before attempting any installation or maintenance.
- Ensure all connections are secure and properly insulated to prevent electrical shorts.
- Do not modify the headlight or its wiring. Unauthorized modifications may void warranty and pose safety risks.
- Keep the headlight clean and free from obstructions to ensure optimal light output.
- If you are unsure about any installation step, consult a qualified technician.

3. Package Contents

The package should contain the following item:

- 1 x isinwheel Replacement Headlight Unit

4. Setup and Installation

Follow these general steps for installing the replacement headlight. Specific mounting points and wiring routes may vary slightly depending on your scooter model.

1. **Prepare the Scooter:** Ensure the scooter is powered off and the battery is disconnected or removed to prevent accidental power-on during installation.
2. **Locate Old Headlight:** Identify the existing headlight unit and its mounting points and electrical connections.
3. **Remove Old Headlight:** Carefully unmount the old headlight. This may involve unscrewing fasteners and disconnecting electrical connectors. Note the orientation and wiring for reinstallation.

4. **Connect New Headlight:** Connect the electrical wire of the new isinwheel headlight to the corresponding wiring harness on the scooter. Ensure the connection is firm and correct.
5. **Mount New Headlight:** Secure the new headlight unit to the scooter's designated mounting location using appropriate fasteners. Ensure it is firmly attached and aimed correctly.
6. **Test Functionality:** Reconnect the scooter battery and power on the scooter. Test the headlight to ensure it illuminates properly.



An image showing the isinwheel replacement headlight. The headlight features a circular lens with a black housing, partially covered in clear bubble wrap, and a black electrical wire extending from its base. It is placed on a light brown wooden surface.

5. Operation

The isinwheel replacement headlight operates in conjunction with your scooter's electrical system. Typically, the headlight will activate when the scooter's power is turned on, or via a dedicated light switch if your scooter is equipped with one. Refer to your scooter's main user manual for specific instructions on operating its lighting system.

6. Maintenance

- **Cleaning:** Use a soft, damp cloth to wipe the lens and housing of the headlight. Avoid abrasive cleaners or solvents that could damage the plastic.
- **Inspection:** Periodically check the headlight for any signs of damage, loose connections, or wear. Ensure the mounting is secure.
- **Storage:** If storing the scooter for an extended period, ensure the headlight is clean and protected from extreme temperatures or moisture.

7. Troubleshooting

Problem	Possible Cause	Solution
Headlight does not turn on.	No power to scooter. Loose or disconnected wiring. Faulty headlight unit. Scooter's light switch is off (if applicable).	Ensure scooter is powered on and battery is charged. Check all electrical connections for tightness and proper contact. If connections are good, the headlight may be faulty and require replacement. Ensure the light switch on your scooter is in the 'on' position.
Headlight flickers.	Loose wiring connection. Intermittent power supply from scooter.	Inspect and secure all wiring connections. Consult a scooter technician if the power supply issue persists.

8. Specifications

Brand	isinwheel
Model Number	PJ-E9D-QD-6701-1828367601
Product Dimensions	6 x 6 x 6 cm
Item Weight	100 g
Number of Items	1
Batteries Included?	No
Compatible Scooter Models	isinwheel s9pro, s9max

9. Warranty and Support

Specific warranty terms and conditions for this product are not detailed within this manual. Please refer to the original product packaging, your purchase receipt, or the official isinwheel website for comprehensive warranty information.
For technical support, troubleshooting assistance beyond what is provided in this manual, or inquiries regarding replacement parts, please contact isinwheel customer service through their official channels or the retailer from whom the

product was purchased.
You can visit the isinwheel store page for more information:isinwheel Store

© 2024 isinwheel. All rights reserved.

Ask a question about this manual

Ask about setup, troubleshooting, compatibility, parts, safety, or missing instructions. Manuals+ will review the question and use this page's manual context to help answer it.

Name

Anonymous

Email

you@example.com

After a successful submission, we securely hash the supplied account or form email before sending it to Microsoft Advertising for conversion attribution. Privacy details.

Question

Example: How do I reset this device or fix this error?

Details

Model number, symptoms, what you tried, or the section of the manual you are using.

Submit question

Open the live page

https://manuals.plus/asin/B0CH16TC1X

More documents and user manuals: **https://manuals.plus/**