

[Manuals.plus](#) /

> [ALTSON](#) /

> ALTSON 60 LED Portable Selfie Light Instruction Manual

ALTSON 60 LED Selfie Light

ALTSON 60 LED Portable Selfie Light Instruction Manual

Model: 60 LED Selfie Light

1. INTRODUCTION

The ALTSON 60 LED Portable Selfie Light is designed to provide versatile and high-quality lighting for various applications, including photography, video recording, live streaming, and makeup. Featuring a high Color Rendering Index (CRI) of 97+, three adjustable light modes, and ten brightness levels, this compact and rechargeable light ensures optimal illumination in diverse environments. Its multi-functional design allows for easy attachment to phones, laptops, cameras, and tripods, making it an essential tool for content creators and everyday users.

2. PACKAGE CONTENTS

Please verify that all items listed below are included in your package:

- 2 x LED Video Light
- 2 x Clip
- 2 x USB-C Cable
- 2 x 1/4" Nut Adapter
- 2 x 1/4" Hot Shoe Mount
- 2 x Storage Pouch
- 1 x User Manual

Your browser does not support the video tag.

Video: D6 Video Light Unboxing and Setup. This video demonstrates the unboxing process and shows all included components of the ALTSON 60 LED Portable Selfie Light.

3. PRODUCT OVERVIEW

The ALTSON 60 LED Portable Selfie Light features a compact design with intuitive controls and versatile mounting options. It is equipped with 60 LED beads to provide bright and even illumination.

Key Features:

- **High CRI 97+:** Ensures accurate color reproduction for professional-looking photos and videos.
- **3 Light Modes & 10 Brightness Levels:** Choose from White, White + Warm, and Warm light modes, with adjustable brightness from 10% to 100% and color temperature from 2900K to 6500K.
- **Rechargeable Battery:** Integrated 2200mAh battery provides approximately 4 hours of light at 50% brightness. Charges via USB-C.
- **Multi-functional Mounting:** Includes a clip for phones, tablets, laptops, and webcams, and a 1/4" threaded hot-shoe adapter for DSLR cameras, camcorders, tripods, and light stands.
- **160° Rotation:** Allows for precise light positioning and multi-angle shooting.
- **Compact & Portable:** Weighs only 95g (3.9*2.8*0.78in), easily fits in a pocket or pouch.



Image: Structure Introduction. This diagram highlights the various buttons and ports on the selfie light, including controls for brightness, color temperature, power, battery indicator, and the USB-C charging port.

Powerful and Light

Integrated rechargeable battery offers up to 150 minutes of runtime for on-the-go use



Lightweight and compact design, easy to carry it around

Image: Multiple Light Modes. This image illustrates the three distinct light modes (White, Natural, Warm) and the adjustable color temperature and brightness settings available on the device.

4. SETUP

Follow these steps to set up your ALTSOON 60 LED Portable Selfie Light:

1. **Attaching the Clip:** Locate the mounting slots on the back of the LED light. Slide the provided clip into one of the slots until it securely locks into place. The clip features scratch-resistant sponge to protect your devices.
2. **Attaching the Hot Shoe Mount (for cameras/tripods):** If using with a camera or tripod, attach the 1/4" Nut Adapter to the hot shoe mount. Then, slide the hot shoe mount into one of the mounting slots on the LED light. Secure it by tightening the screw on the hot shoe mount.
3. **Positioning:** The light can be rotated 160° on its mount, allowing you to adjust the angle for optimal lighting.

Multiple Light Modes

3 Color Modes come in handy whenever you need extra light for makeup, taking photos, making videos or live-streaming




Image: Widely Application. This image demonstrates the versatility of the selfie light, showing its use for makeup, photography, selfies, and live-streaming, highlighting its adaptability to different devices and scenarios.

Your browser does not support the video tag.

Video: ALTSON LED Selfie Light Product Video. This video showcases the product's features, including its compact design, mounting options, and adjustable lighting, demonstrating how it can be used to simplify photography and enhance multi-angle shooting.

5. OPERATING INSTRUCTIONS

The ALTSON 60 LED Portable Selfie Light is designed for ease of use with clearly marked buttons.

1. **Power On/Off:** Press and hold the power button () located on the side of the light to turn it on or off.
2. **Adjust Brightness:** Use the '+' and '-' buttons to increase or decrease the brightness level. There are 10 adjustable brightness levels.
3. **Change Light Mode/Color Temperature:** Press the snowflake (❄) or sun (☀) buttons to cycle through the three light modes: White, White + Warm, and Warm. This also adjusts the color temperature between 2900K and 6500K.
4. **Battery Indicator:** The LED indicator lights on the side of the device show the current battery level.

Your browser does not support the video tag.

Video: ALTSON LED Selfie Light Demo. This video demonstrates the various light modes and brightness levels of the ALTSON 60 LED Selfie Light, showing how to adjust settings for different lighting needs.

6. CHARGING

To charge the ALTSON 60 LED Portable Selfie Light:

1. Connect the provided USB-C cable to the Type-C charging port on the side of the light.
2. Connect the other end of the USB-C cable to a compatible USB power source (e.g., wall adapter, computer USB port, power bank).
3. The battery indicator lights will show the charging status. All lights will be solid when fully charged.

7. MAINTENANCE

To ensure the longevity and optimal performance of your selfie light:

- Clean the light surface with a soft, dry cloth. Avoid using abrasive cleaners or solvents.
- Store the light in its provided storage pouch when not in use to protect it from dust and scratches.
- Avoid exposing the device to extreme temperatures, direct sunlight, or high humidity.
- Do not disassemble the unit; this may damage the product and void the warranty.

8. TROUBLESHOOTING

If you encounter any issues with your ALTSON 60 LED Portable Selfie Light, please refer to the following common solutions:

Problem	Possible Cause	Solution
Light does not turn on.	Low battery or power button not pressed correctly.	Charge the device using the USB-C cable. Ensure the power button is pressed and held until the light activates.
Light is not charging.	Faulty cable, power source, or charging port.	Try a different USB-C cable and power source. Ensure the cable is securely connected to both the light and the power source.
Brightness or color temperature cannot be adjusted.	Buttons not functioning or device frozen.	Ensure the light is powered on. Briefly turn the light off and on again. If the issue persists, contact customer support.

9. SPECIFICATIONS

Feature	Detail
Brand	ALTSON

Feature	Detail
Battery Life	Up to 4 Hours (at 50% brightness)
Connectivity Technology	USB
Hardware Interface	USB Type C
Product Dimensions	4.92"L x 2.36"W x 6.5"H
Battery Capacity	2200mAh
CRI	97+
LED Count	60
Color Temperature	2900K-6500K

10. WARRANTY & SUPPORT

The ALTSON 60 LED Portable Selfie Light comes with a **24 Months Warranty**. For any problems or issues, please feel free to contact customer service.

Customer Service Email: service@szaltson.com